YAMAHA

# PARTS CATALOGUE

# DR2E22 AC LI ( J5A1 ) U.S.A., CANADA

YAMAHA GENUINE Parts & Accessories

1XJ5A-110E1

(  )

2022/6/22

| NEWS No. | DATE | COMMENT |
|---|---|---|
| PE0-GC-210007 | Nov.,18,2022 | MOD:FIG.18 or 20 ELECTRICAL 1 LIST REVISION |
| PE0-GC-220001 | Mar.,9,2022 | MOD:FIG.18 or 20 ELECTRICAL 1 LIST & ILLUST REVISION |

DR2E22 AC LI
PARTS CATALOGUE
©2022 by Yamaha Motor Co., Ltd.
1st edition, June 2022
All rights reserved.
Any reprinting or unauthorized use
without the written permission of
Yamaha Motor Co., Ltd.
is expressly prohibited.
Printed in Japan.

# FOREWORD

This Parts Catalogue is related to the parts for the model(s) on the cover page. When you are ordering replacement parts, please refer to this Parts Catalogue and quote both part numbers and part names correctly.

1. Modifications or additions which have been made after the issue of the Parts Catalogue will be announced in the Parts News.
   It is advisable that you make the necessary corrections to the Parts Catalogue according to the Parts News.

2. Abbreviations
   The following abbreviations are used in this Parts Catalogue.

   “UR” Use specified parts number.

   “UN” Use as many as needed.

   “AP” Alternate Parts

   “LM” Locally Made (Parts need to be ordered locally)

   “F#” Frame No. (Applicable machine No.)

   “O/S” Over Size

3. The number of components for assembly
   - Parts, which are to be supplied in an assembly, are listed with a dot (.) in front of the part name as shown below.
   - The numeral appearing to the right of each component part indicates the quantity of parts for each assembly unit.

| PART NO. | DESCRIPTION | Q’TY | REMARKS |
|---|---|---|---|
| 2F5–83310–60 | FRONT FLASHER LIGHT ASSY | 2 | |
| 115–83311–60 | .BULB (6V–18W) | 1 | |

4. Applicable colours of graphics are represented in the “REMARKS” as shown below.

| PART NO. | DESCRIPTION | Q’TY | REMARKS |
|---|---|---|---|
| 2N4–24110–00–X5 | FUEL TANK COMP. | 2 | MXR |
| 3J1–24240–10 | .GRAPHIC, FUEL TANK | 1 | FOR MXR |

5. Note that the illustrations for reference in finding parts numbers are not to be used for assembling. When assembling, please use the applicable service manual.

6. The asterisk (*) before a reference number indicates modified items after the first edition.

7. Applicable Serial No.

Frame Serial No.




8. Applicable Colour Code (The (*) mark shows Model colour.)

| Abbreviation | Colour Name | Colour Code |
|---|---|---|
| BW1(*) | BLUISH WHITE 1 | 1571 |
| DNBME(*) | DARK GRAYISH BLUE METALLIC E | 0866 |
| DNMC(*) | DARK GRAY METALLIC C | 0922 |
| HTR(*) | HEAT RED | 00EY |
| LNMP(*) | LIGHT GRAY METALLIC P | 0925 |
| MDBM2(*) | MAT DARK BLUE METALLIC 2 | 1712 |
| NYM6(*) | GRAYISH YELLOW METALLIC 6 | 1796 |
| NYS5(*) | GRAYISH YELLOW SOLID 5 | 1578 |
| VDGS1(*) | VERY DARK GREEN SOLID 1 | 0614 |
| | | |

9. Quantity Column Information

| Column No. | Name Of Q'ty Column | Destination |
|---|---|---|
| 1 | J5A1 | U.S.A., CANADA |
| | | |
| | | |
| | | |
| | | |

10. Applicable Starting Serial No.

Frame Serial No.

| Serial No. | Name Of Q'ty Column | Model Code |
|---|---|---|
| J5A-000101 | J5A1 | J5A1 |
| | | |
| | | |
| | | |
| | | |

# CONTENTS

## BODY


REAR ARM & SUSPENSION.....1
FRAME.....3
FRONT SUSPENSION & WHEEL.....4
STEERING.....6
PEDAL WIRE.....8
PEDAL ASSEMBLY.....9
BRAKE.....12


## DRIVE


TRANSAXLE.....13
REAR AXLE & WHEEL.....14
BUMPER.....15
BODY.....16
BODY 2.....18
BODY FITTING.....20
CARRIER.....21
SEAT.....22


## ELECTRICAL


ELECTRIC MOTOR.....23
CONTROLLER 1.....24
ELECTRICAL 1.....25
BATTERY CHARGER.....28
ALTERNATE FOR WINDSHIELD.....29
ALTERNATE FOR SUN ROOF.....31
ALTERNATE FOR SEAT.....32


## INDEX


NUMERICAL INDEX.....33




## FIG. 1 REAR ARM & SUSPENSION

| REF. NO. | PART NO. | DESCRIPTION | J5A1 | | | | | REMARKS |
|---|---|---|---|---|---|---|---|---|
| 1 | 95812–10020 | BOLT, FLANGE | 6 | | | | | |
| 2 | 95602–10200 | NUT, S/L FLANGE | 4 | | | | | |
| 3 | J0S–F2110–11 | REAR ARM COMP. | 1 | | | | | |
| 4 | J0S–F141K–10 | BRACKET, OUTER 1 | 1 | | | | | |
| 5 | J0S–F141L–10 | BRACKET, OUTER 2 | 1 | | | | | |
| 6 | J0S–F1485–00 | DAMPER, RUBBER 1 | 4 | | | | | |
| 7 | 95822–10020 | BOLT, FLANGE | 4 | | | | | |
| 8 | J0B–F1531–00 | BOLT | 2 | | | | | |
| 9 | 95602–10200 | NUT, S/L FLANGE | 4 | | | | | |
| 10 | J0S–F139W–10 | COVER | 1 | | | | | |
| 11 | J0B–K8388–00 | BOLT, ROOF 1 | 4 | | | | | |
| 12 | J0S–F2210–01 | SHOCK ABSORBER ASSY, REAR | 1 | | | | | |
| 13 | J0B–F53A1–01 | KNUCKLE, REAR | 1 | | | | | |
| 14 | 93306–006X0 | BEARING | 1 | | | | | |
| 15 | 93306–006Y4 | BEARING | 1 | | | | | |
| 16 | 93106–38046 | OIL SEAL | 1 | | | | | |
| 17 | J0B–F3113–00 | COLLAR | 1 | | | | | |
| 18 | 90381–17803 | BUSH, SOLID | 2 | | | | | |
| 19 | J0B–F537W–00 | BRACKET 1 | 1 | | | | | |
| 20 | 95812–12055 | BOLT, FLANGE | 1 | | | | | |
| 21 | 90185–12811 | NUT, SELF-LOCKING | 1 | | | | | |
| 22 | 95812–08060 | BOLT, FLANGE | 1 | | | | | |
| 23 | 95702–08500 | NUT, FLANGE | 1 | | | | | |
| 24 | 93210–19001 | O-RING | 2 | | | | | |
| 25 | J0S–F2210–01 | SHOCK ABSORBER ASSY, REAR | 1 | | | | | |
| 26 | J0B–F53A1–01 | KNUCKLE, REAR | 1 | | | | | |
| 27 | 93306–006X0 | BEARING | 1 | | | | | |




## FIG. 1 REAR ARM & SUSPENSION

| REF. NO. | PART NO. | DESCRIPTION | J5A1 | | | | | REMARKS |
|---|---|---|---|---|---|---|---|---|
| 28 | 93306–006Y4 | BEARING | 1 | | | | | |
| 29 | 93106–38046 | OIL SEAL | 1 | | | | | |
| 30 | J0B–F3113–00 | COLLAR | 1 | | | | | |
| 31 | 90381–17803 | BUSH, SOLID | 2 | | | | | |
| 32 | J0B–F537W–00 | BRACKET 1 | 1 | | | | | |
| 33 | 95812–12055 | BOLT, FLANGE | 1 | | | | | |
| 34 | 90185–12811 | NUT, SELF-LOCKING | 1 | | | | | |
| 35 | 95812–08060 | BOLT, FLANGE | 1 | | | | | |
| 36 | 95702–08500 | NUT, FLANGE | 1 | | | | | |
| 37 | 93210–19001 | O-RING | 2 | | | | | |
| 38 | 95812–10055 | BOLT, FLANGE | 2 | | | | | |
| 39 | 95602–10200 | NUT, S/L FLANGE | 2 | | | | | |
| 40 | J0S–F2171–00 | ARM, REAR 1 | 2 | | | | | |
| 41 | 5KM–23448–00 | SPACER | 2 | | | | | |
| 42 | 5UG–23517–10 | COVER, THRUST 1 | 4 | | | | | |
| 43 | 90105–10185 | BOLT, FLANGE | 2 | | | | | |
| 44 | 90185–10012 | NUT, SELF-LOCKING | 2 | | | | | |
| 45 | 2HR–23526–00 | BUSH | 4 | | | | | |
| 46 | 90105–10267 | BOLT, FLANGE | 4 | | | | | |
| 47 | 95602–10200 | NUT, S/L FLANGE | 4 | | | | | |



J0E5110-W020

## FIG. 2 FRAME

| REF. NO. | PART NO. | DESCRIPTION | J5A1 | | | | | REMARKS |
|---|---|---|---|---|---|---|---|---|
| 1 | J0B–F2501–30 | FRAME COMP. | 1 | | | | | |
| 2 | J0B–F255G–00 | MEMBER, SEAT SUPPORT | 1 | | | | | |
| 3 | 95812–08040 | BOLT, FLANGE | 2 | | | | | |
| 4 | JC1–F252M–11 | BRACKET, 3 | 1 | | | | | |
| 5 | J0C–F7411–01 | FOOTREST 1 | 1 | | | | | |
| 6 | J0B–F1738–00 | BOLT | 9 | | | | | |
| 7 | JW9–F2535–00 | STAY, BATTERY 1 | 2 | | | | | |
| 8 | JW1–F1738–00 | BOLT | 4 | | | | | |
| 9 | JW9–F2417–00 | PLUG | 2 | | | | | |
| 10 | JW9–F2198–11 | MEMBER, CROSS | 2 | | | | | |
| 11 | JW1–F1738–00 | BOLT | 4 | | | | | |
| 12 | J0B–F258E–10 | SUPPORT, FRONT COWL | 1 | | | | | |
| 13 | 90105–08867 | BOLT, FLANGE | 2 | | | | | |
| 14 | J0B–F2127–00 | SHIM | 1 | | | | | |
| 15 | J1B–K816M–00 | SUPPORT, HOLDER | 2 | | | | | |
| 16 | 90105–06831 | BOLT, FLANGE | 2 | | | | | |
| 17 | 90105–088B6 | BOLT, FLANGE | 4 | | | | | |
| 18 | J0S–F2537–03 | BRACKET | 2 | | | | | |
| 19 | 90267–64844 | RIVET, BLIND | 4 | | | | | |
| 20 | JW2–K8298–10 | PLATE, CAUTION 2 (E,F) | 1 | | | | | ENGLISH/FRENCH |
| 21 | J0B–K821A–00 | PAD, BODY MOUNTING1 | 2 | | | | | |
| 22 | J0B–F125J–00 | PIPE, DRAIN | 2 | | | | | |
| 23 | 90464–76800 | CLAMP | 2 | | | | | |

## FIG. 3 FRONT SUSPENSION & WHEEL




| REF. NO. | PART NO. | DESCRIPTION | J5A1 | | | | | REMARKS |
|---|---|---|---|---|---|---|---|---|
| 1 | J0B–F3570–10 | FRONT LOWER ARM COMP. (LEFT) | 2 | | | | | |
| 2 | 90381–18801 | .BUSH, SOLID | 2 | | | | | |
| 3 | 2HR–23526–00 | .BUSH | 2 | | | | | |
| 4 | JU0–F3511–20 | KNUCKLE, STEERING 1 | 1 | | | | | |
| 5 | JW1–F3512–00 | ARM, KNUCKLE 1 | 2 | | | | | |
| 6 | 90105–10373 | BOLT, FLANGE | 4 | | | | | |
| 7 | 95602–10200 | NUT, S/L FLANGE | 12 | | | | | |
| 8 | 90105–10219 | BOLT, FLANGE | 2 | | | | | |
| 9 | 2NL–23448–00 | SPACER | 2 | | | | | |
| 10 | 90381–17800 | BUSH, SOLID | 4 | | | | | |
| 11 | 2NL–23517–00 | COVER, THRUST 1 | 4 | | | | | |
| 12 | JU0–F3521–20 | KNUCKLE, STEERING 2 | 1 | | | | | |
| 13 | 90105–10267 | BOLT, FLANGE | 4 | | | | | |
| 14 | J0S–F3350–01 | SHOCK ABSORBER ASSY | 1 | | | | | |
| 15 | 90387–12016 | COLLAR | 2 | | | | | |
| 16 | 401–22128–01 | COVER, THRUST 1 | 4 | | | | | |
| 17 | 95812–12080 | BOLT, FLANGE | 2 | | | | | |
| 18 | 90185–12810 | NUT, SELF-LOCKING | 2 | | | | | |
| 19 | J0S–F3390–01 | SHOCK ABSORBER ASSY 2 | 1 | | | | | |
| 20 | 90105–10267 | BOLT, FLANGE | 2 | | | | | |
| 21 | JC1–F5103–10 | HUB BEARING UNIT ASSY | 2 | | | | | |
| 22 | 90114–12805 | .BOLT, SERRATION | 4 | | | | | |
| 23 | 93306–254Y8 | .BEARING | 1 | | | | | |
| 24 | 93306–005X3 | .BEARING | 1 | | | | | |
| 25 | 90387–241M7 | .COLLAR | 1 | | | | | |
| 26 | 93102–30083 | .OIL SEAL | 1 | | | | | |
| 27 | 90208–14801 | WASHER, CONICAL SPRING | 2 | | | | | |




J0B4110-V130

## FIG. 3 FRONT SUSPENSION & WHEEL

| REF. NO. | PART NO. | DESCRIPTION | J5A1 | | | | | REMARKS |
|---|---|---|---|---|---|---|---|---|
| 28 | 95602–14100 | NUT, U | 2 | | | | | |
| 29 | JN6–F5118–01 | COVER, HUB DUST | 2 | | | | | |
| 30 | 90179–12262 | NUT | 8 | | | | | |
| 31 | JW1–F5100–01 | WHEEL ASSY (18X8.50-8-4PLY) | 2 | | | | | |




J0E5100-W040

## FIG. 4 STEERING

| REF. NO. | PART NO. | DESCRIPTION | J5A1 | | | | | REMARKS |
|---|---|---|---|---|---|---|---|---|
| 1 | J0G–F3811–00 | COLUMN, STEERING | 1 | | | | | |
| 2 | 95812–08020 | BOLT, FLANGE | 4 | | | | | |
| 3 | JU0–F3857–20 | HOLDER | 1 | | | | | |
| 4 | JU0–F3828–10 | ROD, STEERING | 1 | | | | | |
| 5 | JU0–F3857–20 | HOLDER | 1 | | | | | |
| 6 | J0B–F3838–00 | WHEEL, STEERING | 1 | | | | | |
| 7 | 90185–12008 | NUT, SELF-LOCKING | 1 | | | | | |
| 8 | 92902–12200 | WASHER | 1 | | | | | |
| 9 | 90185–12811 | NUT, SELF-LOCKING | 2 | | | | | |
| 10 | JW1–F3400–01 | STEERING ASSY | 1 | | | | | |
| 11 | JW1–F387A–00 | .GEAR,PINION | 1 | | | | | |
| 12 | JW1–F3183–00 | .CIRCLIP | 1 | | | | | |
| 13 | JW1–F3812–00 | .BEARING, STEERING | 1 | | | | | |
| 14 | JW1–F387E–00 | .GEAR, RACK | 1 | | | | | |
| 15 | 5UG–F387G–00 | .COVER, ADJUST | 1 | | | | | |
| 16 | 5UG–F387K–00 | .SPRING, PRESSURE | 1 | | | | | |
| 17 | 5UG–F387F–00 | .PAD, PRESSURE | 1 | | | | | |
| 18 | 5UG–F387J–00 | .RING, STOPPER | 1 | | | | | |
| 19 | 5UG–F3844–00 | .SEAL | 1 | | | | | |
| 20 | 5UG–F3527–01 | .SEAL, DUST 1 | 2 | | | | | |
| 21 | JW1–F3837–00 | .ROD, TIE 2 | 2 | | | | | |
| 22 | JW1–F467K–00 | .BUSH, CAP | 1 | | | | | |
| 23 | JW1–F3866–00 | .CIRCLIP | 1 | | | | | |
| 24 | JW1–F3894–00 | .WASHER, LOCK 1 | 2 | | | | | |
| 25 | 1P0–F3833–00 | NUT 1 | 2 | | | | | |
| 26 | JW8–23841–01 | JOINT, UNIVERSAL 1 | 2 | | | | | |
| 27 | 90105–10847 | BOLT, FLANGE | 4 | | | | | |




J0E5100-W040

## FIG. 4 STEERING

| REF. NO. | PART NO. | DESCRIPTION | J5A1 | | | | | REMARKS |
|---|---|---|---|---|---|---|---|---|
| 28 | JW1–F3822–01 | JOINT 1 | 1 | | | | | |
| 29 | 97012–08030 | BOLT | 2 | | | | | |
| 30 | 92902–08600 | WASHER, PLATE | 2 | | | | | |
| 31 | J0B–K8357–00 | HOLDER 1 | 1 | | | | | |
| 32 | J0B–K8358–00 | HOLDER 2 | 1 | | | | | |
| 33 | J0B–K7387–00 | SCREW | 2 | | | | | |
| 34 | 90201–04810 | WASHER, PLATE | 2 | | | | | |
| 35 | J0B–K7363–00 | SPRING | 2 | | | | | |
| 36 | J0B–K7115–00 | COLLAR | 2 | | | | | |
| 37 | J0B–K7762–10 | LABEL, WARNING 2 | 1 | | | | | ENGLISH/FRENCH |

## FIG. 5 PEDAL WIRE




FWD

J0B1110-S150

| REF. NO. | PART NO. | DESCRIPTION | J5A1 | | | | | REMARKS |
|---|---|---|---|---|---|---|---|---|
| 1 | J0B–F6341–01 | WIRE, BRAKE 1 | 1 | | | | | |
| 2 | J0B–F6351–01 | CABLE, BRAKE | 1 | | | | | |
| 3 | 91702–10026 | PIN, CLEVIS | 3 | | | | | |
| 4 | 90468–20196 | CLIP | 3 | | | | | |
| 5 | JW7–F312H–00 | CLAMP | 5 | | | | | |
| 6 | JW8–F5681–10 | EQUALIZER, BRAKE | 1 | | | | | |
| 7 | JN6–F5685–01 | ROD | 1 | | | | | |
| 8 | 90179–08822 | NUT | 1 | | | | | |
| 9 | 95307–08700 | NUT | 1 | | | | | |
| 10 | 90249–14129 | PIN | 1 | | | | | |
| 11 | 99001–09600 | CIRCLIP | 2 | | | | | |
| 12 | 91702–08018 | PIN, CLEVIS | 2 | | | | | |
| 13 | 91490–25015 | PIN. COTTER | 2 | | | | | |

## FIG. 6 PEDAL ASSEMBLY




| REF. NO. | PART NO. | DESCRIPTION | J5A1 | | | | | REMARKS |
|---|---|---|---|---|---|---|---|---|
| 1 | J0H–F7850–21 | PEDAL ASSY (L.H) | 1 | | | | | |
| 2 | J0G–F7200–03 | .PEDAL, BRAKE | 1 | | | | | |
| 3 | JW8–F7814–21 | ..BUSH, PEDAL | 2 | | | | | |
| 4 | J0G–F5671–00 | ..PEDAL, PARKING BRAKE | 1 | | | | | |
| 5 | J0G–F7854–00 | ..COVER, PEDAL | 1 | | | | | |
| 6 | 95607–06200 | ..NUT, SELF U-FLANGE | 2 | | | | | |
| 7 | 97012–06020 | ..BOLT | 1 | | | | | |
| 8 | JW8–F8363–00 | ..NUT | 1 | | | | | |
| 9 | J0G–F7416–00 | ..BOLT, FOOTREST | 1 | | | | | |
| 10 | JW8–F639N–00 | ..COLLAR | 1 | | | | | |
| 11 | J0G–F7218–00 | ..NUT | 1 | | | | | |
| 12 | J0G–F7313–00 | ..COLLAR | 1 | | | | | |
| 13 | JW9–F5666–01 | ..SECTOR, PARKING BRAKE | 1 | | | | | |
| 14 | JW8–F7121–00 | ..BUSH | 1 | | | | | |
| 15 | JW9–F7221–00 | ..SEAL, SHAFT | 2 | | | | | |
| 16 | JW8–F7322–00 | ..WASHER | 1 | | | | | |
| 17 | JW8–F3183–00 | ..CIRCLIP | 1 | | | | | |
| 18 | JW8–F7426–01 | ..SPRING, RETURN | 1 | | | | | |
| 19 | JW9–F7231–10 | ..ROD, BRAKE | 1 | | | | | |
| 20 | JW9–F7232–00 | ..END, ROD 2 | 1 | | | | | |
| 21 | JW8–F7318–00 | ..NUT | 2 | | | | | |
| 22 | JW8–F6314–00 | ..SPRING | 1 | | | | | |
| 23 | J0G–F7814–00 | ..BUSH, PEDAL | 1 | | | | | |
| 24 | JW9–F7228–00 | ..PIN, JOINT | 1 | | | | | |
| 25 | JW8–F8323–00 | ..WASHER, LEG SHIELD | 2 | | | | | |
| 26 | JW8–F5415–00 | ..CIRCLIP | 1 | | | | | |
| 27 | 90386–12800 | ..BUSH | 3 | | | | | |

## FIG. 6 PEDAL ASSEMBLY




| REF. NO. | PART NO. | DESCRIPTION | J5A1 | | | | | REMARKS |
|---|---|---|---|---|---|---|---|---|
| 28 | J0G–F7825–00 | ..SPRING, RETURN | 1 | | | | | |
| 29 | JW8–F7119–00 | ..WASHER | 2 | | | | | |
| 30 | JW9–F7245–10 | .PAD, BRAKE PEDAL | 1 | | | | | |
| 31 | JW8–F7316–01 | .SPRING, SIDE STAND | 1 | | | | | |
| 32 | JW8–F7217–00 | .BOLT | 1 | | | | | |
| 33 | J0H–F7445–11 | .PLATE 1 | 1 | | | | | |
| 34 | JW8–F7213–20 | .COLLAR | 1 | | | | | |
| 35 | J0H–F7853–11 | .SHAFT, PEDAL 1 | 1 | | | | | |
| 36 | J0G–F7871–01 | .PEDAL, ACCELERATOR | 1 | | | | | |
| 37 | J0H–F7872–00 | .ARM, ACCELERATOR PEDAL | 1 | | | | | |
| 38 | J0G–F7438–00 | .PIN, CLEVIS | 1 | | | | | |
| 39 | J0G–F744G–00 | .PIN | 1 | | | | | |
| 40 | JW8–F7434–00 | .BOLT | 1 | | | | | |
| 41 | JW8–F7317–00 | .BOLT | 1 | | | | | |
| 42 | JW8–F7118–00 | .NUT | 1 | | | | | |
| 43 | J0G–F815H–10 | .SPRING | 1 | | | | | |
| 44 | J0G–F5922–00 | .WASHER | 2 | | | | | |
| 45 | JW8–F4486–00 | .O-RING | 2 | | | | | |
| 46 | JW9–F5673–00 | .DAMPER, BRAKE | 1 | | | | | |
| 47 | JW9–F7246–20 | .NAIL, BRAKE | 1 | | | | | |
| 48 | JW8–F8331–00 | .BOLT, LEG SHIELD | 2 | | | | | |
| 49 | JW8–F4486–00 | .O-RING | 2 | | | | | |
| 50 | JW9–F7263–00 | .BRACKET 1 | 1 | | | | | |
| 51 | JW9–F4648–20 | .O-RING | 1 | | | | | |
| 52 | JW8–F41B8–00 | .O-RING | 1 | | | | | |
| 53 | JW9–H5885–00 | .THROTTLE SENSOR ASSY | 1 | | | | | |
| 54 | JW9–F5827–00 | .SHIM, CALIPER | 1 | | | | | T: 0.5 MM |




## FIG. 6 PEDAL ASSEMBLY

| REF. NO. | PART NO. | DESCRIPTION | J5A1 | | | | | REMARKS |
|---|---|---|---|---|---|---|---|---|
| 54 | JW9–F5827–10 | .SHIM, CALIPER | 1 | | | | | T: 0.9 MM |
| 55 | JW9–F632G–00 | .SCREW | 2 | | | | | |
| 56 | 90201–05824 | .WASHER, PLATE | 4 | | | | | |
| 57 | JW8–F7435–00 | .BOLT | 2 | | | | | |
| 58 | J0G–F3145–01 | .OIL SEAL | 2 | | | | | |
| 59 | 95812–08020 | BOLT, FLANGE | 6 | | | | | |



J0B1110-S170

## FIG. 7 BRAKE

| REF. NO. | PART NO. | DESCRIPTION | J5A1 | | | | | REMARKS |
|---|---|---|---|---|---|---|---|---|
| 1 | JW8–F7280–10 | BACKING PLATE ASSY 1 | 1 | | | | | |
| 2 | JN9–W2536–11 | .BRAKE SHOE SET | 1 | | | | | |
| 3 | J38–27204–00 | .LEVER ASSY 1 | 1 | | | | | |
| 4 | JW8–F7281–00 | .SPRING, SHOE CLAMP | 2 | | | | | |
| 5 | J10–27282–00 | .PIN, SHOE HOLD DOWN | 2 | | | | | |
| 6 | 90506–20281 | .SPRING, TENSION | 1 | | | | | |
| 7 | 90506–14001 | .SPRING, TENSION | 1 | | | | | |
| 8 | J55–27270–00 | .ADJUSTER ASSY | 1 | | | | | |
| 9 | JW8–F7286–00 | .COVER, DUST | 1 | | | | | |
| 10 | 90201–121H9 | .WASHER, PLATE | 1 | | | | | |
| 11 | 90201–121H8 | .WASHER, PLATE | 1 | | | | | |
| 12 | JW8–F7290–10 | BACKING PLATE ASSY 2 | 1 | | | | | |
| 13 | JN9–W2536–11 | .BRAKE SHOE SET | 1 | | | | | |
| 14 | J38–27205–00 | .LEVER ASSY 2 | 1 | | | | | |
| 15 | JW8–F7281–00 | .SPRING, SHOE CLAMP | 2 | | | | | |
| 16 | J10–27282–00 | .PIN, SHOE HOLD DOWN | 2 | | | | | |
| 17 | 90506–20281 | .SPRING, TENSION | 1 | | | | | |
| 18 | 90506–14001 | .SPRING, TENSION | 1 | | | | | |
| 19 | J55–27260–00 | .ADJUSTER ASSY | 1 | | | | | |
| 20 | JW8–F7286–00 | .COVER, DUST | 1 | | | | | |
| 21 | 90201–121H9 | .WASHER, PLATE | 1 | | | | | |
| 22 | 90201–121H8 | .WASHER, PLATE | 1 | | | | | |
| 23 | 90105–082A0 | BOLT, FLANGE | 8 | | | | | |

## FIG. 8 TRANSAXLE




J0E5110-W082

| REF. NO. | PART NO. | DESCRIPTION | J5A1 | | | | | REMARKS |
|---|---|---|---|---|---|---|---|---|
| 1 | J0S–G6301–02 | TRANSMISSION ASSY | 1 | | | | | |
| 2 | 93306–007Y0 | .BEARING | 2 | | | | | |
| 3 | J0S–G6290–00 | .CASE ASSY | 1 | | | | | |
| 4 | J0S–G6314–00 | .COVER, TRANSMISSION | 1 | | | | | |
| 5 | J0B–G6410–01 | .DIFFERENTIAL ASSY. | 1 | | | | | |
| 6 | JW9–G6421–00 | .GEAR, RING | 1 | | | | | |
| 7 | J0S–G6320–00 | .INPUT SHAFT ASSY | 1 | | | | | |
| 8 | J0S–G6350–00 | .COUNTER GEAR ASSY | 1 | | | | | |
| 9 | J0S–G7339–00 | .PLUG | 1 | | | | | |
| 10 | J0B–G3812–00 | .SEAL, DUST | 3 | | | | | |
| 11 | JC1–G2544–00 | .BOLT | 4 | | | | | |
| 12 | 90170–10840 | .NUT | 4 | | | | | |
| 13 | JW8–G5378–00 | .NIPPLE, HOSE | 1 | | | | | |
| 14 | J0S–G2534–00 | .PIN, DOWEL | 2 | | | | | |
| 15 | J0S–G5148–01 | .PLUG, DRAIN | 1 | | | | | |
| 16 | J0S–G1148–00 | .BOLT | 12 | | | | | |
| 17 | J0S–F1828–00 | ELBOW | 1 | | | | | |
| 18 | 90445–10056 | HOSE (L85) | 1 | | | | | |
| 19 | 90445–143G1 | HOSE (L400) | 1 | | | | | |
| 20 | 90467–10846 | CLIP | 1 | | | | | |
| 21 | 1NS–F1338–00 | CLAMP | 1 | | | | | |



J0B1110-S230

## FIG. 9 REAR AXLE & WHEEL

| REF. NO. | PART NO. | DESCRIPTION | J5A1 | | | | | REMARKS |
|---|---|---|---|---|---|---|---|---|
| 1 | J0B–F5310–10 | HUB ASSY | 2 | | | | | |
| 2 | 90114–12006 | .BOLT, SERRATION | 4 | | | | | |
| 3 | 90179–20016 | NUT | 2 | | | | | |
| 4 | 90179–12262 | NUT | 8 | | | | | |
| 5 | JW1–F5100–01 | WHEEL ASSY (18X8.50-8-4PLY) | 2 | | | | | |
| 6 | JW8–G6521–00 | DRUM | 2 | | | | | |
| 7 | JW8–F5118–00 | COVER, HUB DUST | 2 | | | | | |
| 8 | 90201–20035 | WASHER, PLATE | 2 | | | | | |
| 9 | J0B–F518F–00 | DRIVE SHAFT ASSY | 1 | | | | | |
| 10 | J0B–F518G–00 | DRIVE SHAFT ASSY | 1 | | | | | |
| 11 | 93450–22119 | CIRCLIP | 2 | | | | | |




## FIG. 10 BUMPER

| REF. NO. | PART NO. | DESCRIPTION | J5A1 | | | | | REMARKS |
|---|---|---|---|---|---|---|---|---|
| 1 | J0B–K7510–01 | FRONT BUMPER COMP. | 1 | | | | | |
| 2 | J0B–K8164–00 | STAY, FRONT BUMPER (L.H) | 1 | | | | | |
| 3 | 95812–08016 | BOLT, FLANGE | 2 | | | | | |
| 4 | 95812–08050 | BOLT, FLANGE | 2 | | | | | |
| 5 | 95302–08700 | NUT, HEXAGON | 2 | | | | | |
| 6 | 95822–06012 | BOLT, FLANGE | 4 | | | | | |
| 7 | J0B–K7540–00 | REAR BUMPER COMP. | 1 | | | | | |
| 8 | 95602–10200 | NUT, S/L FLANGE | 2 | | | | | |




## FIG. 11 BODY

| REF. NO. | PART NO. | DESCRIPTION | J5A1 | | | | | REMARKS |
|---|---|---|---|---|---|---|---|---|
| 1 | J0B–K8115–A0 | COWL, FRONT | 1 | | | | | UR FOR BW1 |
| | J0B–K8115–10 | COWL, FRONT | 1 | | | | | UR FOR VDGS1 |
| | J0B–K8115–00 | COWL, FRONT | 1 | | | | | UR FOR DNBME |
| | J0B–K8115–30 | COWL, FRONT | 1 | | | | | UR FOR LNMP |
| | J0B–K8115–B0 | COWL, FRONT | 1 | | | | | UR FOR NYS5 |
| | J0B–K8115–50 | COWL, FRONT | 1 | | | | | UR FOR HTR |
| | J0B–K8115–60 | COWL, FRONT | 1 | | | | | UR FOR DNMC |
| | J0B–K8115–R0 | COWL, FRONT | 1 | | | | | UR FOR MDBM2 |
| | J0B–K8115–S0 | COWL, FRONT | 1 | | | | | UR FOR NYM6 |
| 2 | J0B–F4161–00 | EMBLEM 1 | 1 | | | | | |
| 3 | JU0–K7573–01 | NUT, SPECIAL | 2 | | | | | |
| 4 | 90105–06831 | BOLT, FLANGE | 1 | | | | | |
| 5 | 90269–06804 | RIVET | 2 | | | | | |
| 6 | J0B–K8114–10 | PANEL, FRONT | 1 | | | | | |
| 7 | 90269–08001 | RIVET | 3 | | | | | |
| 8 | J0B–K7768–30 | LABEL, WARNING 8 | 1 | | | | | UR ENGLISH |
| | J0B–K7768–40 | LABEL, WARNING 8 | 1 | | | | | UR ENGLISH/FRENCH |
| 9 | J0B–K8282–00 | PLATE, SWITCH PANEL | 1 | | | | | |
| 10 | J0C–K7741–00 | INDICATOR 1 | 1 | | | | | |
| 11 | J0B–K835E–00 | HOLDER, BEVERAGE | 1 | | | | | |
| 12 | 90111–05805 | BOLT,HEX. SOCKET BUTTON | 1 | | | | | |
| 13 | 90183–05008 | NUT, SPRING | 1 | | | | | |
| 14 | J0B–H2370–00 | PLUG CAP ASSY | 1 | | | | | |
| 15 | J0B–K8233–10 | MAT, MAIN FLOOR 3 | 1 | | | | | |
| 16 | 90269–09003 | RIVET | 12 | | | | | |
| 17 | J0B–K8273–10 | COVER, HOLE | 1 | | | | | |
| 18 | J0B–K8243–00 | MAT, REAR BODY SIDE (LH) | 1 | | | | | |




## FIG. 11 BODY

| REF. NO. | PART NO. | DESCRIPTION | J5A1 | | | | | REMARKS |
|---|---|---|---|---|---|---|---|---|
| 19 | 90269–07805 | RIVET | 2 | | | | | |
| 20 | J0B–K8244–00 | MAT, REAR BODY SIDE (RH) | 1 | | | | | |
| 21 | 90269–07805 | RIVET | 2 | | | | | |
| 22 | J1B–K832F–00 | GROMMET, ROOF SUPPORT 1 | 1 | | | | | WITH SUN ROOF |
| | J0B–K832F–00 | GROMMET, ROOF SUPPORT 1 | 1 | | | | | WITHOUT SUN ROOF |
| 23 | J1B–K832G–00 | GROMMET, ROOF SUPPORT 2 | 1 | | | | | WITH SUN ROOF |
| | J0B–K832G–00 | GROMMET, ROOF SUPPORT 2 | 1 | | | | | WITHOUT SUN ROOF |




J5A1110-X120

## FIG. 12 BODY 2

| REF. NO. | PART NO. | DESCRIPTION | J5A1 | | | | | REMARKS |
|---|---|---|---|---|---|---|---|---|
| 1 | J0B–K8111–A0 | PANEL, BODY SHELL | 1 | | | | | UR FOR BW1 |
| | J0B–K8111–10 | PANEL, BODY SHELL | 1 | | | | | UR FOR VDGS1 |
| | J0B–K8111–00 | PANEL, BODY SHELL | 1 | | | | | UR FOR DNBME |
| | J0B–K8111–30 | PANEL, BODY SHELL | 1 | | | | | UR FOR LNMP |
| | J0B–K8111–B0 | PANEL, BODY SHELL | 1 | | | | | UR FOR NYS5 |
| | J0B–K8111–50 | PANEL, BODY SHELL | 1 | | | | | UR FOR HTR |
| | J0B–K8111–60 | PANEL, BODY SHELL | 1 | | | | | UR FOR DNMC |
| | J0B–K8111–R0 | PANEL, BODY SHELL | 1 | | | | | UR FOR MDBM2 |
| | J0B–K8111–S0 | PANEL, BODY SHELL | 1 | | | | | UR FOR NYM6 |
| 2 | J0B–F3447–00 | CLIP | 1 | | | | | |
| 3 | 90269–07805 | RIVET | 3 | | | | | |
| 4 | J0B–K8112–A0 | PANEL, BODY SHELL | 1 | | | | | UR FOR BW1 |
| | J0B–K8112–10 | PANEL, BODY SHELL | 1 | | | | | UR FOR VDGS1 |
| | J0B–K8112–00 | PANEL, BODY SHELL | 1 | | | | | UR FOR DNBME |
| | J0B–K8112–30 | PANEL, BODY SHELL | 1 | | | | | UR FOR LNMP |
| | J0B–K8112–B0 | PANEL, BODY SHELL | 1 | | | | | UR FOR NYS5 |
| | J0B–K8112–50 | PANEL, BODY SHELL | 1 | | | | | UR FOR HTR |
| | J0B–K8112–60 | PANEL, BODY SHELL | 1 | | | | | UR FOR DNMC |
| | J0B–K8112–R0 | PANEL, BODY SHELL | 1 | | | | | UR FOR MDBM2 |
| | J0B–K8112–S0 | PANEL, BODY SHELL | 1 | | | | | UR FOR NYM6 |
| 5 | J0B–F3447–00 | CLIP | 1 | | | | | |
| 6 | 90269–07805 | RIVET | 3 | | | | | |
| 7 | J0B–K819H–00 | SHELL, REAR BODY | 1 | | | | | |
| 8 | JW7–K7329–00 | RIVET | 2 | | | | | |
| 9 | J0B–F1738–00 | BOLT | 4 | | | | | |
| 10 | J0C–K8141–A0 | PANEL, INTERMEDIATE BODY | 1 | | | | | UR FOR BW1 |
| | J0C–K8141–10 | PANEL, INTERMEDIATE BODY | 1 | | | | | UR FOR VDGS1 |




## FIG. 12 BODY 2

| REF. NO. | PART NO. | DESCRIPTION | J5A1 | | | | | REMARKS |
|---|---|---|---|---|---|---|---|---|
| 10 | J0B–K8141–00 | PANEL, INTERMEDIATE BODY | 1 | | | | | UR FOR DNBME |
| | J0C–K8141–30 | PANEL, INTERMEDIATE BODY | 1 | | | | | UR FOR LNMP |
| | J0C–K8141–B0 | PANEL, INTERMEDIATE BODY | 1 | | | | | UR FOR NYS5 |
| | J0C–K8141–50 | PANEL, INTERMEDIATE BODY | 1 | | | | | UR FOR HTR |
| | J0C–K8141–60 | PANEL, INTERMEDIATE BODY | 1 | | | | | UR FOR DNMC |
| | J0C–K8141–R0 | PANEL, INTERMEDIATE BODY | 1 | | | | | UR FOR MDBM2 |
| | J0C–K8141–S0 | PANEL, INTERMEDIATE BODY | 1 | | | | | UR FOR NYM6 |
| 11 | 90269–07805 | RIVET | 8 | | | | | |
| 12 | J0B–K8237–02 | COVER, REAR FLOOR | 1 | | | | | FOR 2 BAGS |
| 13 | J0B–F3447–00 | CLIP | 4 | | | | | |
| 14 | J0B–F1738–00 | BOLT | 2 | | | | | |
| 15 | J0B–F2873–01 | SEAL 1 | 1 | | | | | |
| 16 | J0B–F2874–01 | SEAL 2 | 1 | | | | | |
| 17 | J0C–K827A–00 | GUIDE 1 | 1 | | | | | |
| 18 | J5A–F1781–00 | EMBLEM 1 | 2 | | | | | |
| 19 | J5A–K8297–00 | PLATE, CAUTION 1 | 1 | | | | | ENGLISH/FRENCH |
| 20 | J0B–K817H–10 | TRIM, SIDE PANEL 1 | 1 | | | | | WITH SUN ROOF |
| | J0B–K817H–00 | TRIM, SIDE PANEL 1 | 1 | | | | | WITHOUT SUN ROOF |
| 21 | J0B–K817J–10 | TRIM, SIDE PANEL 2 | 1 | | | | | WITH SUN ROOF |
| | J0B–K817J–00 | TRIM, SIDE PANEL 2 | 1 | | | | | WITHOUT SUN ROOF |

## FIG. 13 BODY FITTING




| REF. NO. | PART NO. | DESCRIPTION | J5A1 | | | | | REMARKS |
|---|---|---|---|---|---|---|---|---|
| 1 | J0B–K8271–01 | SERVICE LID, PEDAL | 1 | | | | | |
| 2 | J0B–K818A–00 | PROTECTOR, SIDE PLATE | 1 | | | | | |
| 3 | 90269–09003 | RIVET | 3 | | | | | |
| 4 | 90269–06804 | RIVET | 1 | | | | | |
| 5 | J0B–K818B–00 | PROTECTOR, SIDE PLATE 2 | 1 | | | | | |
| 6 | 90269–09003 | RIVET | 3 | | | | | |
| 7 | 90269–06804 | RIVET | 1 | | | | | |
| 8 | J0B–K8191–00 | PANEL, REAR FENDER 1 | 1 | | | | | |
| 9 | 90269–06804 | RIVET | 5 | | | | | |
| 10 | J0B–K8192–00 | PANEL, REAR FENDER 2 | 1 | | | | | |
| 11 | 90269–06804 | RIVET | 5 | | | | | |

## FIG. 14 CARRIER




J0B1110-S280

| REF. NO. | PART NO. | DESCRIPTION | J5A1 | | | | | REMARKS |
|---|---|---|---|---|---|---|---|---|
| 1 | J0B–K8423–00 | SUPPORT, SEAT BACK | 1 | | | | | |
| 2 | 90109–08178 | BOLT | 4 | | | | | |
| 3 | JW1–K8340–00 | LUGGAGE RACK ASSY., REAR | 1 | | | | | |
| 4 | 92017–06040 | BOLT, BUTTON HEAD | 4 | | | | | |
| 5 | J0B–K7389–00 | WASHER | 4 | | | | | |
| 6 | 90176–06008 | NUT, CROWN | 4 | | | | | |
| 7 | JF2–K8356–00 | PAD, BAG SUPPORT | 1 | | | | | |
| 8 | JN6–K8355–20 | BAND | 1 | | | | | |
| 9 | JW1–K834G–00 | HOLDER, RAKE SAND | 1 | | | | | |
| 10 | 9708R–06020 | BOLT | 1 | | | | | |
| 11 | 90185–06836 | NUT, SELF-LOCKING | 1 | | | | | |
| 12 | JN6–K8380–00 | LOCK ASSY | 2 | | | | | |
| 13 | 90159–06845 | SCREW, WITH WASHER | 4 | | | | | |
| 14 | 9299R–06200 | WASHER | 4 | | | | | |

## FIG. 15 SEAT




J0B1110-S290

| REF. NO. | PART NO. | DESCRIPTION | J5A1 | | | | | REMARKS |
|---|---|---|---|---|---|---|---|---|
| 1 | JW9–H1674–00 | BOLT | 4 | | | | | |
| 2 | JW1–K8427–00 | HINGE, SEAT 2 | 2 | | | | | |
| 3 | J0A–K8401–10 | SEAT SUB-ASSY,CUSHION | 1 | | | | | |
| 4 | J0B–K8361–00 | ARM REST 1 | 1 | | | | | |
| 5 | J0B–F1738–00 | BOLT | 4 | | | | | |
| 6 | J0B–K8362–00 | ARM REST 2 | 1 | | | | | |
| 7 | J0B–F1738–00 | BOLT | 4 | | | | | |
| 8 | J0B–K8426–01 | HINGE, SEAT 1 | 2 | | | | | |
| 9 | 90110–06125 | BOLT, HEXAGON SOCKET HEAD | 4 | | | | | |
| 10 | JW1–K8402–10 | SEAT SUB ASSY, BACK | 1 | | | | | |
| 11 | 90119–06808 | BOLT, WITH WASHER | 4 | | | | | |

## FIG. 16 ELECTRIC MOTOR




J0J5100-W160

| REF. NO. | PART NO. | DESCRIPTION | J5A1 | | | | | REMARKS |
|---|---|---|---|---|---|---|---|---|
| 1 | J0J–H1890–00 | MOTOR ASSY | 1 | | | | | |
| 2 | JW3–H183J–00 | .BRACKET, FRONT | 1 | | | | | |
| 3 | JW3–H3756–00 | .SENSOR, UNIT | 1 | | | | | |
| 4 | J0J–H1155–00 | .ARMATURE | 1 | | | | | |
| 5 | J0J–H2379–00 | .SCREW, UNIT | 1 | | | | | |
| 6 | J0J–H1117–00 | .STATOR | 1 | | | | | |
| 7 | J0J–H165G–00 | .PLTE, TERMINAL | 1 | | | | | |
| 8 | JW3–H182J–00 | .BRACKET COMPLETE | 1 | | | | | |
| 9 | JW3–H1869–00 | .COVER, DUST | 1 | | | | | |
| 10 | J0J–H183X–00 | .CAP, TERMINAL | 1 | | | | | |
| 11 | J0J–H5588–00 | .SLEEVE | 1 | | | | | |
| 12 | 90101–069U0 | BOLT | 3 | | | | | |
| 13 | 90215–06811 | WASHER, LOCK | 3 | | | | | |
| 14 | 90201–068E2 | WASHER, PLATE | 2 | | | | | |
| 15 | JU2–H218E–01 | RELIEF, STRAIN 1 | 1 | | | | | |

## FIG. 17 CONTROLLER 1




J0J5100-W170

| REF. NO. | PART NO. | DESCRIPTION | J5A1 | | | | | REMARKS |
|---|---|---|---|---|---|---|---|---|
| 1 | J5A–H6510–01 | MOTOR CONTROL UNIT ASSY | 1 | | | | | |
| 2 | JW2–H2727–00 | SWITCH | 1 | | | | | |
| 3 | 97027–08016 | BOLT, HEXAGON | 5 | | | | | |
| 4 | 92907–08600 | WASHER, PLATE | 5 | | | | | |
| 5 | 90105–06833 | BOLT, FLANGE | 4 | | | | | |




## FIG. 18 ELECTRICAL 1

| REF. NO. | PART NO. | DESCRIPTION | J5A1 | | | | | REMARKS |
|---|---|---|---|---|---|---|---|---|
| 1 | J5A–H212B–00 | BOX, BATTERY 1 | 1 | | | | | |
| 2 | J5A–H2121–00 | PAD, BATTERY | 1 | | | | | |
| 3 | 95822–08025 | BOLT, FLANGE | 4 | | | | | |
| 4 | 90201–08055 | WASHER, PLATE | 4 | | | | | |
| 5 | J5A–H2136–11 | PLATE, BATTERY FITTING | 2 | | | | | |
| 6 | J5A–H213E–11 | PLATE, BETTERY FITTING | 1 | | | | | |
| 7 | J5A–F2873–10 | SEAL 1 | 2 | | | | | |
| 8 | J5A–F2874–10 | SEAL 2 | 2 | | | | | |
| 9 | J5A–H2113–00 | SCREW | 4 | | | | | |
| 10 | J5A–F723F–01 | WASHER, SPECIAL | 4 | | | | | |
| 11 | 95602–08200 | NUT, U FLANGE | 4 | | | | | |
| 12 | J5A–H213F–11 | PLATE, BATTERY FITTING 3 | 1 | | | | | |
| 13 | JW9–K811K–00 | NUT, TRIM FITTING | 4 | | | | | |
| 14 | J5A–H2115–01 | WIRE, PLUS LEAD | 1 | | | | | |
| 15 | J5A–H2116–01 | WIRE, MINUS LEAD | 1 | | | | | |
| 16 | JU2–H2917–00 | SWITCH | 1 | | | | | |
| 17 | 90464–25826 | CLAMP | 3 | | | | | |
| 18 | J5A–H2590–02 | WIRE HARNESS ASSY | 1 | | | | | |
| 19 | J0J–H554E–10 | .FUSE (1A) | 1 | | | | | |
| 20 | J0J–H554E–30 | .FUSE (3A) | 1 | | | | | |
| 21 | J0J–H554E–50 | .FUSE (5A) | 1 | | | | | |
| 22 | JU6–H1950–00 | RELAY ASSY | 1 | | | | | |
| 23 | 90179–05807 | .NUT | 2 | | | | | |
| 24 | 90179–08824 | .NUT | 2 | | | | | |
| 25 | 90105–06831 | BOLT, FLANGE | 2 | | | | | |
| 26 | JR1–H3383–02 | BUZZER | 1 | | | | | |
| 27 | JN6–H3386–01 | STAY, BUZZER | 1 | | | | | |




## FIG. 18 ELECTRICAL 1

| REF. NO. | PART NO. | DESCRIPTION | J5A1 | | | | | REMARKS |
|---|---|---|---|---|---|---|---|---|
| 28 | J5A–H7228–00 | COVER HARNESS | 1 | | | | | |
| 29 | J0S–H6181–00 | RECEPTACLE | 1 | | | | | |
| 30 | JW1–F3394–00 | BOLT, SPECIAL | 3 | | | | | |
| 31 | JF7–82817–22 | SWITCH | 1 | | | | | |
| 32 | 98502–05025 | SCREW, PAN HEAD | 2 | | | | | |
| 33 | 92902–05600 | WASHER, PLATE | 2 | | | | | |
| 34 | 90464–40825 | CLAMP | 2 | | | | | |
| 35 | J0J–H6527–00 | WIRE 7 | 1 | | | | | |
| 36 | 90464–20005 | CLAMP | 1 | | | | | |
| 37 | 90464–48800 | CLAMP | 9 | | | | | |
| 38 | 90464–76800 | CLAMP | 1 | | | | | |
| 39 | J0E–H21E0–04 | USB ASSY | 1 | | | | | |
| 40 | J0E–H21E1–03 | .PLUG, USB | 1 | | | | | |
| 41 | J0D–H21E2–02 | .CABLE, USB | 2 | | | | | |
| 42 | J0D–H2114–00 | .NUT | 1 | | | | | |
| 43 | 90119–06868 | BOLT, WITH WASHER | 2 | | | | | |
| 44 | * | BATTERY ASSY (51.2V/105AH) | 1 | | | | | LM |
| 45 | 90119–08852 | BOLT, WITH WASHER | 3 | | | | | |
| 46 | J5A–F134A–00 | BRKT.,RESISTOR | 1 | | | | | |
| 47 | J5A–H2718–00 | RESISTOR ASSY | 1 | | | | | |
| 48 | J5A–H5515–02 | LEAD WIRE ASSY | 1 | | | | | |
| 49 | J5A–83791–00 | SENSOR | 1 | | | | | |
| 50 | 90267–32809 | RIVET, BLIND | 2 | | | | | |
| 51 | 90201–08043 | WASHER, PLATE | 4 | | | | | |
| 52 | 90464–20005 | CLAMP | 1 | | | | | |
| 53 | 90201–03015 | WASHER, PLATE | 2 | | | | | |
| 54 | 90105–08867 | BOLT, FLANGE | 3 | | | | | |




## FIG. 18 ELECTRICAL 1

| REF. NO. | PART NO. | DESCRIPTION | J5A1 | | | | | REMARKS |
|---|---|---|---|---|---|---|---|---|
| 55 | 90461–14108 | CLAMP | 1 | | | | | |
| 56 | 90105–08867 | BOLT, FLANGE | 1 | | | | | |
| 57 | 1NS–F1338–00 | CLAMP | 5 | | | | | |
| 58 | J0S–H2544–00 | CLAMP | 1 | | | | | |
| 59 | JW1–H2510–20 | MAIN SWITCH ASSY | 1 | | | | | |
| 60 | 1XD–H2579–10 | .CAP, KEY | 1 | | | | | |
| 61 | JU2–H2511–20 | .KEY, MAIN SWITCH | 2 | | | | | |
| 62 | JU6–H2569–20 | .NUT, MAIN SWITCH | 1 | | | | | |




J5B1110-X190

## FIG. 19 BATTERY CHARGER

| REF. NO. | PART NO. | DESCRIPTION | J5A1 | | | | | REMARKS |
|---|---|---|---|---|---|---|---|---|
| 1 | J5A–H2107–01 | CHARGER, BATTERY | 1 | | | | | |
| 2 | J5A–H7209–00 | .CHARGE CORD ASSY | 1 | | | | | |
| 3 | JU2–H1962–20 | CORD COMP. (100V) | 1 | | | | | |
| 4 | J5A–H2107–A1 | CHARGER, BATTERY | 1 | | | | | AP |
| 5 | J5A–H7209–A0 | .CHARGE CORD ASSY | 1 | | | | | |




## FIG. 20 ALTERNATE FOR WINDSHIELD

| REF. NO. | PART NO. | DESCRIPTION | J5A1 | | | | | REMARKS |
|---|---|---|---|---|---|---|---|---|
| 1 | J0B–K7200–01 | WINDSHIELD ASSY | 1 | | | | | UR AP CLEAR |
| | J0B–K7200–11 | WINDSHIELD ASSY | 1 | | | | | UR AP SMOKE |
| 2 | J0B–K7237–00 | .GROMMET | 6 | | | | | |
| 3 | J0B–K7238–00 | .DAMPER | 2 | | | | | |
| 4 | J0B–K7240–01 | .WIND SHIELD HARDWARE KIT 1 | 1 | | | | | |
| 5 | J0B–K7217–00 | ..NUT, WIND SHIELD | 6 | | | | | |
| 6 | J0B–K7248–00 | ..SCREW 1 | 6 | | | | | |
| 7 | J0B–K7218–00 | ..WASHER 1 | 6 | | | | | |
| 8 | J0B–K838A–20 | ..RETAINER 1 | 1 | | | | | |
| 9 | J0B–K7200–24 | WINDSHIELD ASSY | 1 | | | | | UR AP CLEAR |
| | J0B–K7200–34 | WINDSHIELD ASSY | 1 | | | | | UR AP SMOKE |
| 10 | J0B–K7173–21 | .LEVER, LATCH 1 | 2 | | | | | |
| 11 | J0B–K7237–00 | .GROMMET | 2 | | | | | |
| 12 | J0B–K7257–20 | .GROMMET, W/S 3 | 2 | | | | | |
| 13 | J0G–K7155–C0 | .RIVET 1 | 2 | | | | | |
| 14 | J0G–K7156–C0 | .RIVET 2 | 2 | | | | | |
| 15 | J0B–K7155–20 | .RIVET 1 | 2 | | | | | |
| 16 | J0B–K7145–20 | .HINGE 1 | 1 | | | | | |
| 17 | J0B–K7146–20 | .HINGE 2 | 1 | | | | | |
| 18 | J0B–K7529–20 | .SPACER, BUMPER | 2 | | | | | |
| 19 | J0B–K7240–20 | .WIND SHIELD HARDWARE KIT 1 | 1 | | | | | |
| 20 | J0B–K7248–00 | ..SCREW 1 | 4 | | | | | |
| 21 | J0B–K7217–00 | ..NUT, WIND SHIELD | 4 | | | | | |
| 22 | J0B–K7218–00 | ..WASHER 1 | 4 | | | | | |
| 23 | J0B–K7147–20 | .HINGE 3 | 1 | | | | | |
| 24 | J0B–K7148–20 | .HINGE 4 | 1 | | | | | |
| 25 | J0B–F3147–20 | .O-RING | 2 | | | | | |

## FIG. 20 ALTERNATE FOR WINDSHIELD




| REF. NO. | PART NO. | DESCRIPTION | J5A1 | | | | | REMARKS |
|---|---|---|---|---|---|---|---|---|
| 26 | J0B–K7247–00 | .GROMMET, W/S 2 | 2 | | | | | |
| 27 | J0B–K838A–20 | .RETAINER 1 | 1 | | | | | |



J0A2100-T370

## FIG. 21 ALTERNATE FOR SUN ROOF

| REF. NO. | PART NO. | DESCRIPTION | J5A1 | | | | | REMARKS |
|---|---|---|---|---|---|---|---|---|
| 1 | JW1–F414G–10 | SEAL | 2 | | | | | |
| 2 | J0B–K84A0–00 | SUN TOP KIT | 1 | | | | | UR AP TAN |
| | J0B–K84A0–10 | SUN TOP KIT | 1 | | | | | UR AP BLACK |
| 3 | J0B–K84A2–00 | .HARDWARE KIT, SUN TOP | 1 | | | | | |
| 4 | J0B–K8312–00 | ..SUPPORT, SUN ROOF 1 | 2 | | | | | |
| 5 | JW1–K8388–00 | ..BOLT, ROOF 1 | 4 | | | | | |
| 6 | JW1–K8313–01 | ..SUPPORT, SUN ROOF 2 | 2 | | | | | |
| 7 | J0B–K8388–00 | ..BOLT, ROOF 1 | 4 | | | | | |
| 8 | JU0–K8388–00 | ..BOLT, ROOF 1 | 8 | | | | | |
| 9 | JW1–F1549–01 | ..WASHER, FENDER MOLD | 16 | | | | | |
| 10 | JU0–K8398–00 | ..NUT, ROOF 1 | 8 | | | | | |
| 11 | JW1–K7387–00 | ..SCREW | 4 | | | | | |
| 12 | JW1–K8314–10 | .COVER, SUN ROOF | 1 | | | | | UR TAN |
| | JW1–K8314–21 | .COVER, SUN ROOF | 1 | | | | | UR BLACK |
| 13 | JW1–K8214–00 | .GRIP, HAND | 2 | | | | | |
| 14 | JU0–K8388–00 | .BOLT, ROOF 1 | 4 | | | | | |
| 15 | JW1–F1549–01 | .WASHER, FENDER MOLD | 8 | | | | | |
| 16 | JU0–K8398–00 | .NUT, ROOF 1 | 4 | | | | | |
| 17 | J0B–F417A–00 | .DRAIN TUBE ASSY | 1 | | | | | |




## FIG. 22 ALTERNATE FOR SEAT

| REF. NO. | PART NO. | DESCRIPTION | J5A1 | | | | | REMARKS |
|---|---|---|---|---|---|---|---|---|
| 1 | 90109–08178 | BOLT | 4 | | | | | |
| 2 | J0B–K8460–00 | SEAT FRAME COMP. | 1 | | | | | |
| 3 | J0B–K8477–00 | FLOOR ASSEMBLY | 1 | | | | | |
| 4 | J0B–K8473–00 | HANDRAIL ASSEMBLY (LH) | 1 | | | | | |
| 5 | J0B–K8474–00 | HANDRAIL ASSEMBLY (RH) | 1 | | | | | |
| 6 | J0B–K8432–00 | BRACKET, SEAT SUPPORT 2 | 1 | | | | | |
| 7 | J0B–K8402–00 | SEAT SUB ASSY, BACK | 1 | | | | | UR TAN |
| | J0B–K8402–10 | SEAT SUB ASSY, BACK | 1 | | | | | UR BLACK |
| 8 | J0B–K8480–00 | SEAT BOTTOM COMPLETE 1 | 1 | | | | | UR TAN |
| | J0B–K8480–10 | SEAT BOTTOM COMPLETE 1 | 1 | | | | | UR BLACK |
| 9 | J0B–F47E2–00 | HARDWARE KIT, TANDEM SEAT | 1 | | | | | |
| 10 | J0B–K8483–00 | LABEL WARNING | 1 | | | | | ENGLISH |
| 11 | J0B–K8466–00 | MAT, RUBBER | 1 | | | | | |
| 12 | J0B–F1696–00 | LABEL, CAUTION | 1 | | | | | ENGLISH |

| PART NO. | REF. NO. |
|---|---|
| 401–22128–01 | 3 – 16 |
| 2NL–23448–00 | 3 – 9 |
| 5KM–23448–00 | 1 – 41 |
| 2NL–23517–00 | 3 – 11 |
| 5UG–23517–10 | 1 – 42 |
| 2HR–23526–00 | 1 – 45 |
| | 3 – 3 |
| JW8–23841–01 | 4 – 26 |
| J38–27204–00 | 7 – 3 |
| J38–27205–00 | 7 – 14 |
| J55–27260–00 | 7 – 19 |
| J55–27270–00 | 7 – 8 |
| J10–27282–00 | 7 – 5 |
| | 7 – 16 |
| JF7–82817–22 | 18 – 31 |
| J5A–83791–00 | 18 – 49 |
| J0B–F125J–00 | 2 – 22 |
| 1NS–F1338–00 | 8 – 21 |
| | 18 – 57 |
| J5A–F134A–00 | 18 – 46 |
| J0S–F139W–10 | 1 – 10 |
| J0S–F141K–10 | 1 – 4 |
| J0S–F141L–10 | 1 – 5 |
| J0S–F1485–00 | 1 – 6 |
| J0B–F1531–00 | 1 – 8 |
| JW1–F1549–01 | 21 – 9 |
| | 21 – 15 |
| J0B–F1696–00 | 22 – 12 |
| J0B–F1738–00 | 2 – 6 |
| | 12 – 9 |
| | 12 – 14 |
| | 15 – 5 |
| | 15 – 7 |
| JW1–F1738–00 | 2 – 8 |
| | 2 – 11 |
| J5A–F1781–00 | 12 – 18 |
| J0S–F1828–00 | 8 – 17 |
| J0S–F2110–11 | 1 – 3 |
| J0B–F2127–00 | 2 – 14 |
| J0S–F2171–00 | 1 – 40 |
| JW9–F2198–11 | 2 – 10 |
| J0S–F2210–01 | 1 – 12 |
| | 1 – 25 |
| JW9–F2417–00 | 2 – 9 |
| J0B–F2501–30 | 2 – 1 |
| JC1–F252M–11 | 2 – 4 |
| JW9–F2535–00 | 2 – 7 |
| J0S–F2537–03 | 2 – 18 |

| PART NO. | REF. NO. |
|---|---|
| J0B–F255G–00 | 2 – 2 |
| J0B–F258E–10 | 2 – 12 |
| J0B–F2873–01 | 12 – 15 |
| J5A–F2873–10 | 18 – 7 |
| J0B–F2874–01 | 12 – 16 |
| J5A–F2874–10 | 18 – 8 |
| J0B–F3113–00 | 1 – 17 |
| | 1 – 30 |
| JW7–F312H–00 | 5 – 5 |
| J0G–F3145–01 | 6 – 58 |
| J0B–F3147–20 | 20 – 25 |
| JW1–F3183–00 | 4 – 12 |
| JW8–F3183–00 | 6 – 17 |
| J0S–F3350–01 | 3 – 14 |
| J0S–F3390–01 | 3 – 19 |
| JW1–F3394–00 | 18 – 30 |
| JW1–F3400–01 | 4 – 10 |
| J0B–F3447–00 | 12 – 2 |
| | 12 – 5 |
| | 12 – 13 |
| JU0–F3511–20 | 3 – 4 |
| JW1–F3512–00 | 3 – 5 |
| JU0–F3521–20 | 3 – 12 |
| 5UG–F3527–01 | 4 – 20 |
| J0B–F3570–10 | 3 – 1 |
| J0G–F3811–00 | 4 – 1 |
| JW1–F3812–00 | 4 – 13 |
| JW1–F3822–01 | 4 – 28 |
| JU0–F3828–10 | 4 – 4 |
| 1P0–F3833–00 | 4 – 25 |
| JW1–F3837–00 | 4 – 21 |
| J0B–F3838–00 | 4 – 6 |
| 5UG–F3844–00 | 4 – 19 |
| JU0–F3857–20 | 4 – 3 |
| | 4 – 5 |
| JW1–F3866–00 | 4 – 23 |
| JW1–F387A–00 | 4 – 11 |
| JW1–F387E–00 | 4 – 14 |
| 5UG–F387F–00 | 4 – 17 |
| 5UG–F387G–00 | 4 – 15 |
| 5UG–F387J–00 | 4 – 18 |
| 5UG–F387K–00 | 4 – 16 |
| JW1–F3894–00 | 4 – 24 |
| JW1–F414G–10 | 21 – 1 |
| J0B–F4161–00 | 11 – 2 |
| J0B–F417A–00 | 21 – 17 |
| JW8–F41B8–00 | 6 – 52 |
| JW8–F4486–00 | 6 – 45 |

| PART NO. | REF. NO. |
|---|---|
| JW8–F4486–00 | 6 – 49 |
| JW9–F4648–20 | 6 – 51 |
| JW1–F467K–00 | 4 – 22 |
| J0B–F47E2–00 | 22 – 9 |
| JW1–F5100–01 | 3 – 31 |
| | 9 – 5 |
| JC1–F5103–10 | 3 – 21 |
| JW8–F5118–00 | 9 – 7 |
| JN6–F5118–01 | 3 – 29 |
| J0B–F518F–00 | 9 – 9 |
| J0B–F518G–00 | 9 – 10 |
| J0B–F5310–10 | 9 – 1 |
| J0B–F537W–00 | 1 – 19 |
| | 1 – 32 |
| J0B–F53A1–01 | 1 – 13 |
| | 1 – 26 |
| JW8–F5415–00 | 6 – 26 |
| JW9–F5666–01 | 6 – 13 |
| J0G–F5671–00 | 6 – 4 |
| JW9–F5673–00 | 6 – 46 |
| JW8–F5681–10 | 5 – 6 |
| JN6–F5685–01 | 5 – 7 |
| JW9–F5827–00 | 6 – 54 |
| JW9–F5827–10 | 6 – 54 |
| J0G–F5922–00 | 6 – 44 |
| JW8–F6314–00 | 6 – 22 |
| JW9–F632G–00 | 6 – 55 |
| J0B–F6341–01 | 5 – 1 |
| J0B–F6351–01 | 5 – 2 |
| JW8–F639N–00 | 6 – 10 |
| JW8–F7118–00 | 6 – 42 |
| JW8–F7119–00 | 6 – 29 |
| JW8–F7121–00 | 6 – 14 |
| J0G–F7200–03 | 6 – 2 |
| JW8–F7213–20 | 6 – 34 |
| JW8–F7217–00 | 6 – 32 |
| J0G–F7218–00 | 6 – 11 |
| JW9–F7221–00 | 6 – 15 |
| JW9–F7228–00 | 6 – 24 |
| JW9–F7231–10 | 6 – 19 |
| JW9–F7232–00 | 6 – 20 |
| J5A–F723F–01 | 18 – 10 |
| JW9–F7245–10 | 6 – 30 |
| JW9–F7246–20 | 6 – 47 |
| JW9–F7263–00 | 6 – 50 |
| JW8–F7280–10 | 7 – 1 |
| JW8–F7281–00 | 7 – 4 |
| | 7 – 15 |

| PART NO. | REF. NO. |
|---|---|
| JW8–F7286–00 | 7 – 9 |
| | 7 – 20 |
| JW8–F7290–10 | 7 – 12 |
| J0G–F7313–00 | 6 – 12 |
| JW8–F7316–01 | 6 – 31 |
| JW8–F7317–00 | 6 – 41 |
| JW8–F7318–00 | 6 – 21 |
| JW8–F7322–00 | 6 – 16 |
| J0C–F7411–01 | 2 – 5 |
| J0G–F7416–00 | 6 – 9 |
| JW8–F7426–01 | 6 – 18 |
| JW8–F7434–00 | 6 – 40 |
| JW8–F7435–00 | 6 – 57 |
| J0G–F7438–00 | 6 – 38 |
| J0H–F7445–11 | 6 – 33 |
| J0G–F744G–00 | 6 – 39 |
| J0G–F7814–00 | 6 – 23 |
| JW8–F7814–21 | 6 – 3 |
| J0G–F7825–00 | 6 – 28 |
| J0H–F7850–21 | 6 – 1 |
| J0H–F7853–11 | 6 – 35 |
| J0G–F7854–00 | 6 – 5 |
| J0G–F7871–01 | 6 – 36 |
| J0H–F7872–00 | 6 – 37 |
| J0G–F815H–10 | 6 – 43 |
| JW8–F8323–00 | 6 – 25 |
| JW8–F8331–00 | 6 – 48 |
| JW8–F8363–00 | 6 – 8 |
| J0S–G1148–00 | 8 – 16 |
| J0S–G2534–00 | 8 – 14 |
| JC1–G2544–00 | 8 – 11 |
| J0B–G3812–00 | 8 – 10 |
| J0S–G5148–01 | 8 – 15 |
| JW8–G5378–00 | 8 – 13 |
| J0S–G6290–00 | 8 – 3 |
| J0S–G6301–02 | 8 – 1 |
| J0S–G6314–00 | 8 – 4 |
| J0S–G6320–00 | 8 – 7 |
| J0S–G6350–00 | 8 – 8 |
| J0B–G6410–01 | 8 – 5 |
| JW9–G6421–00 | 8 – 6 |
| JW8–G6521–00 | 9 – 6 |
| J0S–G7339–00 | 8 – 9 |
| J0J–H1117–00 | 16 – 6 |
| J0J–H1155–00 | 16 – 4 |
| J0J–H165G–00 | 16 – 7 |
| JW9–H1674–00 | 15 – 1 |
| JW3–H182J–00 | 16 – 8 |

| PART NO. | REF. NO. |
|---|---|
| JW3–H183J–00 | 16 – 2 |
| J0J–H183X–00 | 16 – 10 |
| JW3–H1869–00 | 16 – 9 |
| J0J–H1890–00 | 16 – 1 |
| JU6–H1950–00 | 18 – 22 |
| JU2–H1962–20 | 19 – 3 |
| J5A–H2107–01 | 19 – 1 |
| J5A–H2107–A1 | 19 – 4 |
| J5A–H2113–00 | 18 – 9 |
| J0D–H2114–00 | 18 – 42 |
| J5A–H2115–01 | 18 – 14 |
| J5A–H2116–01 | 18 – 15 |
| J5A–H2121–00 | 18 – 2 |
| J5A–H212B–00 | 18 – 1 |
| J5A–H2136–11 | 18 – 5 |
| J5A–H213E–11 | 18 – 6 |
| J5A–H213F–11 | 18 – 12 |
| JU2–H218E–01 | 16 – 15 |
| J0E–H21E0–04 | 18 – 39 |
| J0E–H21E1–03 | 18 – 40 |
| J0D–H21E2–02 | 18 – 41 |
| J0B–H2370–00 | 11 – 14 |
| J0J–H2379–00 | 16 – 5 |
| JW1–H2510–20 | 18 – 59 |
| JU2–H2511–20 | 18 – 61 |
| J0S–H2544–00 | 18 – 58 |
| JU6–H2569–20 | 18 – 62 |
| 1XD–H2579–10 | 18 – 60 |
| J5A–H2590–02 | 18 – 18 |
| J5A–H2718–00 | 18 – 47 |
| JW2–H2727–00 | 17 – 2 |
| JU2–H2917–00 | 18 – 16 |
| JR1–H3383–02 | 18 – 26 |
| JN6–H3386–01 | 18 – 27 |
| JW3–H3756–00 | 16 – 3 |
| J5A–H5515–02 | 18 – 48 |
| J0J–H554E–10 | 18 – 19 |
| J0J–H554E–30 | 18 – 20 |
| J0J–H554E–50 | 18 – 21 |
| J0J–H5588–00 | 16 – 11 |
| JW9–H5885–00 | 6 – 53 |
| J0S–H6181–00 | 18 – 29 |
| J5A–H6510–01 | 17 – 1 |
| J0J–H6527–00 | 18 – 35 |
| J5A–H7209–00 | 19 – 2 |
| J5A–H7209–A0 | 19 – 5 |
| J5A–H7228–00 | 18 – 28 |
| J0B–K7115–00 | 4 – 36 |

| PART NO. | REF. NO. |
|---|---|
| J0B–K7145–20 | 20 – 16 |
| J0B–K7146–20 | 20 – 17 |
| J0B–K7147–20 | 20 – 23 |
| J0B–K7148–20 | 20 – 24 |
| J0B–K7155–20 | 20 – 15 |
| J0G–K7155–C0 | 20 – 13 |
| J0G–K7156–C0 | 20 – 14 |
| J0B–K7173–21 | 20 – 10 |
| J0B–K7200–01 | 20 – 1 |
| J0B–K7200–11 | 20 – 1 |
| J0B–K7200–24 | 20 – 9 |
| J0B–K7200–34 | 20 – 9 |
| J0B–K7217–00 | 20 – 5 |
| | 20 – 21 |
| J0B–K7218–00 | 20 – 7 |
| | 20 – 22 |
| J0B–K7237–00 | 20 – 2 |
| | 20 – 11 |
| J0B–K7238–00 | 20 – 3 |
| J0B–K7240–01 | 20 – 4 |
| J0B–K7240–20 | 20 – 19 |
| J0B–K7247–00 | 20 – 26 |
| J0B–K7248–00 | 20 – 6 |
| | 20 – 20 |
| J0B–K7257–20 | 20 – 12 |
| JW7–K7329–00 | 12 – 8 |
| J0B–K7363–00 | 4 – 35 |
| J0B–K7387–00 | 4 – 33 |
| JW1–K7387–00 | 21 – 11 |
| J0B–K7389–00 | 14 – 5 |
| J0B–K7510–01 | 10 – 1 |
| J0B–K7529–20 | 20 – 18 |
| J0B–K7540–00 | 10 – 7 |
| JU0–K7573–01 | 11 – 3 |
| J0C–K7741–00 | 11 – 10 |
| J0B–K7762–10 | 4 – 37 |
| J0B–K7768–30 | 11 – 8 |
| J0B–K7768–40 | 11 – 8 |
| J0B–K8111–00 | 12 – 1 |
| J0B–K8111–10 | 12 – 1 |
| J0B–K8111–30 | 12 – 1 |
| J0B–K8111–50 | 12 – 1 |
| J0B–K8111–60 | 12 – 1 |
| J0B–K8111–A0 | 12 – 1 |
| J0B–K8111–B0 | 12 – 1 |
| J0B–K8111–R0 | 12 – 1 |
| J0B–K8111–S0 | 12 – 1 |
| J0B–K8112–00 | 12 – 4 |

| PART NO. | REF. NO. |
|---|---|
| J0B–K8112–10 | 12 – 4 |
| J0B–K8112–30 | 12 – 4 |
| J0B–K8112–50 | 12 – 4 |
| J0B–K8112–60 | 12 – 4 |
| J0B–K8112–A0 | 12 – 4 |
| J0B–K8112–B0 | 12 – 4 |
| J0B–K8112–R0 | 12 – 4 |
| J0B–K8112–S0 | 12 – 4 |
| J0B–K8114–10 | 11 – 6 |
| J0B–K8115–00 | 11 – 1 |
| J0B–K8115–10 | 11 – 1 |
| J0B–K8115–30 | 11 – 1 |
| J0B–K8115–50 | 11 – 1 |
| J0B–K8115–60 | 11 – 1 |
| J0B–K8115–A0 | 11 – 1 |
| J0B–K8115–B0 | 11 – 1 |
| J0B–K8115–R0 | 11 – 1 |
| J0B–K8115–S0 | 11 – 1 |
| JW9–K811K–00 | 18 – 13 |
| J0B–K8141–00 | 12 – 10 |
| J0C–K8141–10 | 12 – 10 |
| J0C–K8141–30 | 12 – 10 |
| J0C–K8141–50 | 12 – 10 |
| J0C–K8141–60 | 12 – 10 |
| J0C–K8141–A0 | 12 – 10 |
| J0C–K8141–B0 | 12 – 10 |
| J0C–K8141–R0 | 12 – 10 |
| J0C–K8141–S0 | 12 – 10 |
| J0B–K8164–00 | 10 – 2 |
| J1B–K816M–00 | 2 – 15 |
| J0B–K817H–00 | 12 – 20 |
| J0B–K817H–10 | 12 – 20 |
| J0B–K817J–00 | 12 – 21 |
| J0B–K817J–10 | 12 – 21 |
| J0B–K818A–00 | 13 – 2 |
| J0B–K818B–00 | 13 – 5 |
| J0B–K8191–00 | 13 – 8 |
| J0B–K8192–00 | 13 – 10 |
| J0B–K819H–00 | 12 – 7 |
| JW1–K8214–00 | 21 – 13 |
| J0B–K821A–00 | 2 – 21 |
| J0B–K8233–10 | 11 – 15 |
| J0B–K8237–02 | 12 – 12 |
| J0B–K8243–00 | 11 – 18 |
| J0B–K8244–00 | 11 – 20 |
| J0B–K8271–01 | 13 – 1 |
| J0B–K8273–10 | 11 – 17 |
| J0C–K827A–00 | 12 – 17 |

| PART NO. | REF. NO. |
|---|---|
| J0B–K8282–00 | 11 – 9 |
| J5A–K8297–00 | 12 – 19 |
| JW2–K8298–10 | 2 – 20 |
| J0B–K8312–00 | 21 – 4 |
| JW1–K8313–01 | 21 – 6 |
| JW1–K8314–10 | 21 – 12 |
| JW1–K8314–21 | 21 – 12 |
| J0B–K832F–00 | 11 – 22 |
| J1B–K832F–00 | 11 – 22 |
| J0B–K832G–00 | 11 – 23 |
| J1B–K832G–00 | 11 – 23 |
| JW1–K8340–00 | 14 – 3 |
| JW1–K834G–00 | 14 – 9 |
| JN6–K8355–20 | 14 – 8 |
| JF2–K8356–00 | 14 – 7 |
| J0B–K8357–00 | 4 – 31 |
| J0B–K8358–00 | 4 – 32 |
| J0B–K835E–00 | 11 – 11 |
| J0B–K8361–00 | 15 – 4 |
| J0B–K8362–00 | 15 – 6 |
| JN6–K8380–00 | 14 – 12 |
| J0B–K8388–00 | 1 – 11 |
| | 21 – 7 |
| JU0–K8388–00 | 21 – 8 |
| | 21 – 14 |
| JW1–K8388–00 | 21 – 5 |
| J0B–K838A–20 | 20 – 8 |
| | 20 – 27 |
| JU0–K8398–00 | 21 – 10 |
| | 21 – 16 |
| J0A–K8401–10 | 15 – 3 |
| J0B–K8402–00 | 22 – 7 |
| J0B–K8402–10 | 22 – 7 |
| JW1–K8402–10 | 15 – 10 |
| J0B–K8423–00 | 14 – 1 |
| J0B–K8426–01 | 15 – 8 |
| JW1–K8427–00 | 15 – 2 |
| J0B–K8432–00 | 22 – 6 |
| J0B–K8460–00 | 22 – 2 |
| J0B–K8466–00 | 22 – 11 |
| J0B–K8473–00 | 22 – 4 |
| J0B–K8474–00 | 22 – 5 |
| J0B–K8477–00 | 22 – 3 |
| J0B–K8480–00 | 22 – 8 |
| J0B–K8480–10 | 22 – 8 |
| J0B–K8483–00 | 22 – 10 |
| J0B–K84A0–00 | 21 – 2 |
| J0B–K84A0–10 | 21 – 2 |

| PART NO. | REF. NO. |
|---|---|
| J0B–K84A2–00 | 21 – 3 |
| JN9–W2536–11 | 7 – 2 |
| | 7 – 13 |
| 90101–069U0 | 16 – 12 |
| 90105–06831 | 2 – 16 |
| | 11 – 4 |
| | 18 – 25 |
| 90105–06833 | 17 – 5 |
| 90105–082A0 | 7 – 23 |
| 90105–08867 | 2 – 13 |
| | 18 – 54 |
| | 18 – 56 |
| 90105–088B6 | 2 – 17 |
| 90105–10185 | 1 – 43 |
| 90105–10219 | 3 – 8 |
| 90105–10267 | 1 – 46 |
| | 3 – 13 |
| | 3 – 20 |
| 90105–10373 | 3 – 6 |
| 90105–10847 | 4 – 27 |
| 90109–08178 | 14 – 2 |
| | 22 – 1 |
| 90110–06125 | 15 – 9 |
| 90111–05805 | 11 – 12 |
| 90114–12006 | 9 – 2 |
| 90114–12805 | 3 – 22 |
| 90119–06808 | 15 – 11 |
| 90119–06868 | 18 – 43 |
| 90119–08852 | 18 – 45 |
| 90159–06845 | 14 – 13 |
| 90170–10840 | 8 – 12 |
| 90176–06008 | 14 – 6 |
| 90179–05807 | 18 – 23 |
| 90179–08822 | 5 – 8 |
| 90179–08824 | 18 – 24 |
| 90179–12262 | 3 – 30 |
| | 9 – 4 |
| 90179–20016 | 9 – 3 |
| 90183–05008 | 11 – 13 |
| 90185–06836 | 14 – 11 |
| 90185–10012 | 1 – 44 |
| 90185–12008 | 4 – 7 |
| 90185–12810 | 3 – 18 |
| 90185–12811 | 1 – 21 |
| | 1 – 34 |
| | 4 – 9 |
| 90201–03015 | 18 – 53 |
| 90201–04810 | 4 – 34 |

| PART NO. | REF. NO. |
|---|---|
| 90201–05824 | 6 – 56 |
| 90201–068E2 | 16 – 14 |
| 90201–08043 | 18 – 51 |
| 90201–08055 | 18 – 4 |
| 90201–121H8 | 7 – 11 |
| | 7 – 22 |
| 90201–121H9 | 7 – 10 |
| | 7 – 21 |
| 90201–20035 | 9 – 8 |
| 90208–14801 | 3 – 27 |
| 90215–06811 | 16 – 13 |
| 90249–14129 | 5 – 10 |
| 90267–32809 | 18 – 50 |
| 90267–64844 | 2 – 19 |
| 90269–06804 | 11 – 5 |
| | 13 – 4 |
| | 13 – 7 |
| | 13 – 9 |
| | 13 – 11 |
| 90269–07805 | 11 – 19 |
| | 11 – 21 |
| | 12 – 3 |
| | 12 – 6 |
| | 12 – 11 |
| 90269–08001 | 11 – 7 |
| 90269–09003 | 11 – 16 |
| | 13 – 3 |
| | 13 – 6 |
| 90381–17800 | 3 – 10 |
| 90381–17803 | 1 – 18 |
| | 1 – 31 |
| 90381–18801 | 3 – 2 |
| 90386–12800 | 6 – 27 |
| 90387–12016 | 3 – 15 |
| 90387–241M7 | 3 – 25 |
| 90445–10056 | 8 – 18 |
| 90445–143G1 | 8 – 19 |
| 90461–14108 | 18 – 55 |
| 90464–20005 | 18 – 36 |
| | 18 – 52 |
| 90464–25826 | 18 – 17 |
| 90464–40825 | 18 – 34 |
| 90464–48800 | 18 – 37 |
| 90464–76800 | 2 – 23 |
| | 18 – 38 |
| 90467–10846 | 8 – 20 |
| 90468–20196 | 5 – 4 |
| 90506–14001 | 7 – 7 |

| PART NO. | REF. NO. |
|---|---|
| 90506–14001 | 7 – 18 |
| 90506–20281 | 7 – 6 |
| | 7 – 17 |
| 91490–25015 | 5 – 13 |
| 91702–08018 | 5 – 12 |
| 91702–10026 | 5 – 3 |
| 92017–06040 | 14 – 4 |
| 92902–05600 | 18 – 33 |
| 92902–08600 | 4 – 30 |
| 92902–12200 | 4 – 8 |
| 92907–08600 | 17 – 4 |
| 9299R–06200 | 14 – 14 |
| 93102–30083 | 3 – 26 |
| 93106–38046 | 1 – 16 |
| | 1 – 29 |
| 93210–19001 | 1 – 24 |
| | 1 – 37 |
| 93306–005X3 | 3 – 24 |
| 93306–006X0 | 1 – 14 |
| | 1 – 27 |
| 93306–006Y4 | 1 – 15 |
| | 1 – 28 |
| 93306–007Y0 | 8 – 2 |
| 93306–254Y8 | 3 – 23 |
| 93450–22119 | 9 – 11 |
| 95302–08700 | 10 – 5 |
| 95307–08700 | 5 – 9 |
| 95602–08200 | 18 – 11 |
| 95602–10200 | 1 – 2 |
| | 1 – 9 |
| | 1 – 39 |
| | 1 – 47 |
| | 3 – 7 |
| | 10 – 8 |
| 95602–14100 | 3 – 28 |
| 95607–06200 | 6 – 6 |
| 95702–08500 | 1 – 23 |
| | 1 – 36 |
| 95812–08016 | 10 – 3 |
| 95812–08020 | 4 – 2 |
| | 6 – 59 |
| 95812–08040 | 2 – 3 |
| 95812–08050 | 10 – 4 |
| 95812–08060 | 1 – 22 |
| | 1 – 35 |
| 95812–10020 | 1 – 1 |
| 95812–10055 | 1 – 38 |
| 95812–12055 | 1 – 20 |

| PART NO. | REF. NO. |
|---|---|
| 95812–12055 | 1 – 33 |
| 95812–12080 | 3 – 17 |
| 95822–06012 | 10 – 6 |
| 95822–08025 | 18 – 3 |
| 95822–10020 | 1 – 7 |
| 97012–06020 | 6 – 7 |
| 97012–08030 | 4 – 29 |
| 97027–08016 | 17 – 3 |
| 9708R–06020 | 14 – 10 |
| 98502–05025 | 18 – 32 |
| 99001–09600 | 5 – 11 |