



# YAMAHA

## PARTS CATALOGUE

GOLF CAR

**G1-A** (J16)

11J16-700E1





# FOREWORD

This Parts Catalogue is related to the parts in use for the Yamaha Golf Car G1-A (J16).  
When you are ordering replacement parts for the Golf Car G1-A (J16), refer to this Parts Catalogue and quote both part numbers and part names correctly.

1. Modifications or additions which have been made after issue of the Parts Catalogue will be announced in the Yamaha Parts News.

It is advisable that according to the Yamaha Parts News you make necessary corrections to the Parts Catalogue on hand to keep it up-to-date.

2. Abbreviations

The following abbreviations are used in this Parts Catalogue.

- U.R. Use size (thickness) and/or number as required.
- U.N. Use as many as you need.
- A.P. Alternate Parts
- L.M. Local Made
- F# Frame No. (Applicable machine No.)



3. The parts marked with (\*) in the parts number column of this Catalogue are not supplied with by Yamaha, those have to be found locally.

4. Parts, which are to be supplied in the form of assemblies, are listed with an indentation of one letter's space, and a dot ( . ) is put against the name of each part.

**EXAMPLE** CARBURETOR ASS'Y  
  . JET, pilot  
  . NOZZLE, main

5. Initial Serial No.

(A) Frame Serial No.	J16-300401 and following
(B) Engine Serial No.	S215-300401 and following



# CONTENTS

## ENGINE

Fig. 1	Cylinder Head - Cylinder	1
Fig. 2	Crankshaft - Piston	2
Fig. 3	Air Shroud - Fan	3
Fig. 4	Oil Pump	4
Fig. 5	Pump Drive Gear	5
Fig. 6	Intake	6
Fig. 7	Carburetor	8
Fig. 8	Exhaust	9
Fig. 9	Crankcase	11

## BODY

Fig. 10	Oil Tank	12
Fig. 11	Rear Suspension	13
Fig. 12	Frame	14
Fig. 13	Front Suspension - Wheel	15
Fig. 14	Steering	17
Fig. 15	Fuel Tank	19
Fig. 16	Brake	21
Fig. 17	Drum Brake	23
Fig. 18	Accelerator	24
Fig. 19	Governor	25

## DRIVE

Fig. 20	Primary Sheave	26
Fig. 21	Secondary Sheave	27
Fig. 22	Transmission	28
Fig. 23	Rear Axle - Wheel	30

## RIG

Fig. 24	Bumper	31
Fig. 25	Body	33
Fig. 26	Body Fitting	35

Fig. 27	Carrier	37
Fig. 28	Sun Roof	39
Fig. 29	Seat	40

## ELECTRICAL

Fig. 30	D.C Generator	41
Fig. 31	Starter Pulley	43
Fig. 32	C.D.I Magneto	44
Fig. 33	Electrical 1	46

## ALTERNATE PARTS

Fig. 34	Alternate (Body Rig)	48
---------	----------------------	----


## OTHERS

Fig. 35	Special Tools	49
---------	---------------	----

## INDEX

Numerical Index
Parts Name Index

FIG. 1 CYLINDER HEAD, CYLINDER



REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	J10-11111-00	HEAD, cylinder 1	1	
2	J10-11181-00	GASKET, cylinder head 1	1	
3	*	PLUG, sPark (CHAMPION L89CM)	1	LM
4	J10-11311-00	CYLINDER 1	1	
5	881-11351-01	GASKET, cylinder	1	
6	90116-08254	BOLT, stud	4	
7	90179-08278	NUT	4	





FIG. 2 CRANKSHAFT·PISTON

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	J10-11631-00-96	PISTON (STD)	1	UR
	J10-11631-00-98	PISTON (STD)	1	UR
	J10-11635-00	PISTON (1ST O/S 0.25MM)	1	AP
	J10-11636-00	PISTON (2ND O/S 0.50MM)	1	AP
2	J10-11610-00	PISTON RING SET (STD)	1	AP STD
	J10-11610-10	PISTON RING SET (1ST O/S)	1	AP
	J10-11610-20	PISTON RING SET (2ND O/S)	1	AP
3	81B-11633-00	PIN, Piston	1	
4	93450-20026	CIRCLIP	2	
5	93310-218A6	BEARING, cylindrical	1	
6	J10-11400-00	CRANKSHAFT ASSY	1	
7	J10-11412-00	•CRANK 1	1	
8	J10-11422-00	•CRANK 2	1	
9	8F3-11681-00	•PIN, crank 1	1	
10	90209-24073	•WASHER	2	
11	93310-424E8	•BEARING, cylindrical	1	
12	881-11651-00	•ROD, connecting	1	
13	93306-30621	BEARING (B6306)	1	
14	93306-20618	BEARING (B6206)	1	
15	93102-30188	OIL SEAL	1	
16	93450-72048	CIRCLIP	1	
17	93102-30128	OIL SEAL	1	
18	90280-05013	KEY, woodruff	1	
19	90170-16182	NUT	1	
20	92902-16100	WASHER	1	


FIG. 3 AIR SHROUD-FAN



REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	J10-12651-00	AIR SHROUD, cylinder 1	1	
2	J10-12652-00	AIR SHROUD, cylinder 2	1	
3	92502-06016	SCREW, Pan head	3	
4	92902-06600	WASHER	3	
5	97301-06015	BOLT	4	
6	90465-10129	CLAMP	1	
7	90465-08028	CLAMP	1	
8	90201-06557	WASHER, Plate	4	
9	J10-12631-00	DEFLECTOR 1	1	
10	90267-48040	RIVET, blind	3	
11	90201-04756	WASHER, Plate	3	
12	8G8-12611-01	FAN	1	
13	97322-06014	BOLT	6	
14	92902-06100	WASHER, sPring	6	
15	92902-06600	WASHER	6	
16	J10-12621-01	CASE, fan	1	
17	97302-06050	BOLT	5	
18	92902-06600	WASHER	5	

FIG. 4 OIL PUMP

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
✓ 1	J10-13101-01	OIL PUMP ASSY	1	4
2	90149-04128	•SCREW	1	X
✓ 3	90430-04004	•GASKET	1	
✓ 4	93210-18024	D-RING	1	
5	98902-05018	SCREW, bind	2	X
6	92902-05200	WASHER	2	✓
✓ 7	859-13410-00	STRAINER HOUSING ASSY	1	
8	90445-09108	HOSE	1	X
9	90445-09113	HOSE	1	X
10	90501-08430	SPRING, compression	1	X
✓ 11	90467-09005	CLIP	3	
12	90467-09026	CLIP	1	X
✓ 13	J10-13283-00	JET, senser	1	
14	90445-11391	HOSE	1	X
15	90467-10035	CLIP	2	X



FWD




FIG. 5 PUMP DRIVE GEAR

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	J10-15416-00	COVER 1	1	
2	93101-10090	OIL SEAL	1	
3	137-13176-00	METAL, worm shaft outer	1	
4	J10-13175-00	SHAFT, worm	1	
5	J10-13188-00	GEAR, drive	1	
6	93603-22028	PIN, dowel	1	
7	90206-11016	WASHER, wave	1	
8	137-13148-00	PLATE, cam thrust	1	
9	93410-10025	CIRCLIP	1	
10	J10-15466-00	GASKET 2	1	
11	J10-15426-00	COVER 2	1	
12	93112-53004	OIL SEAL	1	
13	91810-18027	PIN, dowel	2	
14	92501-06018	SCREW, Pan head	1	
15	92501-06012	SCREW, Pan head	1	
16	97322-08035	BOLT	1	
17	92902-08100	WASHER, sPring	1	
18	92902-08600	WASHER, Plate	1	
19	95822-06035	BOLT, flange	2	
20	97322-06030	BOLT	1	
21	92902-06100	WASHER, sPring	1	
22	92902-06600	WASHER	1	

FWD



FIG. 6 INTAKE

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
31	97302-06022	BOLT	2	
32	90201-06557	WASHER, Plate	1	
33	90387-06026	COLLAR	2	








FIG. 8 EXHAUST



REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	J10-14612-01	NUT, ring	1	
2	888-14633-00	RING	2	
3	J10-14613-00	GASKET, exhaust Pipe	1	
4	97322-08025	BOLT	2	
5	92902-08100	WASHER, sPring	2	
6	90506-20074	SPRING, tension	2	
7	J10-14610-01	EXHAUST PIPE ASSY 1	1	1
8	J10-14715-00	BAND, muffler	2	
9	95612-08100	NUT, u	2	
10	J10-14813-01	SHAFT, butterfly	1	
11	J10-14812-02	VALVE, butterfly	1	
12	90149-03130	SCREW	2	
13	93430-05033	CIRCLIP	2	
14	J10-14815-00	GASKET	1	
15	J10-14818-00	COVER, Gasket	1	
16	J10-14836-00	ROD	1	
17	J10-14833-00	JDINT	1	
18	95302-05700	NUT	1	
19	J10-14864-00	JDINT	1	
20	90170-05190	NUT	1	
21	J10-14837-00	CONNECTER, rod	1	
22	J10-14833-00	JDINT	1	
23	95302-05700	NUT	1	
24	J10-14864-00	JDINT	1	
25	90170-05190	NUT	1	
26	J10-14802-00	CONNECTER COMP.	1	
27	90464-07034	CLAMP	2	
28	92901-05600	WASHER, Plate	2	

FIG. 8 EXHAUST



REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
29	92902-05100	WASHER, sPring	2	
30	95302-05600	NUT	2	
31	93430-06005	CIRCLIP	2	
32	90506-06201	SPRING, tension	1	
33	90468-05112	CLIP	3	

FWD

FIG. 9 CRANKCASE

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
✓ 1	8H4-15100-00	CRANKCASE ASSY	1	
✓ 2	91830-21014	•PIN, dowel	2	
3	812-24461-00 X	PIPE, Joint	1	2
4	92502-06045 X	SCREW, Pan head	5	
✓ 5	92502-06055	SCREW, Pan head	1	
6	92502-06065 X	SCREW, Pan head	1	






FIG. 10 OIL TANK



REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
✓ 1	J10-21751-01	TANK, oil	1	
✓ 2	863-21771-00	BODY, cap	1	55
✓ 3	90430-31003	GASKET	1	55
✓ 4	J10-21745-00	PIPE, oil tank breather	1	
✓ 5	810-24357-00	CLIP, Pipe 2	2	
✓ 6	J10-21776-00	BAND, tank fitting	1	
✓ 7	92501-06012	SCREW, Pan head	1	
✓ 8	92902-06100	WASHER, spring	1	
✓ 9	92902-06600	WASHER	1	


FIG. 11 REAR SUSPENSION



REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	J10-W2211-01	REAR ARM COMP.	1	
2	J10-22123-00	BUSH 1	2	
3	90101-10419	BOLT	2	
4	95612-10100	NUT, u	2	
5	J10-22210-00	SHOCK ABSORBER ASSY, rear	2	
6	97302-10050	BDLT	4	
7	95602-10100	NUT, u	4	
8	J10-21411-01	BRACKET, engine 1	1	
9	90106-10034	BOLT	4	
10	92901-10100	WASHER, sPring	4	
11	92902-10600	WASHER, Plate	4	
12	J10-21486-00	DAMPER 2	4	
13	92901-10100	WASHER, sPring	8	
14	90170-10047	NUT	8	
15	J10-2219X-00	COVER	1	
16	J10-77277-00	DAMPER, noise 17	2	
17	J10-77278-00	DAMPER, noise 18	2	


FIG. 12 FRAME

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	J10-22501-01 ✓	FRAME COMP.	1	
2	90202-08111 ✗	WASHER, Plate	7	
3	J10-78249-00	TRIM, floor	2	
4	90267-48040	RIVET, blind	6	
5	J10-78187-00	FLAP, front fender	2	
6	90267-40054	RIVET, blind	6	
7	90201-05034	WASHER, Plate	6	
8	J10-78181-00	PLATE 1	1	
9	J10-78182-00	PLATE 2	1	
10	J11-22567-00	SUPPORT 1	1	
11	J11-22568-00	SUPPORT 2	1	
12	98902-08016 ✗	SCREW, blind	2	
13	92902-08100	WASHER, spring	2	
14	95302-08600	NUT	2	
15	97302-08075 ✗	BOLT	2	
16	92902-08600 ✓	WASHER, Plate	2	
17	95602-08100	NUT, u	2	
18	J10-78246-00	SEAL, floor 2	1	
19	J10-78247-00	SEAL 3	1	
20	J10-78248-00	SEAL 4	1	



FWD

FIG. 13 FRONT SUSPEN. WHEEL



REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	J10-W2351-01	FRONT LOWER ARM COMP.(L.H)	1	1
2	90381-15032	.BUSH, solid	2	
3	J10-23526-00	.BUSH	1	
4	J10-23510-02	KNUCKLE, steering comp.	1	1
5	97302-08030	BOLT	1	
6	95301-08700	NUT	1	
7	J10-W2352-01	FRONT LOWER ARM COMP.(R.H)	1	2
8	90381-15032	.BUSH, solid	2	
9	J10-23526-00	.BUSH	1	
10	J10-23520-02	STEERING KNUCKLE COMP.	1	2
11	97302-08030	BOLT	1	
12	95301-08700	NUT	1	
13	J10-23516-02	KING PIN, steering knuckle	2	1
14	91402-30025	PIN, cotter	2	
15	95702-12300	NUT, nylon	2	
16	90101-10418	BOLT	2	
17	95612-10100	NUT, u	2	
18	J10-W2355-00	ROD, tension	2	
19	J10-23583-00	.BUSH	1	
20	90101-08125	BOLT	2	
21	95612-08100	NUT, u	2	
22	90105-10007	BOLT, washer based	2	
23	95702-10300	NUT, nylon	2	
24	J10-23350-00	SHOCK ABSORBER ASSY	2	
25	97302-10050	BOLT	4	
26	95602-10100	NUT, u	4	
27	J10-W2511-01	HUB, front	2	
28	J10-25118-00	COVER, hub dust	2	




FIG. 13 FRONT SUSPEN. WHEEL

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
✓29	93306-00416	BEARING (B6004RS)	2	
✓30	93306-20314	BEARING (B6203)	2	
✓31	95302-14900	NUT	2	
✓32	90201-142E5	WASHER, Plate	2	
33	91402-30025	X PIN, cotter	2	
34	J11-25100-00	X FRONT WHEEL ASSY	2	3
✓35	J11-25102-00	•WHEEL RIM ASSY, front	1	
36	94118-B5507	X •TIRE	1	
✓37	787-25170-00	•AIR VALVE ASSY	1	
✓38	90179-12262	NUT	8	




FIG. 14 STEERING

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
✓ 1	J10-23816-02	ARM, Pitman	1	
✓ 2	J10-23836-09	•PIN, Pitman	2	
✓ 3	93102-22082	OIL SEAL	1	
✓ 4	J10-23876-00	BDLT	1	
✓ 5	93332-00010	BEARING	1	
✓ 6	J10-23877-00	NUT	1	
✓ 7	J10-23444-00	WASHER	1	
✓ 8	J10-23818-00	COVER, steering	1	
✓ 9	J10-23462-00	SEAL, steering	1	
✓ 10	90430-08119	GASKET	1	
✓ 11	J10-23459-00	BDLT	1	
✓ 12	90170-08024	NUT	1	
✓ 13	93104-15005	OIL SEAL	1	
✓ 14	97302-08020	BDLT	4	
✓ 15	92902-08100	WASHER, sPring	4	
✓ 16	93332-00010	BEARING	1	
✓ 17	J10-23814-00	HOLDER, handle upper	1	
✓ 18	J10-23811-00-9E	COLUMN, steering	1	
✓ 19	J10-23840-00	STEERING SHAFT ASSY	1	
✓ 20	J10-23838-00	WHEEL, steering	1	
✓ 21	J10-23826-00	ARM, idler	1	
✓ 22	J10-23831-00	ROD, tie	1	
✓ 23	J10-23841-10	JOINT, universal 1	1	
✓ 24	J10-23845-10	JOINT, universal 2	1	
✓ 25	90170-12054	NUT	1	
✓ 26	90170-12055	NUT	1	
✓ 27	J10-23831-00	ROD, tie	1	
✓ 28	J10-23841-10	JOINT, universal 1	1	

S  
S  
S




FIG. 14 STEERING

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
29	J10-23845-10	JOINT, universal 2	1	
30	90170-12054	NUT	1	
31	90170-12055	NUT	1	
32	95302-12900	NUT, slotted	4	
33	92902-12600	WASHER, Plate	2	
34	91402-30025	PIN, cotter	4	
35	95702-16300	NUT, nylon	1	
36	90215-16161	WASHER, lock	1	
37	90185-12061	NUT, self-locking	1	
38	92902-12200	WASHER	1	
39	90340-14029	PLUG, straight screw	1	
40	97302-10050	BOLT	4	
41	92901-10100	WASHER, spring	4	
42	90430-14043	GASKET	1	

To Fig. 13- 4 KNUCKLE, steering




FIG. 15 FUEL TANK

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
✓ 1	J10-24111-00	TANK, fuel	1	
✓ 2	J10-24611-00	BODY, caP	1	2
✓ 3	J10-24612-00	GASKET, caP	1	
✓ 4	J10-24461-00	PIPE, Joint	1	
✓ 5	J10-21773-00	GROMMET	1	
✓ 6	J10-24311-00	PIPE, fuel 1	1	N
✓ 7	90468-04092	CLIP	1	X
✓ 8	J10-21744-00	BREATHER	1	
✓ 9	J10-21773-00	GROMMET	1	
✓ 10	J10-85710-01	FUEL LEVEL GAUGE ASSY	1	N
✓ 11	J10-24312-00	PIPE 2	1	X
✓ 12	810-24357-00	CLIP, Pipe 2	2	X
✓ 13	809-24560-01	FILTER ASSY	1	
✓ 14	810-24357-00	CLIP, Pipe 2	2	X
✓ 15	90501-08486	SPRING, compression	1	X
✓ 16	J10-24366-00	CLAMP, fuel Pipe 1	2	X
✓ 17	90445-11288	HOSE	1	
✓ 18	J10-24313-00	PIPE 3	1	X
✓ 19	90461-10054	CLAMP	3	X
✓ 20	98502-05012	SCREW, Pan head	3	
✓ 21	92902-05100	WASHER, spring	3	
✓ 22	92901-05600	WASHER, Plate	3	
✓ 23	90445-11151	HOSE	1	X
✓ 24	810-24357-00	CLIP, Pipe 2	2	X
✓ 25	J10-24410-02	FUEL PUMP ASSY	1	
✓ 26	92501-06018	SCREW, Pan head	2	
✓ 27	92902-06100	WASHER, spring	2	
✓ 28	90445-09069	HOSE	1	X





FIG. 15 FUEL TANK


REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
29	90467-08017	CLIP	2	
30	90445-10449	HOSE	1	
31	90467-09006	CLIP	2	
32	J10-24173-00	BAND, tank fitting 1	2	
33	90201-08107	WASHER, Plate	2	
34	95602-08100	NUT, u	2	

FIG. 16 BRAKE




REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	J10-27250-00 ✓	BRAKE ARM COMP.	1	
2	J10-27245-00 ✓	PAD, brake Pedal	1	
3	J10-27211-00 ✓	PEDAL, brake	1	
4	90508-40384 ✓	SPRING, torsion	1	
5	90387-10684 ✓	COLLAR	1	
6	J10-25654-00 ✓	BRACKET, Pedal	1	
7	90101-10447 ✓	BOLT	1	
8	95602-10100 ✓	NUT, u	1	
9	92901-10100 ✓	WASHER, sPring	1	
10	J10-25670-00 X	PARKING PEDAL COMP.	1	# 2
11	97302-06030 ✓	BOLT	1	
12	92902-06200 ✓	WASHER	1	
13	92902-06100 ✓	WASHER, sPring	1	
14	95302-06600 ✓	NUT	1	
15	90508-20383 ✓	SPRING, torsion	1	5
16	90109-08506 ✓	BOLT	1	
17	92902-08200 ✓	WASHER	1	
18	92902-08100 ✓	WASHER, sPring	1	
19	90179-08263 ✓	NUT	1	
20	J10-25679-00 ✓	DAMPER	1	
21	97301-06015 ✓	BOLT	4	
22	92902-06100 ✓	WASHER, sPring	4	
23	J10-25681-00 ✓	EQUALIZER, brake	1	
24	J10-25685-00 ✓	ROD	1	
25	91701-10022 ✓	PIN, clevis	1	
26	91490-30015 ✓	PIN, cotter	1	
27	90249-14129 ✓	PIN	1	
28	90179-08261 ✓	NUT	1	

FIG. 16 BRAKE



REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
29	95301-08700 ✓	NUT	1	
30	J10-26341-00 ✓	CABLE, brake	1	
31	J10-26351-01 ✓	CABLE, brake	1	
32	93430-09035 ✓	CIRCLIP	4	
33	91701-08018 ✓	PIN, clevis	4	
34	91490-25015 ✗	PIN, cotter	4	

FIG. 17 DRUM BRAKE



REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	J10-27280-01	BACKING PLATE ASSY 1	1	
2	J10-27208-01	•BACKING PLATE SUB ASSY 1	1	
3	J10-27207-00	•BRAKE LEVER COMP.	1	
4	J10-27286-00	•COVER, dust	1	
5	J10-27270-00	•ADJUSTER ASSY	1	
6	92902-06100	•WASHER, sPrInG	2	
7	95302-06600	•NUT	2	
8	J10-27285-00	•CAP	1	
9	J10-25330-00	•BRAKE SHOE COMP.	2	6
10	90506-26191	•SPRING, tension	2	
11	J10-27282-00	•PIN, shoe hold down	2	
12	J10-27281-00	•SPRING, shoe clamp	2	
13	J10-27290-01	BACKING PLATE ASSY 2	1	
14	J10-27209-01	•BACKING PLATE SUB ASSY 2	1	
15	J10-27207-00	•BRAKE LEVER COMP.	1	
16	J10-27286-00	•COVER, dust	1	
17	J10-27270-00	•ADJUSTER ASSY	1	
18	92902-06100	•WASHER, sPrInG	2	
19	95302-06600	•NUT	2	
20	J10-27285-00	•CAP	1	
21	J10-25330-00	•BRAKE SHOE COMP.	2	
22	90506-26191	•SPRING, tension	2	
23	J10-27282-00	•PIN, shoe hold down	2	
24	J10-27281-00	•SPRING, shoe clamp	2	
25	97322-08016	BOLT	8	
26	92902-08100	WASHER, sPrInG	8	







FIG. 18 ACCELERATOR

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	J10-27874-01	BRACKET, accelerator Pedal	1	
2	J10-27853-02	SHAFT, Pedal 1	1	
3	J10-27872-01	ARM, accelerator Pedal	1	
4	91609-60025	PIN, sPrinE	1	
5	J10-27871-01	PEDAL, accelerator	1	
6	97302-06025	BOLT	1	
7	92902-06100	WASHER, sPrinE	1	
8	90101-06422	BOLT	1	
9	95302-06700	NUT	1	
10	J10-27852-00	CUP 1	1	
11	91609-35028	PIN, sPrinE	1	
12	90384-14080	BUSH, bimetal formed	2	
13	93210-14104	O-RING	4	
14	97302-06014	BOLT	4	
15	92902-06100	WASHER, sPrinE	4	
16	90506-29187	SPRING, tension	1	
17	J10-26311-02	CABLE, throttle 1	1	
18	91702-05012	PIN, clevis	1	
19	91401-16010	PIN, cotter	1	
20	93430-07012	CIRCLIP	1	
21	90508-16460	SPRING, torsion	1	
22	90560-05001	SPACER	1	
23	J10-27981-00	BRACKET, throttle	1	

FIG. 19 GOVERNOR



REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	J10-27912-00	RETAINER	1	
2	90387-21690	COLLAR	1	
3	J10-27913-00	WEIGHT	8	
4	J10-27911-00	HOLDER	1	
5	J10-27927-00	LIFTER	1	
6	93342-22502	BEARING	1	
7	90201-20275	WASHER, Plate	1	
8	J10-27921-00	SHAFT, Governor	1	
9	J10-27922-00	FDRK, Governor	1	
10	98501-04008	SCREW, Pan head	2	
11	90202-08110	WASHER, Plate	2	
12	93430-06005	CIRCLIP	1	
13	93104-08058	OIL SEAL	1	
14	J10-27951-01	LEVER, sPeed limiter	1	
15	90385-08034	BUSH	2	
16	90508-40398	SPRING, torsion	1	
17	95302-06600	NUT	1	
18	J10-27959-00	SCREW, adjusting	1	
19	95302-05700	NUT	1	
20	J10-14836-00	ROD	1	
21	J10-14833-00	JOINT	1	
22	95302-05700	NUT	1	
23	J10-14864-00	JOINT	1	
24	90170-05190	NUT	1	

FWD




FIG. 20 PRIMARY SHEAVE

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	J10-46210-00 ✓	PRIMARY FIXED SHEAVE COMP.	1	
2	93306-90601 ✓	BEARING (B6906)	1	
3	90387-47686 ✓	COLLAR	1	
4	J10-46244-00 ✓	SEAT, sPring	1	
5	J10-46220-01 ✓	PRIMARY SLIDING SHEAVE COMP.	1	1
6	J10-46223-01 ✓	CAM	1	
7	J10-46230-00 ✓	PRIMARY SHEAVE CAP COMP.	1	
8	J10-46232-00 ✓	WEIGHT 1	4	
9	J10-46236-00 ✓	PIN, weight	4	
10	98501-05020 ✓	SCREW, Pan head	8	
11	92902-05100 ✓	WASHER, sPring	8	
12	J10-46253-01 ✓	SLIDER	4	
13	90149-05129 ✓	SCREW	4	
14	90501-32557 ✓	SPRING, comPression	1	
15	93410-28051 ✓	CIRCLIP	1	
16	90560-12180 ✓	SPACER	1	
17	90215-13146 ✓	WASHER, lock	1	
18	J10-46249-00 ✓	BOLT	1	
19	93210-27458 ✓	O-RING	2	
20	J10-46241-02 ✓	BELT	1	

FIG. 21 SECONDARY SHEAVE

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	J10-46260-00 ✓	SECONDARY FIXED SHEAVE COMP.	1	
2	J10-W4621-01 ✓	SECONDARY SLIDING SHEAVE COMP.	1	<u>1</u>
3	90384-20143 ✓	BUSH, bimetal formed	1	
4	93109-20014 ✓	OIL SEAL	2	
5	801-17688-10 ✓	SHOE, ramp	3	
6	J10-46284-00 ✓	SEAT, secondary sPring	1	
7	801-17688-10 ✓	SHOE, ramp	3	
8	90280-05022 ✓	KEY, woodruff	1	
9	90501-45600 ✓	SPRING, comPression	1	
10	92902-12200 ✓	WASHER	1	
11	95302-12900 ✓	NUT, slotted	1	
12	91401-30025 ✓	PIN, cotter	1	






FIG. 22 TRANSMISSION




REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	J10-46311-00 ✓	CASE, transmission 1	1	
2	93306-20501 ✓	BEARING (B6205)	1	
3	93306-20401 ✓	BEARING (B6204)	1	
4	93306-00801 ✓	BEARING (B6008)	1	
5	93102-25017 ✓	OIL SEAL	1	
6	93102-22189 ✓	OIL SEAL	1	
7	95601-08335 ✗	BOLT, stud	9	
8	95601-08345 ✗	BOLT, stud	2	
9	J10-46312-00 ✓	CASE, transmission 2	1	
10	93306-20309 ✓	BEARING (B6203)	1	2
11	93306-20401 ✓	BEARING (B6204)	1	
12	93306-00801 ✓	BEARING (B6008)	1	
13	93102-22189 ✓	OIL SEAL	1	
14	8E4-24461-00 ✓	PIPE, joint	1	
15	91810-05016 ✓	PIN, dowel	2	
16	92902-08600 ✓	WASHER, Plate	11	
17	92902-08100 ✓	WASHER, spring	11	
18	95302-08600 ✓	NUT	11	
19	J10-46319-00 ✓	GASKET	1	
20	90340-14036 ✓	PLUG, straight screw	2	
21	90430-14043 ✓	GASKET	2	
22	90465-06011 ✗	CLAMP	1	
23	835-47559-00 ✓	CAP 2	1	
24	97322-10020 ✓	BOLT	2	
25	92901-10100 ✓	WASHER, spring	2	
26	92902-10600 ✓	WASHER, Plate	2	
27	90465-08028 ✓	CLAMP	1	
28	92502-06010 ✗	SCREW, Pan head	1	

FIG. 22 TRANSMISSION



REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
29	92902-06100	WASHER, sPring	1	
30	J10-46321-00	SHAFT, inPut	1	
31	J10-46331-02	GEAR, inPut 1	1	
32	93410-25017	CIRCLIP	1	
33	J10-W4631-00	SHAFT, counter	1	
34	J10-46361-02	GEAR, counter 1	1	
35	J10-46362-02	GEAR, counter 2	1	
36	90201-20272	WASHER, Plate	1	
37	J10-W4641-00	CASE, differential	1	
38	J10-W4642-02	GEAR, ring	1	
39	J10-46414-00	GEAR, differential side	2	
40	J10-46415-00	PINION, differential	4	
41	97312-08030	BOLT	4	
42	92902-08100	WASHER, sPring	4	
43	91810-03014	PIN, dowel	2	

FIG. 23 REAR AXLE•WHEEL



REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	J11-25300-00	REAR WHEEL ASSY	2	
2	J11-25102-00	•WHEEL RIM ASSY, front	1	
3	94118-85508	•TIRE	1	
4	787-25170-00	•AIR VALVE ASSY	1	
5	90179-12262	NUT	8	
6	J10-46540-00	REAR AXLE HOUSING COMP.	2	
7	97322-08025	BOLT	12	
8	92902-08100	WASHER, sPring	12	
9	97322-10020	BOLT	8	
10	92901-10100	WASHER, sPring	8	
11	J10-46510-02	REAR AXLE SHAFT COMP.	1	2
12	J10-46521-00	DRUM	2	




FIG. 24 BUMPER

REF. ND.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	J10-78106-03-93	BUMPER SUB-ASSY, front	1	chrome-Plated 2
2	J10-78167-01	BUMPER, rubber 1	1	
3	J10-78162-01	PAD, front bumPer	1	
4	90267-40077	RIVET, blind	8	
5	J10-78168-01	BUMPER, rubber 2	1	
6	J10-78164-01	STAY, front bumPer 1	2	
7	97322-08016	BDLT	4	
8	92902-08100	WASHER, sPrinG	4	
9	92902-08600	WASHER, Plate	4	
10	90201-04756	WASHER, Plate	8	
11	97322-08025	BDLT	4	
12	92902-08600	WASHER, Plate	4	
13	90201-08766	WASHER, Plate	4	
14	92902-08100	WASHER, sPrinG	4	
15	95302-08600	NUT	4	
16	J10-78107-03-93	BUMPER SUB-ASSY, rear	1	chrome-Plated 2
17	J10-78167-01	BUMPER, rubber 1	1	
18	J10-78162-01	PAD, front bumPer	1	
19	90267-40077	RIVET, blind	8	
20	J10-78168-01	BUMPER, rubber 2	1	
21	J10-78174-01	STAY, rear bumPer	2	
22	97322-08016	BDLT	4	
23	92902-08100	WASHER, sPrinG	4	
24	J10-78179-00	PLATE, extension	1	
25	97302-08014	BDLT	2	
26	92902-08600	WASHER, Plate	2	
27	92902-08200	WASHER	2	
28	92902-08100	WASHER, sPrinG	2	




FIG. 24 BUMPER

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
29	95301-08800	NUT, crown	2	
30	90201-04756	WASHER, Plate	8	
31	97322-08020	BOLT	4	
32	92902-08600	WASHER, Plate	4	
33	92902-08200	WASHER	4	
34	92902-08100	WASHER, sPring	4	
35	95302-08600	NUT	4	
36	J10-78122-00	REINFORCEMENT 2	1	
37	90387-375A1	COLLAR	3	




FIG. 25 BODY

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	J16-W7811-00	PANEL, body shell	1	
2	J10-78119-00	PLATE 3	1	
3	90267-40038	RIVET, blind	7	
4	J10-78121-00	REINFORCEMENT 1	1	
5	98901-06016	SCREW, blind	6	
6	92902-08100	WASHER, spring	6	
7	95302-06600	NUT	6	
8	J10-78318-00	HOOK, end 1	4	
9	90267-40038	RIVET, blind	4	
10	J10-78137-00	PLATE 4	1	
11	90267-40075	RIVET, blind	4	
12	J10-78272-00-9E	COVER, fuel inlet	1	
13	J10-77764-00	LABEL, warning 4	1	
14	J10-78238-01	FASTENER, upper	1	
15	90201-08083	WASHER, plate	1	
16	93430-06005	CIRCLIP	1	
17	J10-78239-00	FASTENER, lower	1	
18	90267-32019	RIVET, blind	2	
19	90480-35242	GROMMET	2	
20	90267-40038	RIVET, blind	2	
21	90201-04M06	WASHER, plate	2	
22	J16-78115-00	CDWL, front	1	
23	J10-77165-01	TRIM 1	1	
24	90267-63047	RIVET, blind	11	
25	J16-78117-00	PLATE 1	1	
26	90267-40M00	RIVET, blind	4	
27	J10-78118-01	PLATE 2	1	
28	90267-40054	RIVET, blind	4	




FIG. 25 BODY

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
29	J10-78232-00	MAT, main floor 2	1	
30	90267-63047	RIVET, blind	7	
31	J10-78233-00	MAT, main floor 3	1	
32	90267-63047	RIVET, blind	6	
33	J16-78147-00	PLATE 5	1	
34	90267-40M00	RIVET, blind	3	
35	J10-78359-00	HOLDER 3	2	
36	J10-78291-00	EMBLEM 1	1	
37	J10-77151-01	PAD 1	1	
38	J10-77152-01	PAD 2	1	
39	95702-05300	NUT, nylon	2	
40	92902-05200	WASHER	2	
41	J10-77768-00	LABEL, warning	1	
42	J10-77711-00	PANEL, instrument	1	2
43	J10-78245-00	SEAL 1	1	
44	J10-77741-00	INDICATOR 1	1	
45	90480-48243	GROMMET	1	
46	97701-50130	SCREW, tapping	2	
47	90201-05029	WASHER, Plate	2	
48	90480-07241	GROMMET	2	
49	90201-06075	WASHER, Plate	3	
50	90201-08310	WASHER, Plate	2	
51	98902-08020	SCREW, bind	2	
52	92902-08100	WASHER, spring	2	
53	97302-06020	BOLT	3	
54	92902-06100	WASHER, spring	3	




FIG. 26 BODY FITTING

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	J10-77145-00	HINGE 1	1	
2	90480-06240	GROMMET	2	
3	J10-77146-00	HINGE 2	2	
4	91701-08118	PIN, clevis	2	
5	91401-25015	PIN, cotter	2	
6	98903-06020	SCREW, bind	8	
7	98903-06025	SCREW, bind	2	
8	90202-08085	WASHER, Plate	2	
9	90201-06697	WASHER, Plate	10	
10	92902-06100	WASHER, sPring	10	
11	95302-06600	NUT	10	
12	97322-08020	BOLT	4	
13	92902-08100	WASHER, sPring	4	
14	92902-08600	WASHER, Plate	4	
15	J10-77125-00	STAY 1	2	
16	J10-77766-00	LABEL, warning 6	2	
17	91701-08014	PIN, clevis	4	
18	90206-08051	WASHER, wave	4	
19	90468-16065	CLIP	4	
20	J10-77188-00	STOPPER	1	
21	91701-06012	PIN, clevis	1	
22	90206-06060	WASHER, wave	1	
23	92902-06200	WASHER	1	
24	90468-12007	CLIP	1	
25	J10-78156-00	STOPPER, lock	1	
26	98702-05035	SCREW, flat head	2	
27	J10-78231-02	MAT, main floor 1	1	
28	J10-78234-00	MAT, main floor 4	1	




FIG. 26 BODY FITTING

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
29	90267-63047 ✓	RIVET, blind	8	
30	J10-78271-02 ✓	SERVICE LID, Pedal	1	
31	J10-78235-00 ✓	SHEET, main floor	1	
32	90267-63047 ✓	RIVET, blind	8	
33	J10-78241-00 ✓	MAT, rear floor	1	
34	J10-78191-01 ✓	PANEL, rear fender 1	1	
35	J10-77765-00 ✓	LABEL, warning 5	1	
36	J10-78197-00 ✓	FLAP, rear fender	1	
37	90267-40054 ✓	RIVET, blind	4	
38	90201-05034 ✓	WASHER, Plate	4	
39	90480-12071 ✓	GROMMET	1	
40	97301-06015 ✓	BOLT	4	
41	92902-06100 ✓	WASHER, sPrinG	4	
42	92902-06600 ✓	WASHER	4	
43	J10-78192-02 ✓	PANEL, rear fender 2	1	
44	J10-78197-00 ✓	FLAP, rear fender	1	
45	90267-40054 ✓	RIVET, blind	4	
46	90201-05034 ✓	WASHER, Plate	4	
47	90480-12071 ✓	GROMMET	1	
48	97301-06015 ✓	BOLT	4	
49	92902-06100 ✓	WASHER, sPrinG	4	
50	92902-06600 ✓	WASHER	4	

Fig. 12 FRAME COMP




Fig. 14-19 WHEEL, steering

FIG. 27 CARRIER

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	J10-78351-00-9E	SUPPORT, ba& upper	1	
2	J10-78352-00-9E	SUPPORT, ba& lower 1	1	
3	J10-78353-00-9E	SUPPORT, ba& lower 2	1	
4	92701-08045	SCREW, flat head	4	
5	90201-08107	WASHER, Plate	4	
6	92902-08100	WASHER, sPring	4	
7	95303-08800	NUT, crown	4	
8	J10-78356-00	PAD, ba& support	1	
9	J10-78355-00	BAND	1	
10	J10-78367-00	PLATE, anchor	1	
11	98903-06016	SCREW, bind	2	
12	92903-06100	WASHER, sPring	2	
13	95303-06800	NUT, crown	2	
14	J10-78157-00	BASE, lock	1	
15	J10-78368-00	LEVER, lock	1	
16	J10-78369-01	PIN, lever	1	
17	90508-10382	SPRING, torsion	1	
18	93410-06053	CIRCLIP	1	
19	92503-06008	SCREW, Pan head	4	
20	92902-06100	WASHER, sPring	4	
21	J10-78139-00	CAP, end	2	
22	92901-10100	WASHER, sPring	2	
23	95302-10600	NUT	2	
24	97302-06014	BOLT	4	
25	92902-06100	WASHER, sPring	4	
26	J10-78366-01	CLAMP, support	2	
27	J10-78357-01	HOLDER 1	1	
28	J10-78358-00	HOLDER 2	1	





FIG. 27 CARRIER


REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
29	90502-10013	SPRING, conical	2	
30	97702-50125	SCREW, tapping	2	
31	J10-78292-00	EMBLEM 2	1	
32	J10-77762-00	LABEL, warning 2	1	
33	92901-05600	WASHER, plate	2	

FIG. 28 SUN ROOF




REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	J11-78310-00	SUN ROOF ASSY	1	Not available use highlighted items
2	J11-78314-00	COVER, sun roof	1	
3	97701-60116	SCREW, tapping	10	10
4	90201-06557	WASHER, Plate	10	20
5	90202-06008	WASHER, Plate	20	20
6	J11-78301-00	FRAME COMP., roof	1	
7	J11-78311-00	FRAME, sun roof	1	
8	J11-78316-00	DAMPER	1	
9	J11-78335-01	LOCK, side wind	2	
10	90249-05136	PIN	4	
11	93430-04003	CIRCLIP	4	
12	92603-08050	SCREW, oval head	4	
13	90201-08310	WASHER, Plate	2	
14	95602-08100	NUT, u	6	
15	J11-78312-00	SUPPORT, sun roof 1	1	
16	J11-78313-00	SUPPORT, sun roof 2	1	
17	97301-08060	BOLT	8	
18	95601-08100	NUT, u	8	
19	J11-78329-00	SPACER 2	8	
20	J11-78343-00	RETAINER	4	
21	95602-08100	NUT, u	8	
22	J11-78328-00	SPACER 1	2	
23	90338-06018	PLUG	16	
24	J11-77271-00	DAMPER, noise 11	8	
25	J11-77272-00	DAMPER, noise 12	1	
26	J11-78344-00	RETAINER 2	2	
27	J11-78338-00	SPACER 3	4	
28	90506-23204	SPRING, tension	2	

FIG. 29 SEAT




REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	J10-78401-02 ✓	SEAT SUB-ASSY, cushion	1	UR
2	J10-78361-00-93 ✓	ARM REST 1	1	UR for hawaii (brown)
3	97302-10030 ✓	BOLT	1	
4	92901-10100 ✓	WASHER, sPring	1	
5	92902-10600 ✓	WASHER, Plate	1	
6	92603-08035 ✓	SCREW, oval head	2	
7	92901-08500 ✓	WASHER, tooth	2	
8	97302-08025 ✓	BOLT	4	
9	92902-08100 ✓	WASHER, sPring	4	
10	90201-08310 ✓	WASHER, Plate	4	
11	J10-78439-00 ✓	WASHER, seat	4	
12	90480-42282 ✓	GROMMET	2	
13	J10-78403-02 ✓	SEAT SUB-ASSY, cushion 2	1	
14	J10-78362-00-93 ✓	ARM REST 2	1	UR
15	97302-10030 ✓	BOLT	1	UR for hawaii (brown)
16	92901-10100 ✓	WASHER, sPring	1	
17	92902-10600 ✓	WASHER, Plate	1	
18	92603-08035 ✓	SCREW, oval head	2	
19	92901-08500 ✓	WASHER, tooth	2	
20	97302-08025 ✓	BOLT	4	
21	92902-08100 ✓	WASHER, sPring	4	
22	90201-08310 ✓	WASHER, Plate	4	
23	J10-78439-00 ✓	WASHER, seat	4	

FIG. 30 D.C GENERATOR




REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	J10-81100-10	STARTER GENERATOR ASSY	1	
2	J10-81150-10	ARMATURE ASSY	1	
3	J10-81157-10	BEARING 1 (6202 SD)	1	
4	J10-81158-10	BEARING 2 (6203 SD)	1	
5	J10-81159-10	HOLDER, bearing	1	
6	J10-81175-10	STOPPER 1	1	
7	J10-81110-10	STATOR ASSY	1	
8	J10-81160-10	FIELD COIL ASSY	1	
9	J10-81148-10	SCREW 4	2	
10	95301-06600	NUT	4	
11	92901-06600	WASHER, Plate	2	
12	92901-06100	WASHER, sPring	4	
13	J10-81146-10	SCREW 2	4	
14	J10-81165-10	BRACKET, starter generator 1	1	
15	J10-81166-10	BRACKET, starter generator 2	1	
16	J10-81147-10	SCREW 3	2	
17	95301-06600	NUT	4	
18	92901-06600	WASHER, Plate	2	
19	92901-06100	WASHER, sPring	4	
20	J10-81119-10	BRUSH HOLDER ASSY	1	
21	J10-81111-10	BRUSH	4	
22	J10-81113-10	SPRING, brush	4	
23	J10-81115-10	WIRE, lead	2	
24	98501-05016	SCREW, Pan head	2	
25	98503-04010	SCREW, Pan head	4	
26	J10-81163-10	KEY	1	
27	95301-14600	NUT	1	
28	92901-06100	WASHER, sPring	1	

FIG. 30 D.C GENERATOR



REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
29	98501-05018	•SCREW, Pan head	3	
30	J10-81129-10	•COVER, brush	3	
31	J10-81139-10	•COVER, brush 2	1	
32	J10-81145-10	•SCREW 1	2	
33	92901-06600	•WASHER, Plate	2	
34	92901-06100	•WASHER, sPrinG	2	
35	92901-05100	•WASHER, sPrinG	2	
36	92901-04100	•WASHER, sPrinG	4	

FIG. 31 STARTER PULLEY




REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	J10-87183-00	INSULATOR, Generator	1	
2	98501-05008	SCREW, Pan head	4	
3	92902-05100	WASHER, sPring	4	
4	J10-81161-00	PULLEY	1	
5	J10-87172-00	FAN, Generator	1	
6	92502-06025	SCREW, Pan head	2	
7	92902-06100	WASHER, sPring	2	
8	92902-06600	WASHER	2	
9	J10-81173-00	BELT	1	
10	90101-08420	BOLT	1	
11	J10-21647-00	COLLAR	1	3
12	92902-08200	WASHER	2	
13	92902-08100	WASHER, sPring	1	
14	95302-08600	NUT	1	
15	90387-08687	COLLAR	2	
16	J10-81170-00	TENSIONER ASSY	1	
17	97302-08030	BOLT	1	
18	90201-08107	WASHER, Plate	2	
19	92902-08100	WASHER, sPring	1	
20	95302-08600	NUT	1	
21	97302-08020	BOLT	1	
22	92902-08100	WASHER, sPring	1	
23	90201-08107	WASHER, Plate	1	

3



FIG. 32 C.D.I MAGNETO



REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	J10-85500-20	C.D.I. MAGNETO ASSY	1	
2	8G8-85511-20	•COIL, source	1	
3	J10-85580-20	•COIL, Pulser	1	
4	J10-85515-20	•LEAD WIRE ASSY	1	
5	104-81328-20	•CLAMP	2	
6	98501-05020	•SCREW, Pan head	2	
7	92901-05100	•WASHER, sPrinG	2	
8	98501-04020	•SCREW, Pan head	2	
9	92901-04100	•WASHER, sPrinG	2	
10	98501-04008	•SCREW, Pan head	1	
11	92901-04100	•WASHER, sPrinG	1	
12	J10-85550-20	•ROTOR ASSY	1	
13	98901-06014	SCREW, bind	2	
14	90201-06043	WASHER, Plate	2	
15	J10-85540-20	C.D.I. UNIT ASSY	1	
16	2A7-85546-00	BAND	1	
17	J10-81910-10	VOLTAG E REGULATOR ASSY	1	
18	92502-06014	SCREW, Pan head	1	
19	92902-06100	WASHER, sPrinG	1	
20	92902-06600	WASHER	1	
21	J10-81940-01	STARTER SWITCH ASSY	1	
22	92901-04100	•WASHER, sPrinG	2	
23	95301-04700	•NUT	2	
24	95301-06700	•NUT	10	
25	92901-06100	•WASHER, sPrinG	10	
26	J10-81924-01	•BAR, short	1	
27	J10-81945-00	•PLATE, switch fitting	1	
28	J10-81951-00	•RELAY	2	




FIG. 32 C.D.I MAGNETO

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
29	95301-06700 ✓	..NUT	10	
30	92901-06100 ✓	..WASHER, sPring	10	
31	95301-04700 ✓	..NUT	2	
32	92901-04100 ✓	..WASHER, sPring	2	
33	J10-81916-00 ✓	..COVER, terminal	1	
34	J10-81925-00 ✓	..TERMINAL	1	
35	J10-81923-00 ✓	..WASHER	2	
36	92901-05100 ✓	..WASHER, sPring	2	
37	98501-05020 ✓	..SCREW, Pan head	2	
38	J10-81949-00 ✓	..WIRE, lead	1	
39	95701-08300 ✓	NUT, nylon	3	





FIG. 33 ELECTRICAL 1

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	J10-82115-00	WIRE, Plus lead	1	
2	J10-82116-00	WIRE, minus lead	1	
3	J10-82105-00	WIRE HARNESS	1	
4	J10-82117-00	WIRE, lead	1	
5	1E6-82150-00	FUSE HOLDER ASSY	1	Z
6	1E6-82151-00	•FUSE (6V-10A)	2	A
7	J14-82150-00	FUSE HOLDER ASSY	1	
8	1E6-82151-00	•FUSE (6V-10A)	2	
9	J11-82110-70	BATTERY ASSY	1	
10	J10-82133-00	SCREW, fitting	2	
11	J10-82136-00	PLATE, battery fitting	1	
12	95302-06600	NUT	2	
13	92902-06200	WASHER	2	
14	8H4-82310-20	IGNITION COIL ASSY	1	
15	92502-06025	SCREW, Pan head	2	
16	90465-06038	CLAMP	2	
17	8G8-82318-00	WIRE, sub-lead	2	
18	512-82370-10	PLUG CAP ASSY	1	with noise sup- Presser
19	J10-82508-20	MAIN SWITCH ASSY	1	
20	J10-82550-03	STOP SWITCH ASSY	1	KEY
21	95302-10700	NUT	2	
22	90465-08028	CLAMP	1	
23	J10-82590-21	WIRE HARNESS ASSY	1	
24	366-82591-00	BAND	1	
25	256-83936-00	BAND, switch cord	1	
26	J10-83383-02	BUZZER	1	
27	97302-06014	BOLT	1	
28	95302-06700	NUT	1	

FIG. 33 ELECTRICAL 1


REF. ND.	PART ND.	DESCRIPTION	Q'TY	REMARKS
29	92902-06100	WASHER, sPrinE	1	





# ALTERNATE PARTS

FIG. 34 ALTERNATE (BODY RIG.)




REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	J11-78287-00	ASH TRAY	1	
2	J11-78286-00	LID, ash tray	1	
3	91701-06026	PIN, clevis	1	
4	92901-06600	WASHER, Plate	1	
5	90501-08256	SPRING, compression	1	
6	91401-20012	PIN, cotter	1	
7	J11-77767-00	LABEL, warning 7	1	
8	J11-78103-00	FLAP COMP.	2	
9	J11-78198-00	•RETAINER, flap	1	
10	J11-78199-00	•FLAP, rear 2	1	
11	90201-05034	•WASHER, Plate	3	
12	90267-40054	•RIVET, blind	3	
13	92580-08012	SCREW, Pan head	2	
14	95601-08100	NUT, u	2	
15	90338-09094	PLUG	12	

FWD

**OTHERS**

FIG. 35 SPECIAL TOOLS

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	90890-01135-00	CRANKCASE SEPARATOR		
2	90890-01051-00	RING NUT WRENCH (Ignition Switch)		
3	90890-01235-00	ROTOR HOLDING TOOL		
4	90890-90058-00	CRANKSHAFT SETTING POT		
5	ACC-11401-01-00	SPECIAL ADAPTOR (16x1.0x20 UNF)		
6	90890-90067-00	ADAPTOR (16x1.0)		
7	90890-01202-00	SPACER (Large)		
8	90890-90059-00	SPACER (Small)		
9	90890-90060-00	SETTING BOLT		
10	90890-90105-10	UNIVERSAL MAGNETO/SHEAVE PULLER		
11	90890-01876-00	PRIMARY SHEAVE PULLER		
12	90890-02300-00	CRANKSHAFT JIG		
13	90890-02204-00	PRESS PLATE (2 Reg.)		
14	90890-02203-00	PRESS PIN		
15	ACC-11401-02-00	SPECIAL PRESS PLATES (PR.)		
16	90890-02213-00	WIDTH GAUGE (55.75mm)		
17	90890-02202-00	PRESS BOX		
18	ACC-11401-03-00	SECONDARY SHEAVE HOLDER		
19	90890-01886-00	SOCKET WRENCH (Brake Adjusting)		



# INDEX

NUMERICAL INDEX

PART NO.	REF. NO.	PART NO.	REF. NO.	PART NO.	REF. NO.
J10-W1443-00	6-23	J10-14141-00	7-15	J10-21411-01	11- 8
J10-W2211-01	11- 1	620-14142-45	7-16	J10-21486-00	11-12
J10-W2351-01	13- 1	796-14181-00	7-13	J10-21647-00	31-11
J10-W2352-01	13- 7	796-14184-00	7-14	J10-21744-00	15- 8
J10-W2355-00	13-18	796-14185-00	7- 5	J10-21745-00	10- 4
J10-W2511-01	13-27	796-14186-00	7- 6	J10-21751-01	10- 1
J10-W4621-01	21- 3	353-14190-15	7-17	863-21771-00	10- 2
J10-W4631-00	22-33	127-14195-00	7- 7	J10-21773-00	15- 5
J10-W4641-00	22-37	620-14211-00	7- 9		15- 9
J10-W4642-02	22-38	620-14212-00	7-10	J10-21776-00	10- 6
J16-W7811-00	25- 1	732-14237-00	7-12	J10-22123-00	11- 2
J10-11111-00	1- 1	J10-14243-00	7- 3	J10-2219X-00	11-15
J10-11181-00	1- 2	J10-14244-00	7-11	J10-22210-00	11- 5
J10-11311-00	1- 4	J10-14377-00	7-19	J10-22501-01	12- 1
881-11351-01	1- 5	J10-1441F-00	6-27	J11-22567-00	12-10
J10-11400-00	2- 6	J10-14410-00	6-19	J11-22568-00	12-11
J10-11412-00	2- 7	J10-14411-00	6-20	J10-23350-00	13-24
J10-11422-00	2- 8	J10-14416-00	6-24	J10-23444-00	14- 7
J10-11610-00	2- 2	J10-14417-00	6-29	J10-23459-00	14-11
J10-11610-10	2- 2	J10-14436-00	6-30	J10-23462-00	14- 9
J10-11610-20	2- 2	J10-14450-10	6-26	J10-23510-02	13- 4
J10-11631-00-96	2- 1	J10-14453-00	6-16	J10-23516-02	13-13
J10-11631-00-98	2- 1	J10-14581-00	7- 4	J10-23520-02	13-10
818-11633-00	2- 3	J10-14610-01	8- 7	J10-23526-00	13- 3
J10-11635-00	2- 1	J10-14612-01	8- 1		13- 9
J10-11636-00	2- 1	J10-14613-00	8- 3	J10-23583-00	13-19
881-11651-00	2-12	888-14633-00	8- 2	J10-23811-00-9E	14-18
8F3-11681-00	2- 9	J10-14715-00	8- 8	J10-23814-00	14-17
8G8-12611-01	3-12	J10-14802-00	8-26	J10-23816-02	14- 1
J10-12621-01	3-16	J10-14812-02	8-11	J10-23818-00	14- 8
J10-12631-00	3- 9	J10-14813-01	8-10	J10-23826-00	14-21
J10-12644-00	6-25	J10-14815-00	8-14	J10-23831-00	14-22
J10-12651-00	3- 1	J10-14818-00	8-15		14-27
J10-12652-00	3- 2	J10-14833-00	8-17	J10-23836-09	14- 2
J10-13101-01	4- 1		8-22	J10-23838-00	14-20
137-13148-00	5- 8		19-21	J10-23840-00	14-19
J10-13175-00	5- 4	J10-14836-00	8-16	J10-23841-10	14-23
137-13176-00	5- 3		19-20		14-28
J10-13188-00	5- 5	J10-14837-00	8-21	J10-23845-10	14-24
J10-13283-00	4-13	J10-14864-00	8-19		14-29
859-13410-00	4- 7		8-24	J10-23876-00	14- 4
J10-13586-00	6- 6		19-23	J10-23877-00	14- 6
885-13610-00	6- 1	256-14944-20	7-18	J10-24111-00	15- 1
1L8-13613-00	6- 2	8H4-15100-00	9- 1	J10-24173-00	15-32
885-13616-01	6- 3	J10-15416-00	5- 1	J10-24311-00	15- 6
311-13621-01	6- 5	J10-15426-00	5-11	J10-24312-00	15-11
J10-14100-02	7- 1	J10-15466-00	5-10	J10-24313-00	15-18
J10-14122-00	7- 8	801-17688-10	21- 5	810-24357-00	10- 5
			21- 7		

NUMERICAL INDEX

PART NO.	REF. NO.	PART NO.	REF. NO.	PART NO.	REF. NO.
810-24357-00	15-12	J10-27290-01	17-13	J11-77271-00	28-24
	15-14	J10-27852-00	18-10	J11-77272-00	28-25
	15-24	J10-27853-02	18- 2	J10-77277-00	11-16
J10-24366-00	15-16	J10-27871-01	18- 5	J10-77278-00	11-17
J10-24410-02	15-25	J10-27872-01	18- 3	J10-77711-00	25-42
J10-24461-00	15- 4	J10-27874-01	18- 1	J10-77741-00	25-44
8E4-24461-00	22-14	J10-27911-00	19- 4	J10-77762-00	27-32
812-24461-00	9- 3	J10-27912-00	19- 1	J10-77764-00	25-13
809-24560-01	15-13	J10-27913-00	19- 3	J10-77765-00	26-35
J10-24611-00	15- 2	J10-27921-00	19- 8	J10-77766-00	26-16
J10-24612-00	15- 3	J10-27922-00	19- 9	J11-77767-00	34- 7
J11-25100-00	13-34	J10-27927-00	19- 5	J10-77768-00	25-41
J11-25102-00	13-35	J10-27951-01	19-14	J11-78103-00	34- 8
	23- 2	J10-27959-00	19-18	J10-78106-03-93	24- 1
J10-25118-00	13-28	J10-27981-00	18-23	J10-78107-03-93	24-16
787-25170-00	13-37	J10-46210-00	20- 1	J16-78115-00	25-22
	23- 4	J10-46220-01	20- 5	J16-78117-00	25-25
J11-25300-00	23- 1	J10-46223-01	20- 6	J10-78118-01	25-27
J10-25330-00	17- 9	J10-46230-00	20- 7	J10-78119-00	25- 2
		J10-46232-00	20- 8	J10-78121-00	25- 4
J10-25654-00	16- 6	J10-46236-00	20- 9	J10-78122-00	24-36
J10-25670-00	16-10	J10-46241-02	20-20	J10-78137-00	25-10
J10-25679-00	16-20	J10-46244-00	20- 4	J10-78139-00	27-21
J10-25681-00	16-23	J10-46249-00	20-18	J16-78147-00	25-33
J10-25685-00	16-24	J10-46253-01	20-12	J10-78156-00	26-25
J10-26311-02	18-17	J10-46260-00	21- 1	J10-78157-00	27-14
J10-26325-00	6-12	J10-46284-00	21- 6	J10-78162-01	24- 3
J10-26331-01	6-11	J10-46311-00	22- 1		24-18
J10-26341-00	16-30	J10-46312-00	22- 9	J10-78164-01	24- 6
J10-26351-01	16-31	J10-46319-00	22-19	J10-78167-01	24- 2
J10-27207-00	17- 3	J10-46321-00	22-30		24-17
	17-15	J10-46331-02	22-31	J10-78168-01	24- 5
J10-27208-01	17- 2	J10-46361-02	22-34		24-20
J10-27209-01	17-14	J10-46362-02	22-35	J10-78174-01	24-21
J10-27211-00	16- 3	J10-46414-00	22-39	J10-78179-00	24-24
J10-27245-00	16- 2	J10-46415-00	22-40	J10-78181-00	12- 8
J10-27250-00	16- 1	J10-46510-02	23-11	J10-78182-00	12- 9
J10-27270-00	17- 5	J10-46521-00	23-12	J10-78187-00	12- 5
	17-17	J10-46540-00	23- 6	J10-78191-01	26-34
J10-27280-01	17- 1	835-47559-00	22-23	J10-78192-02	26-43
J10-27281-00	17-12	J10-77125-00	26-15	J10-78197-00	26-36
	17-24	J10-77145-00	26- 1		26-44
J10-27282-00	17-11	J10-77146-00	26- 3	J11-78198-00	34- 9
	17-23	J10-77151-01	25-37	J11-78199-00	34-10
J10-27285-00	17- 8	J10-77152-01	25-38	J10-78231-02	26-27
	17-20	J10-77165-01	25-23	J10-78232-00	25-29
J10-27286-00	17- 4	J10-77188-00	26-20	J10-78233-00	25-31
	17-16	J10-77197-00	26-36	J10-78234-00	26-28
				J10-78235-00	26-31

NUMERICAL INDEX

PART NO.	REF. NO.	PART NO.	REF. NO.	PART NO.	REF. NO.
J10-78238-01	25-14	J10-81100-10	30- 1	J10-82550-03	33-20
J10-78239-00	25-17	J10-81110-10	30- 7	J10-82590-21	33-23
J10-78241-00	26-33	J10-81111-10	30-21	366-82591-00	33-24
J10-78245-00	25-43	J10-81113-10	30-22	J10-83383-02	33-26
J10-78246-00	12-18	J10-81115-10	30-23	256-83936-00	33-25
J10-78247-00	12-19	J10-81119-10	30-20	J10-85500-20	32- 1
J10-78248-00	12-20	J10-81129-10	30-30	8G8-85511-20	32- 2
J10-78249-00	12- 3	J10-81139-10	30-31	J10-85515-20	32- 4
J10-78271-02	26-30	J10-81145-10	30-32	J10-85540-20	32-15
J10-78272-00-9E	25-12	J10-81146-10	30-13	2A7-85546-00	32-16
J11-78286-00	34- 2	J10-81147-10	30-16	J10-85550-20	32-12
J11-78287-00	34- 1	J10-81148-10	30- 9	J10-85580-20	32- 3
J10-78291-00	25-36	J10-81150-10	30- 2	J10-85710-01	15-10
J10-78292-00	27-31	J10-81157-10	30- 3	J10-87172-00	31- 5
J11-78301-00	28- 6	J10-81158-10	30- 4	J10-87183-00	31- 1
J11-78310-00	28- 1	J10-81159-10	30- 5	90101-06422	18- 8
J11-78311-00	28- 7	J10-81160-10	30- 8	90101-08125	13-20
J11-78312-00	28-15	J10-81161-00	31- 4	90101-08420	31-10
J11-78313-00	28-16	J10-81163-10	30-26	90101-10418	13-16
J11-78314-00	28- 2	J10-81165-10	30-14	90101-10419	11- 3
J11-78316-00	28- 8	J10-81166-10	30-15	90101-10447	16- 7
J10-78318-00	25- 8	J10-81170-00	31-16	90105-10007	13-22
J11-78328-00	28-22	J10-81173-00	31- 9	90106-10034	11- 9
J11-78329-00	28-19	J10-81175-10	30- 6	90109-08506	16-16
J11-78335-01	28- 9	104-81328-20	32- 5	90116-08254	1- 6
J11-78338-00	28-27	J10-81910-10	32-17	90149-03130	8-12
J11-78343-00	28-20	J10-81916-00	32-33	90149-03132	6-13
J11-78344-00	28-26	J10-81923-00	32-35	90149-04128	4- 2
J10-78351-00-9E	27- 1	J10-81924-01	32-26	90149-05129	20-13
J10-78352-00-9E	27- 2	J10-81925-00	32-34	90157-03022	7-20
J10-78353-00-9E	27- 3	J10-81940-01	32-21	90170-05190	8-20
J10-78355-00	27- 9	J10-81945-00	32-27		8-25
J10-78356-00	27- 8	J10-81949-00	32-38	90206-11016	19-24
J10-78357-01	27-27	J10-81951-00	32-28	90170-08024	14-12
J10-78358-00	27-28	J10-82105-00	33- 3	90170-10047	11-14
J10-78359-00	25-35	J11-82110-70	33- 9	90170-12054	14-25
J10-78361-00-93	29- 2	J10-82115-00	33- 1		14-30
J10-78362-00-93	29-14	J10-82116-00	33- 2	90170-12055	14-26
J10-78366-01	27-26	J10-82117-00	33- 4		14-31
J10-78367-00	27-10	J10-82133-00	33-10	90170-16182	2-19
J10-78368-00	27-15	J10-82136-00	33-11	90179-08261	16-28
J10-78369-01	27-16	J14-82150-00	33- 7	90179-08263	16-19
J10-78401-02	29- 1	1E6-82150-00	33- 5	90179-08278	1- 7
		1E6-82151-00	33- 6	90179-12262	13-38
J10-78403-02	29-13		33- 8		23- 5
		8H4-82310-20	33-14	90185-12061	14-37
J10-78439-00	29-11	8G8-82318-00	33-17	90201-04M06	25-21
	29-23	512-82370-10	33-18	90201-04756	3-11
		J10-82508-20	33-19		

NUMERICAL INDEX

PART NO.	REF. NO.	PART NO.	REF. NO.	PART NO.	REF. NO.
90201-04756	24-10	90267-40054	34-12	90465-08028	33-22
	24-30	90267-40075	25-11	90465-10129	3- 6
90201-05029	25-47	90267-40077	24- 4	90467-08017	15-29
90201-05034	12- 7		24-19	90467-09005	4-11
		90267-48040	3-10	90467-09006	15-31
			12- 4	90467-09026	4-12
		90267-63047	25-24	90467-10035	4-15
90201-06043	32-14		25-30	90468-04092	15- 7
90201-06075	25-49		25-32	90468-05112	8-33
90201-06557	3- 8		26-29	90468-10049	6-15
	6-32		26-32	90468-12007	26-24
	28- 4	90280-05013	2-18	90468-16065	26-19
90201-06697	26- 9	90280-05022	21- 8	90480-06240	26- 2
90201-08083	25-15	90338-06018	28-23	90480-07241	25-48
90201-08107	15-33	90338-09094	34-15	90480-12071	26-39
	27- 5	90340-14029	14-39		26-47
	31-18	90340-14036	22-20	90480-13238	6-21
	31-23	90381-15032	13- 2	90480-14100	6-28
90201-08310	25-50		13- 8	90480-14239	6-22
	28-13	90384-14080	18-12	90480-35242	25-19
	29-10	90384-20143	21- 2	90480-42282	29-12
	29-22	90385-08034	19-15	90480-48243	25-45
90201-08766	24-13	90387-06026	6-33	90501-08256	34- 5
90201-142E5	13-32	90387-08687	31-15	90501-08430	4-10
90201-20272	22-36	90387-10684	16- 5	90501-08486	15-15
90201-20275	19- 7	90387-21690	19- 2	90501-32557	20-14
90202-06008	28- 5	90387-375A1	24-37	90501-45600	21- 9
90202-08085	26- 8	90387-47686	20- 3	90502-10013	27-29
90202-08110	19-11	90430-04004	4- 3	90506-06201	8-32
90202-08111	12- 2	90430-08119	14-10	90506-20074	8- 6
90206-06060	26-22	90430-14043	14-42	90506-23204	28-28
90206-08051	26-18		22-21	90506-26191	17-10
90206-11016	5- 7	90430-31003	10- 3		17-22
90209-24073	2-10	90445-09069	15-28	90506-29187	18-16
90215-13146	20-17	90445-09108	4- 8	90508-10382	27-17
90215-16161	14-36	90445-09113	4- 9	90508-16460	18-21
90249-05136	28-10	90445-10449	15-30	90508-20383	16-15
90249-14129	16-27	90445-11151	15-23	90508-40384	16- 4
90267-32019	25-18	90445-11288	15-17	90508-40398	19-16
90267-40M00	25-26	90445-11391	4-14	90560-05001	18-22
	25-34	90460-41145	6-17	90560-12180	20-16
90267-40038	25- 3	90460-41146	6-10	91401-16010	18-19
	25- 9	90460-50035	6-18	91401-20012	34- 6
	25-20	90461-10054	15-19	91401-25015	26- 5
90267-40054	12- 6	90464-07034	8-27	91401-30025	21-12
	25-28	90465-06011	22-22	91402-30025	13-14
	26-37	90465-06038	33-16		13-33
	26-45	90465-08028	3- 7		14-34
			22-27		



NUMERICAL INDEX

PART NO.	REF. NO.	PART NO.	REF. NO.	PART NO.	REF. NO.
97322-08016	24-22	90890-90067-00	35- 6		
97322-08020	24-31	90890-90105-10	35-10		
	26-12				
97322-08025	8- 4				
	23- 7				
	24-11				
97322-08035	5-16				
97322-10020	22-24				
	23- 9				
97602-03108	6- 4				
	7- 2				
97701-50130	25-46				
97701-60116	28- 3				
97702-50125	27-30				
98501-04008	19-10				
	32-10				
98501-04020	32- 8				
98501-05008	31- 2				
98501-05016	30-24				
98501-05018	30-29				
98501-05020	20-10				
	32- 6				
	32-37				
98502-05012	15-20				
98503-04010	30-25				
98702-05035	26-26				
98901-06014	32-13				
98901-06016	25- 5				
98902-05018	4- 5				
98902-08016	12-12				
98902-08020	25-51				
98903-06016	27-11				
98903-06020	26- 6				
98903-06025	26- 7				
SPECIAL TOOLS					
ACC-11401-01-00	35- 5				
ACC-11401-02-00	35-15				
ACC-11401-03-00	35-18				
90890-01051-00	35- 2				
90890-01135-00	35- 1				
90890-01202-00	35- 7				
90890-01235-00	35- 3				
90890-01876-00	35-11				
90890-01886-00	35-19				
90890-02202-00	35-17				
90890-02203-00	35-14				
90890-02204-00	35-13				
90890-02213-00	35-16				
90890-02300-00	35-12				
90890-90058-00	35- 4				
90890-90059-00	35- 8				
90890-90060-00	35- 9				

## PARTS NAME INDEX

DESCRIPTION	REF. NO.
ADJUSTER ASSY	17- 5
*	17-17
AIR CLEANER ASSY	6-19
AIR SHROUD, cylinder 1	3- 1
AIR SHROUD, cylinder 2	3- 2
AIR VALVE ASSY	13-37
*	23- 4
ARM REST 1	29- 2
ARM REST 2	29-14
ARM, accelerator Pedal	18- 3
ARM, idler	14-21
ARM, Pitman	14- 1
ARMATURE ASSY	30- 2
ASH TRAY	34- 1
BACKING PLATE ASSY 1	17- 1
BACKING PLATE ASSY 2	17-13
BACKING PLATE SUB ASSY 1	17- 2
BACKING PLATE SUB ASSY 2	17-14
BAND	27- 9
*	32-16
*	33-24
BAND, muffler	8- 8
BAND, switch cord	33-25
BAND, tank fitting	10- 6
BAND, tank fitting 1	15-32
BAR, short	32-26
BASE, lock	27-14
BATTERY ASSY	33- 9
BEARING	14- 5
*	14-16
*	19- 6
BEARING (B6004R5)	13-29
BEARING (B6008)	22- 4
*	22-12
BEARING (B6203)	13-30
*	22-10
BEARING (B6204)	22- 3
*	22-11
BEARING (B6205)	22- 2
BEARING (B6206)	2-14
BEARING (B6306)	2-13
BEARING (B6906)	20- 2
BEARING 1 (6202 SD)	30- 3
BEARING 2 (6203 SD)	30- 4
BEARING, cylindrical	2- 5
*	2-11
BELT	20-20
*	31- 9

## PARTS NAME INDEX

DESCRIPTION	REF. NO.
BODY, caP	10- 2
*	15- 2
BODY, float chamber 1	7-13
BOLT	3- 5
*	3-13
*	3-17
*	5-16
*	5-20
*	6- 7
*	6-31
*	8- 4
*	11- 3
*	11- 6
*	11- 9
*	12-15
*	13- 5
*	13-11
*	13-16
*	13-20
*	13-25
*	14- 4
*	14-11
*	14-14
*	14-40
*	16- 7
*	16-11
*	16-16
*	16-21
*	17-25
*	18- 6
*	18- 8
*	18-14
*	20-18
*	22-24
*	22-41
*	23- 7
*	23- 9
*	24- 7
*	24-11
*	24-22
*	24-25
*	24-31
*	25-53
*	26-12
*	26-40
*	26-48
*	27-24
*	28-17

## PARTS NAME INDEX

DESCRIPTION	REF. NO.
BOLT	29- 3
*	29- 8
*	29-15
*	29-20
*	31-10
*	31-17
*	31-21
*	33-27
BOLT, flange	5-19
BOLT, stud	1- 6
*	22- 7
*	22- 8
BOLT, washer based	13-22
BRACKET	7- 4
BRACKET, accelerator Pedal	18- 1
BRACKET, engine 1	11- 8
BRACKET, Pedal	16- 6
BRACKET, starter Generator 1	30-14
BRACKET, starter Generator 2	30-15
BRACKET, throttle	18-23
BRAKE ARM COMP.	16- 1
BRAKE LEVER COMP.	17- 3
*	17-15
BRAKE SHOE COMP.	17- 9
*	17-21
BREATHER	15- 8
BRUSH	30-21
BRUSH HOLDER ASSY	30-20
BUMPER SUB-ASSY, front	24- 1
BUMPER SUB-ASSY, rear	24-16
BUMPER, rubber 1	24- 2
*	24-17
BUMPER, rubber 2	24- 5
*	24-20
BUSH	13- 3
*	13- 9
*	13-19
*	19-15
BUSH 1	11- 2
BUSH, bimetal formed	18-12
*	21- 2
BUSH, solid	13- 2
*	13- 8
BUZZER	33-26
C.D.I. MAGNETO ASSY	32- 1
C.D.I. UNIT ASSY	32-15
CABLE, brake	16-30
*	16-31
CABLE, starter 1	6-11

## PARTS NAME INDEX

DESCRIPTION	REF. NO.
CABLE, throttle 1	18-17
CAM	20- 6
CAP	17- 8
*	17-20
CAP 2	22-23
CAP, cleaner case 1	6-23
CAP, end	27-21
CARBURETOR ASSY	7- 1
CASE, air cleaner 1	6-20
CASE, differential	22-37
CASE, fan	3-16
CASE, transmission 1	22- 1
CASE, transmission 2	22- 9
CIRCLIP	2- 4
*	2-16
*	5- 9
*	8-13
*	8-31
*	16-32
*	18-20
*	19-12
*	20-15
*	22-32
*	25-16
*	27-18
*	28-11
CLAMP	3- 6
*	3- 7
*	8-27
*	15-19
*	22-22
*	22-27
*	32- 5
*	33-16
*	33-22
CLAMP, fuel Pipe 1	15-16
CLAMP, hose	6-10
*	6-17
*	6-18
CLAMP, support	27-26
CLIP	4-11
*	4-12
*	4-15
*	6-15
*	8-33
*	15- 7
*	15-29
*	15-31

## PARTS NAME INDEX

DESCRIPTION	REF. NO.
CLIP	26-19
*	26-24
CLIP, Pipe 2	10- 5
*	15-12
*	15-14
*	15-24
COIL, Pulser	32- 3
COIL, source	32- 2
COLLAR	6-33
*	16- 5
*	19- 2
*	20- 3
*	24-37
*	31-11
*	31-15
COLUMN, steering	14-18
CONNECTER COMP.	8-26
CONNECTER, rod	8-21
COVER	11-15
COVER 1	5- 1
*	6-29
COVER 2	5-11
COVER, brush	30-30
COVER, brush 2	30-31
COVER, dust	17- 4
*	17-16
COVER, fuel inlet	25-12
COVER, gasket	8-15
COVER, hub dust	13-28
COVER, steering	14- 8
COVER, sun roof	28- 2
COVER, terminal	32-33
COWL, front	25-22
CRANK 1	2- 7
CRANK 2	2- 8
CRANKCASE ASSY	9- 1
CRANKSHAFT ASSY	2- 6
CUP 1	18-10
CYLINDER 1	1- 4
DAMPER	16-20
*	28- 8
DAMPER 2	11-12
DAMPER, noise 11	28-24
DAMPER, noise 12	28-25
DAMPER, noise 17	11-16
DAMPER, noise 18	11-17
DEFLECTOR 1	3- 9
DEFLECTOR 3	6-24
DRUM	23-12

## PARTS NAME INDEX

DESCRIPTION	REF. NO.
ELEMENT ASSY, air cleaner	6-26
EMBLEM 1	25-36
EMBLEM 2	27-31
EQUALIZER, brake	16-23
EXHAUST PIPE ASSY 1	8- 7
FAN	3-12
FAN, Generator	31- 5
FASTENER, lower	25-17
FASTENER, upper	25-14
FIELD COIL ASSY	30- 8
FILTER ASSY	15-13
FLAP COMP.	34- 8
FLAP, front fender	12- 5
FLAP, rear fender	26-36
*	26-44
FLAP, rear 2	34-10
FLOAT	7- 5
FORK, Governor	19- 9
FRAME COMP.	12- 1
FRAME COMP., roof	28- 6
FRAME, sun roof	28- 7
FRONT LOWER ARM COMP.(L,H)	13- 1
FRONT LOWER ARM COMP.(R,H)	13- 7
FRONT WHEEL ASSY	13-34
FUEL LEVEL GAUGE ASSY	15-10
FUEL PUMP ASSY	15-25
FUSE (6V-10A)	33- 6
*	33- 8
FUSE HOLDER ASSY	33- 5
*	33- 7
GASKET	4- 3
*	7-12
*	8-14
*	10- 3
*	14-10
*	14-42
*	22-19
*	22-21
GASKET 2	5-10
GASKET, air cleaner	6-25
GASKET, cap	15- 3
GASKET, cylinder	1- 5
GASKET, cylinder head 1	1- 2
GASKET, exhaust Pipe	8- 3
GASKET, float chamber	7-14
GASKET, valve seat	6- 5
GEAR, counter 1	22-34
GEAR, counter 2	22-35
GEAR, differential side	22-39
GEAR, drive	5- 5

## PARTS NAME INDEX

DESCRIPTION	REF. NO.
GEAR, inPut 1	22-31
GEAR, rinG	22-38
GROMMET	6-21
*	6-22
*	6-28
*	15- 5
*	15- 9
*	25-19
*	25-45
*	25-48
*	26- 2
*	26-39
*	26-47
*	29-12
HEAD, cylinder 1	1- 1
HINGE 1	26- 1
HINGE 2	26- 3
HOLDER	19- 4
HOLDER 1	27-27
HOLDER 2	27-28
HOLDER 3	25-35
HOLDER, bearing	30- 5
HOLDER, handle upper	14-17
HOLDER, nozzle	7-11
HOOK	6-30
HOOK, end 1	25- 8
HOSE	4- 8
*	4- 9
*	4-14
*	15-17
*	15-23
*	15-28
*	15-30
HUB, front	13-27
IGNITION COIL ASSY	33-14
INDICATOR 1	25-44
INSULATOR, generator	31- 1
JET, main (#100.0)	7-18
JET, Pilot (#45.0)	7-16
JET, senser	4-13
JOINT	8-17
*	8-19
*	8-22
*	8-24
*	19-21
*	19-23
JOINT, air cleaner 1	6-16
JOINT, carburetor 1	6- 6

## PARTS NAME INDEX

DESCRIPTION	REF. NO.
JOINT, universal 1	14-23
*	14-28
JOINT, universal 2	14-24
*	14-29
KEY	30-26
KEY, woodruff	2-18
*	21- 8
KING PIN, steering knuckle	13-13
KNOB, starter	6-12
KNUCKLE, steering comp.	13- 4
LABEL, warning	25-41
LABEL, warning 2	27-32
LABEL, warning 4	25-13
LABEL, warning 5	26-35
LABEL, warning 6	26-16
LABEL, warning 7	34- 7
LEAD WIRE ASSY	32- 4
LEVER, lock	27-15
LEVER, speed limiter	19-14
LID, ash tray	34- 2
LIFTER	19- 5
LOCK, side wind	28- 9
MAIN SWITCH ASSY	33-19
MAT, main floor 1	26-27
MAT, main floor 2	25-29
MAT, main floor 3	25-31
MAT, main floor 4	26-28
MAT, rear floor	26-33
METAL, worm shaft outer	5- 3
NEEDLE VALVE ASSY	7-17
NOZZLE, main	7-15
NUT	1- 7
*	2-19
*	8-18
*	8-20
*	8-23
*	8-25
*	8-30
*	11-14
*	12-14
*	13- 6
*	13-12
*	13-31
*	13-38
*	14- 6
*	14-12
*	14-25
*	14-26

## PARTS NAME INDEX

DESCRIPTION	REF. NO.
NUT	14-30
*	14-31
*	16-14
*	16-19
*	16-28
*	16-29
*	17- 7
*	17-19
*	18- 9
*	19-17
*	19-19
*	19-22
*	19-24
*	22-18
*	23- 5
*	24-15
*	24-35
*	25- 7
*	26-11
*	27-23
*	30-10
*	30-17
*	30-27
*	31-14
*	31-20
*	32-23
*	32-24
*	32-29
*	32-31
*	33-12
*	33-21
*	33-28
NUT, crown	24-29
*	27- 7
*	27-13
NUT, nylon	13-15
*	13-23
*	14-35
*	25-39
*	32-39
NUT, rinG	8- 1
NUT, self-locking	14-37
NUT, slotted	14-32
*	21-11
NUT, u	8- 9
*	11- 4
*	11- 7
*	12-17

## PARTS NAME INDEX

DESCRIPTION	REF. NO.
NUT, u	13-17
*	13-21
*	13-26
*	15-34
*	16- 8
*	28-14
*	28-18
*	28-21
*	34-14
O-RING	4- 4
*	18-13
*	20-19
OIL PUMP ASSY	4- 1
OIL SEAL	2-15
*	2-17
*	5- 2
*	5-12
*	14- 3
*	14-13
*	19-13
*	21- 4
*	22- 5
*	22- 6
*	22-13
PAD 1	25-37
PAD 2	25-38
PAD, baG support	27- 8
PAD, brake Pedal	16- 2
PAD, front bumper	24- 3
*	24-18
PANEL, body shell	25- 1
PANEL, instrument	25-42
PANEL, rear fender 1	26-34
PANEL, rear fender 2	26-43
PARKING PEDAL COMP.	16-10
PARTITION, air cleaner case	6-27
PEDAL, accelerator	18- 5
PEDAL, brake	16- 3
PIN	16-27
*	28-10
PIN, clevis	6-14
*	16-25
*	16-33
*	18-18
*	26- 4
*	26-17
*	26-21
*	34- 3

## PARTS NAME INDEX

DESCRIPTION	REF. NO.
PIN, cotter	13-14
*	13-33
*	14-34
*	16-26
*	16-34
*	18-19
*	21-12
*	26- 5
*	34- 6
PIN, crank 1	2- 9
PIN, dowel	5- 6
*	5-13
*	9- 2
*	22-15
*	22-43
PIN, float	7- 6
PIN, lever	27-16
PIN, piston	2- 3
PIN, Pitman	14- 2
PIN, shoe hold down	17-11
*	17-23
PIN, spring	18- 4
*	18-11
PIN, weight	20- 9
PINION, differential	22-40
PIPE 2	15-11
PIPE 3	15-18
PIPE, fuel 1	15- 6
PIPE, joint	9- 3
*	15- 4
*	22-14
PIPE, oil tank breather	10- 4
PISTON (STD)	2- 1
*	2- 1
PISTON (1ST O/S 0.25MM)	2- 1
PISTON (2ND O/S 0.50MM)	2- 1
PISTON RING SET (STD)	2- 2
PISTON RING SET (1ST O/S)	2- 2
PISTON RING SET (2ND O/S)	2- 2
PLATE	7- 3
PLATE 1	12- 8
*	25-25
PLATE 2	12- 9
*	25-27
PLATE 3	25- 2
PLATE 4	25-10
PLATE 5	25-33
PLATE, anchor	27-10

## PARTS NAME INDEX

DESCRIPTION	REF. NO.
PLATE, battery fitting	33-11
PLATE, cam thrust	5- 8
PLATE, extension	24-24
PLATE, switch fitting	32-27
PLUG	28-23
*	34-15
PLUG CAP ASSY	33-18
PLUG, spark (CHAMPION L89CM)	1- 3
PLUG, straight screw	14-39
*	22-20
PRIMARY FIXED SHEAVE COMP.	20- 1
PRIMARY SHEAVE CAP COMP.	20- 7
PRIMARY SLIDING SHEAVE COMP.	20- 5
PULLEY	31- 4
REAR ARM COMP.	11- 1
REAR AXLE HOUSING COMP.	23- 6
REAR AXLE SHAFT COMP.	23-11
REAR WHEEL ASSY	23- 1
REED VALVE ASSY	6- 1
REED, valve	6- 2
REINFORCEMENT 1	25- 4
REINFORCEMENT 2	24-36
RELAY	32-28
RETAINER	19- 1
*	28-20
RETAINER 2	28-26
RETAINER, flap	34- 9
RING	8- 2
RIVET 3	26-36
RIVET, blind	3-10
*	12- 4
*	12- 6
*	24- 4
*	24-19
*	25- 3
*	25- 9
*	25-11
*	25-18
*	25-20
*	25-24
*	25-26
*	25-28
*	25-30
*	25-32
*	25-34
*	26-29
*	26-32
*	26-37

## PARTS NAME INDEX

## PARTS NAME INDEX

## PARTS NAME INDEX

DESCRIPTION	REF. NO.
RIVET, blind	26-45
*	34-12
RDD	8-16
*	16-24
*	19-20
RDD, connecting	2-12
RDD, tension	13-18
RDD, tie	14-22
*	14-27
ROTOR ASSY	32-12
SCREW	4- 2
*	6-13
*	8-12
*	20-13
SCREW 1	30-32
SCREW 2	30-13
SCREW 3	30-16
SCREW 4	30- 9
SCREW, adjusting	19-18
SCREW, bind	4- 5
*	12-12
*	25- 5
*	25-51
*	26- 6
*	26- 7
*	27-11
*	32-13
SCREW, fitting	33-10
SCREW, flat head	26-26
*	27- 4
SCREW, oval head	28-12
*	29- 6
*	29-18
SCREW, Pan head	3- 3
*	5-14
*	5-15
*	7-20
*	9- 4
*	9- 5
*	9- 6
*	10- 7
*	15-20
*	15-26
*	19-10
*	20-10
*	22-28
*	27-19
*	30-24

DESCRIPTION	REF. NO.
SCREW, Pan head	30-25
*	30-29
*	31- 2
*	31- 6
*	32- 6
*	32- 8
*	32-10
*	32-18
*	32-37
*	33-15
*	34-13
SCREW, Pan head with washer	6- 4
*	7- 2
SCREW, Pilot adjusting	7- 9
SCREW, tapping	25-46
*	27-30
*	28- 3
SCREW, throttle	7- 8
SEAL 1	25-43
SEAL 3	12-19
SEAL 4	12-20
SEAL, floor 2	12-18
SEAL, steering	14- 9
SEAT SUB-ASSY, cushion 2	29-13
SEAT SUB-ASSY, cushion	29- 1
SEAT, secondary spring	21- 6
SEAT, spring	20- 4
SECONDARY FIXED SHEAVE COMP.	21- 1
SECONDARY SLIDING SHEAVE COMP.	21- 3
SERVICE LID, Pedal	26-30
SHAFT, butterfly	8-10
SHAFT, counter	22-33
SHAFT, governor	19- 8
SHAFT, input	22-30
SHAFT, Pedal 1	18- 2
SHAFT, worm	5- 4
SHEET, main floor	26-31
SHOCK ABSORBER ASSY	13-24
SHOCK ABSORBER ASSY, rear	11- 5
SHDE, ramp	21- 5
*	21- 7
SLIDER	20-12
SPACER	18-22
*	20-16
SPACER 1	28-22
SPACER 2	28-19

DESCRIPTION	REF. NO.
SPACER 3	28-27
SPRING, brush	30-22
SPRING, compression	4-10
*	15-15
*	20-14
*	21- 9
*	34- 5
SPRING, conical	27-29
SPRING, Pilot adjusting	7-10
SPRING, shoe clamp	17-12
*	17-24
SPRING, tension	8- 6
*	8-32
*	17-10
*	17-22
*	18-16
*	28-28
SPRING, torsion	16- 4
*	16-15
*	18-21
*	19-16
*	27-17
STARTER GENERATOR ASSY	30- 1
STARTER SWITCH ASSY	32-21
STATOR ASSY	30- 7
STAY 1	26-15
STAY, front bumper 1	24- 6
STAY, rear bumper	24-2f
STEERING KNUCKLE COMP.	13-10
STEERING SHAFT ASSY	14-19
STOP SWITCH ASSY	33-20
STOPPER	7-19
*	26-20
STOPPER 1	30- 6
STOPPER, lock	26-25
STOPPER, reed valve	6- 3
STRAINER HOUSING ASSY	4- 7
SUN ROOF ASSY	28- 1
SUPPORT 1	12-10
SUPPORT 2	12-11
SUPPORT, bag lower 1	27- 2
SUPPORT, bag lower 2	27- 3
SUPPORT, bag upper	27- 1
SUPPORT, sun roof 1	28-15
SUPPORT, sun roof 2	28-16
TANK, fuel	15- 1
TANK, oil	10- 1

## PARTS NAME INDEX

DESCRIPTION	REF. NO.
TENSIONER ASSY .....	31-16
TERMINAL .....	32-34
TIRE .....	13-36
*	23- 3
TRIM 1 .....	25-23
TRIM, floor .....	12- 3
VALVE, butterfly .....	8-11
VOLTAGE REGULATOR ASSY .....	32-17
WASHER .....	2-10
*	2-20
*	3- 4
*	3-15
*	3-18
*	5-22
*	4- 6
*	6- 9
*	10- 9
*	14- 7
*	14-38
*	16-12
*	16-17
*	21-10
*	24-27
*	24-33
*	25-40
*	26-23
*	26-42
*	26-50
*	31- 8
*	31-12
*	32-20
*	32-35
*	33-13
WASHER, lock .....	14-36
*	20-17
WASHER, needle valve .....	7- 7
WASHER, Plate .....	3- 8
*	3-11
*	5-18
*	6-32
*	8-28
*	11-11
*	12- 2
*	12- 7
*	12-16
*	13-32
*	14-33
*	15-22

## PARTS NAME INDEX

DESCRIPTION	REF. NO.
WASHER, Plate .....	15-33
*	19- 7
*	19-11
*	22-16
*	22-26
*	22-36
*	24- 9
*	24-10
*	24-12
*	24-13
*	24-26
*	24-30
*	24-32
*	25-15
*	25-21
*	25-47
*	25-49
*	25-50
*	26- 8
*	26- 9
*	26-14
*	26-38
*	26-46
*	27- 5
*	27-33
*	28- 4
*	28- 5
*	28-13
*	29- 5
*	29-10
*	29-17
*	29-22
*	30-11
*	30-18
*	30-33
*	31-18
*	31-23
*	32-14
*	34- 4
*	34-11
WASHER, seat .....	29-11
*	29-23
WASHER, sPring .....	3-14
*	5-17
*	5-21
*	6- 8
*	8- 5

## PARTS NAME INDEX

DESCRIPTION	REF. NO.
WASHER, sPring .....	8-29
*	10- 8
*	11-10
*	11-13
*	12-13
*	14-15
*	14-41
*	15-21
*	15-27
*	16- 9
*	16-13
*	16-18
*	16-22
*	17- 6
*	17-18
*	17-26
*	18- 7
*	18-15
*	20-11
*	22-17
*	22-25
*	22-29
*	22-42
*	23- 8
*	23-10
*	24- 8
*	24-14
*	24-23
*	24-28
*	24-34
*	25- 6
*	25-52
*	25-54
*	26-10
*	26-13
*	26-41
*	26-49
*	27- 6
*	27-12
*	27-20
*	27-22
*	27-25
*	29- 4
*	29- 9
*	29-16
*	29-21
*	30-12
*	30-19

## PARTS NAME INDEX

## PARTS NAME INDEX

DESCRIPTION	REF. NO.
WASHER, sPring	30-28
*	30-34
*	30-35
*	30-36
*	31- 3
*	31- 7
*	31-13
*	31-19
*	31-22
*	32- 7
*	32- 9
*	32-11
*	32-19
*	32-22
*	32-25
*	32-30
*	32-32
*	32-36
*	33-29
WASHER, tooth	29- 7
*	29-19
WASHER, wave	5- 7
*	26-18
*	26-22
WEIGHT	19- 3
WEIGHT 1	20- 8
WHEEL RIM ASSY, front	13-35
*	23- 2
WHEEL, steering	14-20
WIRE HARNESS	33- 3
WIRE HARNESS ASSY	33-23
WIRE, lead	30-23
*	32-38
*	33- 4
WIRE, minus lead	33- 2
WIRE, plus lead	33- 1
WIRE, sub-lead	33-17

## SPECIAL TOOLS

ADAPTOR (16x1.0)	35- 6
CRANKCASE SEPARATOR	35- 1
CRANKSHAFT JIG	35-12
CRANKSHAFT SETTING POT	35- 4
PRESS BOX	35-17
PRESS PIN	35-14
PRESS PLATE (2 Reg.)	35-13
PRIMARY SHEAVE PULLER	35-11
RING NUT WRENCH (Ignition Switch)	35- 2
ROTOR HOLDING TOOL	35- 3
SECONDARY SHEAVE HOLDER	35-18
SETTING BOLT	35- 9
SOCKET WRENCH (Brake Adjusting)	35-19

DESCRIPTION	REF. NO.
SPACER (Large)	35- 7
SPACER (Small)	35- 8
SPECIAL ADAPTOR (16x1.0x20 UNF)	35- 5
SPECIAL PRESS PLATES (PR.)	35-15
UNIVERSAL MAGNETO/SHEAVE PULLER	35-10
WIDTH GAUGE (55.75mm)	35-16

COPY RIGHT: ALL RIGHTS RESERVED  
NO PART OF THIS PUBLICATION MAY BE  
REPRODUCED WITHOUT PERMISSION.



**PRINTED IN JAPAN**  
**First edition Oct., 1980**

**T.G**