

YAMAHA

PARTS CATALOGUE

GOLF CAR

G1-A (J21)

12J21-700E1

FOREWORD

This Parts Catalogue is related to the parts in use for the YAMAHA Golf Car G1-A (J21).
When you are ordering replacement parts for the G1-A (J21), refer to this Parts Catalogue and quote both part numbers and part names correctly.

1. Modifications or additions which have been made after issue of the Parts Catalogue will be announced in the Yamaha Parts News.

It is advisable that according to the Yamaha Parts News you make necessary corrections to the Parts Catalogue on hand to keep it up-to-date.

2. Abbreviations

The following abbreviations are used in this Parts Catalogue.

- U.R. Use size (thickness) and/or number as required.
- U.N. Use as many as you need.
- A.P. Alternate Parts
- L.M. Local Made
- F# Frame No. (Applicable machine No.)

3. The parts marked with (+) in the parts number column of this Catalogue are not supplied with by Yamaha, those have to be found locally.

4. Parts, which are to be supplied in the form of assemblies, are listed with an indention of one letter's space, and a dot (.) is put against the name of each part.

EXAMPLE CARBURETOR ASS'Y
 . JET, pilot
 . NOZZLE, main

5. Initial Serial No. and Color Code

(A) Frame Serial No.	J21-000101 and following
(B) Engine Serial No.	J21-000101 and following







FIG. 1 CYLINDER HEAD, CYLINDER



REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	J17-11111-00	HEAD, cylinder 1	1	
2	J10-11181-00	GASKET, cylinder head 1	1	
3	94701-00168	PLUG, spark (NGK BP5HS)	1	
4	J17-11311-00	CYLINDER 1	1	
5	881-11351-01	GASKET, cylinder	1	
6	90116-08254	BDLT, stud.	4	
7	90179-08278	NUT	4	

FIG. 2 CRANKSHAFT-PISTON



REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	J10-11631-00-96	PISTON (STD)	1	UR 1
	J10-11631-00-98	PISTON (STD)	1	UR 2
	J10-11635-00	PISTON (1ST O/S 0.25MM)	1	AP
	J10-11636-00	PISTON (2ND O/S 0.50MM)	1	AP
2	J10-11610-00	PISTON RING SET (STD)	1	2
	J10-11610-10	PISTON RING SET (1ST O/S)	1	AP
	J10-11610-20	PISTON RING SET (2ND O/S)	1	AP
3	818-11633-00	PIN, Piston	1	
4	93450-20026	CIRCLIP	2	
5	93310-218A6	BEARING, cylindrical	1	
6	J10-11400-00	CRANKSHAFT ASSY	1	
7	J10-11412-00	•CRANK 1	1	
8	J10-11422-00	•CRANK 2	1	
9	8F3-11681-00	•PIN, crank 1	1	
10	90209-24073	•WASHER	2	
11	93310-424E8	•BEARING, cylindrical	1	
12	881-11651-00	•ROD, connecting	1	
13	93306-30621	BEARING (B6306)	1	
14	93306-20618	BEARING (B6206)	1	
15	93102-30188	OIL SEAL	1	
16	93450-72048	CIRCLIP	1	
17	93102-30128	OIL SEAL	1	
18	90280-05013	KEY, woodruff	1	
19	90170-16182	NUT	1	
20	92902-16100	WASHER	1	





FIG. 3 AIR SHROUD.FAN

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	J10-12651-00	AIR SHROUD, cylinder 1	1	
2	J10-12652-00	AIR SHROUD, cylinder 2	1	
3	92502-06016	SCREW, Pan head	3	
4	92902-06600	WASHER	3	
5	97301-06016	BOLT	4	
6	90462-08056	CLAMP	1	
7	90465-08028	CLAMP	1	
8	90201-06557	WASHER, Plate	4	
9	J10-12631-00	DEFLECTOR 1	1	
10	90267-48040	RIVET, blind	3	
11	90201-04756	WASHER, Plate	3	
12	8G8-12611-01	FAN	1	
13	95822-06012	BOLT, flange	6	
14	J17-12621-00	CASE, fan	1	
15	95802-06050	BOLT, flange	1	
16	J17-12616-00	COVER, fan case	1	
17	97302-06060	BOLT	4	
18	92902-06600	WASHER	4	


FIG. 4 OIL PUMP



REF. NO.	PART NO.	DESCRIPTION	QTY	REMARKS
1	J17-13101-00	OIL PUMP ASSY	1	5
2	90401-06001	BOLT, union	1	
3	90430-06180	GASKET	1	5
4	90445-05214	HOSE	1	
5	90468-02033	CLIP	2	
6	126-13116-00	GASKET, Pump case	1	
7	98501-05016	SCREW, Pan head	2	
8	90445-09635	HOSE	1	
9	90501-08430	SPRING, compression	1	
10	90467-09005	CLIP	1	
11	90467-09026	CLIP	1	
12	J10-13283-00	JET, sensor	1	
13	90445-11634	HOSE	1	
14	90467-10035	CLIP	2	
15	90201-08624	WASHER, Plate	1	


FWD

FIG. 5 PUMP DRIVE GEAR




REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	J10-15416-00	COVER 1	1	
2	93101-10090	OIL SEAL	1	
3	137-13176-00	METAL, worm shaft outer	1	
4	J10-13175-00	SHAFT, worm	1	
5	J10-13188-00	GEAR, drive	1	
6	93603-22028	PIN, dowel	1	
7	90206-11016	WASHER, wave	1	
8	137-13148-00	PLATE, cam thrust	1	
9	93410-10025	CIRCLIP	1	
10	J10-15466-00	GASKET 2	1	
11	J10-15426-00	COVER 2	1	
12	93112-53004	OIL SEAL	1	
13	91810-18027	PIN, dowel	2	
14	92501-06018	SCREW, Pan head	1	
15	92501-06012	SCREW, Pan head	1	
16	97322-08035	BOLT	1	
17	92902-08100	WASHER, sPring	1	
18	92902-08600	WASHER, Plate	1	
19	95822-06035	BOLT, flange	2	
20	97322-06030	BOLT	1	
21	92902-06100	WASHER, sPring	1	
22	92902-06600	WASHER	1	

FIG. 6 INTAKE




REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	345-13610-70	REED VALVE ASSY	1	
2	345-13613-70	.REED, valve	2	
3	345-13616-70	.STOPPER, reed valve	2	
4	98502-03008	.SCREW, Pan head	4	
5	92903-03100	.WASHER, sPring	4	
6	314-13621-02	GASKET, valve seat	1	
7	J17-13586-00	JDINT, carburetor 1	1	1
8	97302-06030	BOLT	4	
9	92902-06100	WASHER, sPring	4	
10	92902-06600	WASHER	4	
11	90460-41146	CLAMP, hose	1	
12	J10-26331-02	CABLE, starter 1	1	sb op → 02
13	J10-26325-00	.KNDB, starter	1	
14	90149-03132	.SCREW	1	
15	J17-26339-09	.BOOT	1	
16	91701-05010	PIN, clevis	1	5
17	90468-10049	CLIP	1	
18	J10-14453-00	JDINT, air cleaner 1	1	
19	90460-41145	CLAMP, hose	1	
20	90460-50035	CLAMP, hose	1	
21	J17-14410-00	AIR-CLEANER ASSY	1	
22	J10-14411-00	.CASE, air cleaner 1	1	
23	90480-13238	.GROMMET	2	
24	90480-14239	.GROMMET	2	
25	J17-14412-00	.CAP, cleaner case 1	1	1
26	J10-14416-00	.GASKET, air cleaner	1	
27	J10-14450-10	.ELEMENT ASSY, air cleaner	1	
28	J10-1441F-00	.PARTITION, air cleaner case	1	

FIG. 6 INTAKE



REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
29	90480-14100	•GROMMET	1	
30	J10-14417-00	•COVER 1	1	
31	J17-12644-00	•DEFLECTOR 3	1	2
32	J10-14436-00	•HOOK	3	
33	90269-65032	•RIVET	1	10
34	97302-06022	BOLT	2	
35	90201-06557	WASHER, Plate	1	
36	90387-06026	COLLAR	2	
37	90201-114E6	WASHER, Plate	1	


FIG. 7 CARBURETOR



REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	J17-14101-00	CARBURETOR ASSY 1	1	
2	796-14184-00	GASKET, float chamber	1	
3	796-14181-00	BODY, float chamber 1	1	
4	J17-14141-00	NOZZLE, main	1	
5	256-14944-19	JET, main (#095.0)	1	
6	732-14237-00	GASKET	1	
7	J10-14244-00	HOLDER, nozzle	1	
8	620-14212-00	SPRING, Pilot adjusting	2	
9	620-14211-00	SCREW, Pilot adjusting	1	
10	J10-14122-00	SCREW, throttle	1	
11	620-14142-32	JET, Pilot (#32.5)	1	
12	127-14195-00	WASHER, needle valve	1	
13	353-14190-10	NEEDLE VALVE ASSY	1	5
14	796-14186-00	PIN, float	1	
15	796-14185-00	FLOAT	1	
16	J10-14581-00	BRACKET	1	
17	J10-14243-00	PLATE	1	
18	97602-03108	SCREW, Pan head with washer	2	

FWD

FIG. 8 EXHAUST



REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	J17-14612-00	NUT, ring	1	
2	888-14633-00	RING	2	
3	8F3-14613-00	GASKET, exhaust Pipe	1	
4	97322-08025	BOLT	2	
5	92902-08100	WASHER, sPring	2	
6	90506-20074	SPRING, tension	2	
7	J17-14610-00	EXHAUST PIPE ASSY 1	1	
8	J10-14715-00	BAND, muffler	2	
9	95612-08100	NUT, u	2	
10	J17-1468U-00	PLATE, silencer 1	1	
11	98502-05012	SCREW, Pan head	4	
12	92902-05100	WASHER, sPring	4	
13	90201-06074	WASHER, Plate	4	

FIG. 9 CRANKCASE

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	8H4-15100-00	CRANKCASE ASSY	1	
2	91830-21014	.PIN, dowel	2	
3	812-24461-00	PIPE, Joint	1	
4	92502-06045	SCREW, Pan head	5	
5	92502-06055	SCREW, Pan head	1	
6	92502-06065	SCREW, Pan head	1	






FIG. 10 DIL TANK



REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	J17-21751-00	TANK, oil	1	
2	863-21771-00	BODY, caP	1	
3	90430-31003	GASKET	1	
4	J17-21756-00	NET, filter	1	
5	J10-21745-00	PIPE, oil tank breather	1	
6	90467-11009	CLIP	2	
7	90464-12036	CLAMP	1	
8	J17-21776-00	BAND, tank fitting	1	
9	97301-06016	BOLT	2	
10	90201-06071	WASHER, Plate	2	
11	90185-06098	NUT, self-locking	2	


FWD

FIG. 11 REAR SUSPENSION



REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	J17-W2211-00	REAR ARM COMP.	1	
2	J10-22123-00	BUSH 1	2	
3	90101-10419	BOLT	2	
4	95612-10100	NUT, u	2	
5	J10-22210-00	SHOCK ABSORBER ASSY, rear	2	
6	97302-10050	BOLT	4	
7	95602-10100	NUT, u	4	
8	J17-21411-00	BRACKET, engine 1	1	
9	90106-10034	BOLT	4	
10	92901-10100	WASHER, spring	4	
11	92902-10600	WASHER, plate	4	
12	J10-21486-00	DAMPER 2	4	
13	92901-10100	WASHER, spring	8	4
14	90170-10047	NUT	8	
15	J17-2217J-00	TENSIONER 1	1	513
16	J17-2214F-00	DAMPER 1	1	
17	90201-06778	WASHER, plate	1	
18	95302-06600	NUT	2	


FIG. 12 FRAME



REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	J17-22501-00	FRAME COMP.	1	
2	J17-22571-00	PANEL 1	1	1
3	J17-22572-00	PANEL 2	1	1
4	90267-40054	RIVET, blind	20	
5	J17-22573-00	PANEL 3	1	1
6	90267-40075	RIVET, blind	8	
7	J17-78249-00	TRIM, floor	2	4
8	90267-40090	RIVET, blind	6	30
9	J17-78181-00	PLATE 1	2	4
10	90267-48040	RIVET, blind	4	
11	J17-78187-00	FLAP, front fender	1	2
12	J17-78189-00	FLAP, front fender (R.H)	1	2
13	90267-40054	RIVET, blind	5	
14	90201-05034	WASHER, Plate	5	
15	J17-22567-00	SUPPORT 1	1	1
16	J17-22568-00	SUPPORT 2	1	1
17	97302-08065	BOLT	2	
18	92902-08100	WASHER, spring	2	
19	92902-08600	WASHER, Plate	2	
20	90387-09066	COLLAR	2	
21	95702-08100	NUT, flange	2	
22	J17-2258E-00	SUPPORT, front cowl	1	3
23	J11-77279-01	DAMPER, noise 19	1	3


FWD

FIG. 13 FRONT SUSPEN. WHEEL




REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	J17-W2351-00	FRONT LOWER ARM COMP.(L.H)	1	1
2	90381-15032	.BUSH, solid	1	5
3	J10-23526-00	.BUSH	1	
4	93700-06004	.NIPPLE, Grease	1	
5	90381-15040	.BUSH, solid	1	5
6	93210-15414	.O-RING	1	
7	J17-23510-00	KNUCKLE, steering comp.	1	2
8	J11-23512-00	ARM, knuckle 1	1	1
9	90109-10643	BOLT	2	
10	90201-121F0	WASHER, Plate	2	
11	90201-105F2	WASHER, Plate	2	
12	90171-10035	NUT, castle	2	
13	91490-25025	PIN, cotter	2	
14	90214-16027	WASHER, claw	1	
15	97302-08030	BOLT	1	
16	95301-08700	NUT	1	
17	J17-W2352-00	FRONT LOWER ARM COMP.(R.H)	1	1
18	90381-15032	.BUSH, solid	1	
19	J10-23526-00	.BUSH	1	
20	93700-06004	.NIPPLE, Grease	1	
21	90381-15040	.BUSH, solid	1	
22	93210-15414	.O-RING	1	
23	J17-23510-00	KNUCKLE, steering comp.	1	2
24	J11-23522-00	ARM, knuckle 2	1	1
25	90109-10643	BOLT	2	
26	90201-121F0	WASHER, Plate	2	
27	90201-105F2	WASHER, Plate	2	
28	90171-10035	NUT, castle	2	

FIG. 13 FRONT SUSPEN. WHEEL



REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
29	91490-25025	PIN, cotter	2	
30	90214-16027	WASHER, claw	1	
31	97302-08030	BOLT	1	
32	95301-08700	NUT	1	
33	J10-23516-02	KING PIN, steering knuckle	2	
34	91401-30025	PIN, cotter	2	
35	95702-12300	NUT, nylon	2	
36	90105-10224	BOLT, washer based	2	
37	90179-10280	NUT	2	
38	95822-12085	BOLT, flange	1	
39	90185-12093	NUT, self-locking	1	
40	90387-137F7	COLLAR	1	
41	J17-W2355-00	ROD, tension	2	2
42	J10-23583-01	BUSH	1	2
43	90105-08225	BOLT, washer based	2	
44	90185-08106	NUT, self-locking	2	
45	90105-12226	BOLT, washer based	1	
46	90185-12093	NUT, self-locking	1	
47	90387-137F6	COLLAR	1	
48	90102-12046	BOLT, with hole	2	
49	90185-12093	NUT, self-locking	2	
50	J10-23350-00	SHOCK ABSORBER ASSY	2	
51	97322-10050	BOLT	4	
52	95612-10100	NUT, u	4	
53	J17-W2511-00	HUB, front	2	1
54	J17-25118-00	COVER, hub dust	2	4
55	93306-00511	BEARING	2	4
56	93306-20437	BEARING	2	4

FIG. 13 FRONT SUSPEN. WHEEL



REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
57	95302-14900	NUT	2	
58	90209-14219	WASHER	2	5
59	91401-30025	PIN, cotter	2	
60	91490-25025	PIN, cotter	7	
61	J11-25100-00	FRONT WHEEL ASSY	2	
62	J11-25102-00	WHEEL RIM ASSY, front	1	
63	94118-85507	TIRE	1	
64	787-25170-00	AIR VALVE ASSY	1	
65	90179-12262	NUT	8	




FIG. 14 STEERING

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
X 1	J17-23816-00	ARM, Pitman	1	1
2	J10-23836-09	.PIN, Pitman	2	
3	93102-22082	OIL SEAL	1	
N 4	J10-23876-00	BOLT	1	
5	93332-00010	BEARING	1	
N 6	J10-23877-00	NUT	1	
N 7	J10-23444-00	WASHER	1	
N 8	J10-23818-00	COVER, steering	1	
9	J10-23462-00	SEAL, steering	2	
10	90430-08119	GASKET	1	
11	J10-23459-00	BOLT	1	
12	90170-08024	NUT	1	
13	93104-15005	OIL SEAL	1	
14	97302-08020	BOLT	4	
15	92902-08100	WASHER, spring	4	
16	93332-00010	BEARING	1	
17	J10-23814-00	HOLDER, handle upper	1	
18	J10-23811-00-9E	COLUMN, steering	1	Ivory white
19	J10-23840-00	STEERING SHAFT ASSY	1	
20	J10-23838-00	WHEEL, steering	1	2
X 21	J17-23826-01	ARM, idler	1	1
22	J10-23831-00	ROD, tie	1	
23	J10-23841-10	JOINT, universal 1	1	
24	J10-23845-10	JOINT, universal 2	1	
25	90170-12054	NUT	1	
26	90170-12055	NUT	1	
27	J10-23831-00	ROD, tie	1	
28	J10-23841-10	JOINT, universal 1	1	





FIG. 14 STEERING


REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
✓ 29	J10-23845-10	JOINT, universal 2	1	
✓ 30	90170-12054	NUT	1	
✓ 31	90170-12055	NUT	1	
N 32	95302-12900	NUT, slotted	4	
✓ 33	92902-12600	WASHER, Plate	2	
N 34	91401-30025	PIN, cotter	4	
✓ 35	95702-16300	NUT, nylon	1	
✓ 36	90215-16161	WASHER, lock	1	
✓ 37	90185-12061	NUT, self-locking	1	
✓ 38	92902-12200	WASHER	1	
N 39	90340-14029	PLUG, straight screw	1	
N 40	97302-10050	BOLT	4	
✓ 41	92901-10100	WASHER, spring	4	
X 42	90430-14175	GASKET	2	5

FIG. 15 FUEL TANK




REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
X 1	J17-24111-00	TANK, fuel	1	
X 2	J17-24611-00	BODY, cap	1	2
3	J10-24612-00	GASKET, cap	1	
4	J10-24461-00	PIPE, Joint	1	
5	J10-21773-00	GROMMET	2	
N 6	J10-24311-00	PIPE, fuel 1	1	
X 7	90468-04092	CLIP	1	
8	J10-21744-00	BREATHER	1	
X 9	J17-85710-00	FUEL LEVEL GAUGE ASSY	1	1
N 10	J10-24312-00	PIPE 2	1	
X 11	90467-11009	CLIP	2	
12	809-24560-01	FILTER ASSY	1	
X 13	90467-11009	CLIP	2	
X 14	90501-08486	SPRING, compression	1	
X 15	J10-24366-00	CLAMP, fuel Pipe:1	2	
16	90445-11288	HOSE	1	
N 17	J10-24313-00	PIPE 3	1	
X 18	90461-10054	CLAMP	3	
19	90267-40054	RIVET, blind	3	
X 20	90445-11151	HOSE	1	
X 21	90467-11009	CLIP	2	
22	J10-24410-02	FUEL PUMP ASSY	1	
22-1	THIS W/OUT. OP	REPAIR KIT		
23	92501-06018	SCREW, Pan head	2	
24	92902-06100	WASHER, spring	2	
X 25	90445-09069	HOSE	1	
X 26	90467-08017	CLIP	2	
X 27	90445-10449	HOSE	1	
28	90467-09006	CLIP	2	

FIG. 15 FUEL TANK




REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
X29	J17-24173-00	BAND, tank fitting 1	2	
30	90201-08107	WASHER, Plate	2	
31	95602-08100	NUT, u	2	
X32	J17-24129-00	COVER, side 1	1	
X33	J17-2414H-00	TRIM, cover Panel	1	
X34	90202-08111	WASHER, Plate	4	
X35	90387-062E2	COLLAR	4	
X36	90201-06765	WASHER, Plate	4	
37	95602-06100	NUT, u	4	

FIG. 16 BRAKE



REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
X 1	J17-27250-00	BRAKE ARM COMP.	1	
/ 2	90384-14080	.BUSH, bimetal formed	2	
X 3	J17-27245-00	PAD, brake Pedal	1	
/ 4	J10-27211-00	PEDAL, brake	1	
X 5	90508-40543	SPRING, torsion	1	1
X 6	90387-107F8	COLLAR	1	
X 7	J17-25654-00	BRACKET, Pedal	1	
/ 8	90101-10447	BOLT	1	
/ 9	95602-10100	NUT, u	1	
/ 10	92901-10100	WASHER, sPring	1	
X 11	J17-25670-00	PARKING PEDAL COMP.	1	3
X 12	90384-05163	.BUSH, bimetal formed	1	
X 13	90384-12164	.BUSH, bimetal formed	1	
/ 14	90380-12051	.BUSH, solid	1	
X 15	90101-06555	BOLT	1	
/ 16	92902-06200	WASHER	1	
/ 17	92902-06100	WASHER, sPring	1	
/ 18	95302-06600	NUT	1	
X 19	90508-23542	SPRING, torsion	1	1
X 20	90109-08669	BOLT	1	
/ 21	92902-08100	WASHER, sPring	1	
X 22	90179-08378	NUT	1	
X 23	J17-25679-00	DAMPER	1	
X 24	J17-27246-00	NAIL, brake	1	
/ 25	92902-08200	WASHER	3	
X 26	97312-08025	BOLT	2	
/ 27	95612-08100	NUT, u	2	
X 28	J17-W2561-00	SECTOR, Parking brake	1	2

FIG. 16 BRAKE



REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
X 29	90384-10162	BUSH, bimetal formed	1	
X 30	93210-10166	O-RING	2	10
N 31	90201-06750	WASHER, Plate	1	
32	95602-06100	NUT, u	1	
X 33	90508-14548	SPRING, torsion	1	1
X 34	J17-25672-00	PAD, Parking Pedal	1	
X 35	J17-27231-00	ROD, brake	1	1
X 36	J17-27232-00	END, rod 2	1	1
37	95302-06700	NUT	2	
X 38	90506-12277	SPRING, tension	1	1
X 39	J17-25673-00	DAMPER, brake	2	
X 40	J17-27228-00	PIN, joint	1	5
41	92901-05600	WASHER, Plate	1	
42	93430-04003	CIRCLIP	1	
X 43	90201-123F2	WASHER, Plate	1	
X 44	90508-26557	SPRING, torsion	1	1
X 45	90380-12105	BUSH, solid	1	1
46	97322-06016	BOLT	4	
47	92902-06100	WASHER, spring	4	
48	J10-25681-00	EQUALIZER, brake	1	
X 49	J17-25685-00	ROD	1	1
50	91701-10022	PIN, clevis	1	
N 51	91490-30015	PIN, cotter	1	
52	90249-14129	PIN	1	
53	90179-08261	NUT	1	
54	95301-08700	NUT	1	
X 55	J17-26341-01	CABLE, brake	1	2
X 56	J17-26351-01	CABLE, brake	1	2





FIG. 16 BRAKE

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
✓ 57	93430-09019	CIRCLIP	4	
✓ 58	91701-08018	PIN, clevis	4	
N 59	91490-25015	PIN, cotter	4	

FIG. 17 DRUM BRAKE



REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
X 1	J17-27280-00	BACKING PLATE ASSY (R.H)	1	
X 2	J17-27208-00	BACKING PLATE SUB ASSY 1	1	
X 3	J17-25340-00	BRAKE SHOE COMP.	1	10
X 4	J17-25330-00	BRAKE SHOE COMP.	1	10
X 5	J17-27206-00	ANCHOR BODY COMP.	1	
X 6	J17-27204-00	LEVER ASSY 1	1	1
✓ 7	J10-27281-00	SPRING, shoe clamp	2	
✓ 8	J10-27282-00	PIN, shoe hold down	2	
X 9	90506-20281	SPRING, tension	1	10
✓ 10	90506-26191	SPRING, tension	1	
X 11	J17-27238-00	NUT, adjusting	1	UN
X 12	90109-08657	BOLT	1	
✓ 13	J10-27286-00	COVER, dust	1	
✓ 14	92902-06100	WASHER, spring	2	
✓ 15	95302-06600	NUT	2	
X 16	90202-12133	WASHER, plate	1	
X 17	J17-27290-00	BACKING PLATE ASSY (L.H)	1	
X 18	J17-27209-00	BACKING PLATE SUB ASSY 2	1	
X 19	J17-25340-00	BRAKE SHOE COMP.	1	
X 20	J17-25330-00	BRAKE SHOE COMP.	1	
X 21	J17-27206-00	ANCHOR BODY COMP.	1	
X 22	J17-27205-00	LEVER ASSY 2	1	1
✓ 23	J10-27281-00	SPRING, shoe clamp	2	
✓ 24	J10-27282-00	PIN, shoe hold down	2	
✓ 25	90506-20281	SPRING, tension	1	
✓ 26	90506-26191	SPRING, tension	1	
X 27	J17-27258-00	NUT, adjusting	1	
X 28	90109-08659	BOLT	1	



FIG. 17 DRUM BRAKE

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
29	J10-27286-00	COVER, dust	1	
30	92902-06100	WASHER, sPring	2	
31	95302-06600	NUT	2	
32	90202-12133	WASHER, Plate	1	
33	97322-08016	BOLT	8	
34	92902-08100	WASHER, sPring	8	





FIG. 18 ACCELERATOR



REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	J17-27874-00	BRACKET, accelerator Pedal	1	
2	J17-27853-00	SHAFT, Pedal	1	
3	J17-27872-00	ARM, accelerator Pedal	1	
4	91609-60025	PIN, sPring	1	
5	J10-27871-01	PEDAL, accelerator	1	
6	97302-06025	BOLT	1	
7	92902-06100	WASHER, sPring	1	
8	90106-08040	BOLT	1	
9	95301-08700	NUT	1	
10	J10-27852-00	CUP	1	
11	91609-35028	PIN, sPring	1	
12	90384-14080	BUSH, bimetal formed	2	
13	93210-14104	D-RING	4	
14	97302-06014	BOLT	4	
15	92902-06100	WASHER, sPring	4	
16	90506-26282	SPRING, tension	1	
17	J17-26311-00	CABLE, throttle	1	
18	256-83936-00	BAND, switch cord	1	
19	91702-05012	PIN, clevis	1	
20	91401-16010	PIN, cotter	1	
21	93430-07012	CIRCLIP	1	
22	90508-16460	SPRING, torsion	1	
23	90560-05001	SPACER	1	
24	97302-06025	BOLT	1	
25	95302-06700	NUT	1	
26	J10-27981-00	BRACKET, throttle	1	





FIG. 19 GOVERNOR

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	J10-27912-00	RETAINER	1	
2	90387-21690	COLLAR	1	
3	J10-27913-00	WEIGHT	8	
4	J10-27911-00	HOLDER	1	
5	J10-27927-00	LIFTER	1	
6	93342-22502	BEARING	1	
7	90201-20275	WASHER, Plate	1	
8	J10-27921-01	SHAFT, Governor	1	
9	J10-27922-00	FORK, Governor	1	
10	98501-04008	SCREW, Pan head	2	
11	90202-08110	WASHER, Plate	2	
12	93430-06005	CIRCLIP	1	
13	93104-08058	OIL SEAL	1	
14	J17-27951-00	LEVER, speed limiter	1	
15	90385-08034	BUSH	2	
16	90508-40398	SPRING, torsion	1	
17	95302-06600	NUT	1	
18	J10-27959-00	SCREW, adjusting	1	
19	95302-05700	NUT	1	
20	J10-14836-00	ROD	1	
21	J10-14833-00	JOINT	1	
22	95302-05700	NUT	1	
23	J10-14864-00	JOINT	1	
24	90170-05190	NUT	1	
25	90468-05112	CLIP	2	


FIG. 20 PRIMARY SHEAVE



REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	J10-46210-00	PRIMARY FIXED SHEAVE COMP.	1	
2	93306-90601	BEARING (B6906)	1	
3	90387-47686	COLLAR	1	
4	J10-46244-00	SEAT, sPring	1	
5	J10-46220-01	PRIMARY SLIDING SHEAVE COMP.	1	
6	J10-46223-01	CAM	1	
7	J17-46230-00	PRIMARY SHEAVE CAP COMP.	1	
8	J10-46232-00	WEIGHT	4	
9	J10-46236-00	PIN, weight	4	
10	98501-05020	SCREW, Pan head	8	
11	92902-05100	WASHER, sPring	8	
12	J10-46253-01	SLIDER	4	
13	90149-05129	SCREW	4	
14	90501-32696	SPRING, comPrission	1	
15	93410-28051	CIRCLIP	1	
16	90560-12180	SPACER	1	
17	90215-13146	WASHER, lock	1	
18	J10-46249-00	BOLT	1	
19	J17-46254-00	SPACER, damPer	4	5
20	90202-10129	WASHER, Plate	8	10
21	93210-27458	O-RING	2	
22	J17-46241-00	BELT	1	20




FIG. 21 SECONDARY SHEAVE



REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	J17-46260-00	SECONDARY FIXED SHEAVE COMP.	1	
2	J17-46270-00	SECONDARY SLIDING SHEAVE COMP.	1	
3	93109-20014	OIL SEAL	2	
4	801-17688-10	SHOE, ramp	3	
5	J10-46284-00	SEAT, secondary spring	1	
6	801-17688-10	SHOE, ramp	3	
7	90280-05022	KEY, woodruff	1	5
8	90501-45600	SPRING, compression	1	
9	90201-12588	WASHER, Plate	1	
10	90171-12023	NUT, castle	1	
11	91401-30025	PIN, cotter	1	
12	90202-20130	WASHER, Plate	1	


FWD

FIG. 22 TRANSMISSION




REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	J11-46311-00	CASE, transmission 1	1	
2	93306-2050	BEARING (B6205)	1	
3	93306-2040	BEARING (B6204)	1	
4	93306-0080	BEARING (B6008)	1	
5	93102-2501	OIL SEAL	1	
6	93102-22189	OIL SEAL	1	
7	97321-08035	BOLT	9	
8	92901-08100	WASHER, spring	9	
9	92901-08600	WASHER, Plate	9	
10	97321-08045	BOLT	2	N/S
11	92901-08100	WASHER, spring	2	
12	92901-08600	WASHER, Plate	2	
13	J10-46312-00	CASE, transmission 2	1	N/S
14	93306-20324	BEARING	1	
15	93306-2040	BEARING (B6204)	1	
16	93306-0080	BEARING (B6008)	1	
17	93102-22189	OIL SEAL	1	
18	8E4-24461-00	PIPE, joint	1	
19	91810-05016	PIN, dowel	2	
20	J10-46319-00	GASKET	1	
21	90340-14036	PLUG, straight screw	2	
22	90430-14043	GASKET	2	
23	90465-06011	CLAMP	1	
24	835-47559-00	CAP 2	1	
25	97322-10020	BOLT	2	
26	92901-10100	WASHER, spring	2	
27	90465-08028	CLAMP	1	N/S
28	92502-06010	SCREW, Pan head	1	N/S

FIG. 22 TRANSMISSION




REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
29	92902-06100	WASHER, sPring	1	
30	J10-46321-00	SHAFT, inPut	1	
31	J17-46331-00	GEAR, inPut 1	1	
32	93410-25017	CIRCLIP	1	
33	J10-W4631-00	SHAFT, counter	1	
34	J17-46361-00	GEAR, counter 1	1	
35	J17-46362-00	GEAR, counter 2	1	
36	90201-20272	WASHER, Plate	1	
37	J10-W4641-00	CASE, differential	1	
38	J17-W4642-00	GEAR, ring	1	
39	J10-46414-00	GEAR, differential side	2	
40	J10-46415-00	PINION, differential	4	
41	97312-08030	BOLT	4	
42	92902-08100	WASHER, sPring	4	
43	91810-03014	PIN, dowel	2	

FIG. 23 REAR AXLE WHEEL




REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	J10-46540-00	REAR AXLE HOUSING COMP.	2	
2	97322-08025	BOLT	12	
3	92902-08100	WASHER, sPrin8	12	
4	97322-10020	BOLT	8	
5	92901-10100	WASHER, sPrin8	8	
6	J17-46510-00	REAR AXLE SHAFT COMP.	2	
7	J17-46521-00	DRUM	2	
8	J11-25300-00	REAR WHEEL ASSY	2	
9	J11-25102-00	WHEEL RIM ASSY, front	1	
10	94118-85508	TIRE	1	
11	787-25170-00	AIR VALVE ASSY	1	
12	90179-12262	NUT	8	

FIG. 24 BUMPER




REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	J17-78106-00	BUMPER SUB-ASSY, front	1	4
2	J17-78162-00	PAD, front bumper	1	4
3	J10-78167-01	BUMPER, rubber 1	1	
4	J10-78168-01	BUMPER, rubber 2	1	
5	90267-40077	RIVET, blind	8	
6	J17-77525-00	WASHER 1	4	
7	J17-78164-00	STAY, front bumper 1	1	
8	J17-78165-00	STAY, front bumper 2	1	
9	97322-08016	BOLT	4	
10	92902-08100	WASHER, spring	4	
11	92902-08600	WASHER, plate	4	
12	97322-08025	BOLT	4	
13	92902-08600	WASHER, plate	4	
14	90201-08766	WASHER, plate	4	
15	92902-08100	WASHER, spring	4	
16	95302-08600	NUT	4	
17	J17-78107-00	BUMPER SUB-ASSY, rear	1	3
18	J17-78162-00	PAD, front bumper	1	
19	J10-78167-01	BUMPER, rubber 1	1	
20	J10-78168-01	BUMPER, rubber 2	1	
21	90267-40077	RIVET, blind	8	
22	J17-77525-00	WASHER 1	4	
23	J10-78179-00	PLATE, extension	1	
24	97302-08014	BOLT	2	
25	92902-08600	WASHER, plate	2	
26	92902-08200	WASHER	2	
27	95301-08800	NUT, crown	2	
28	J10-78174-01	STAY, rear bumper	2	

FIG. 24 BUMPER



REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
29	97322-08016	BOLT	4	
30	92902-08100	WASHER, sPring	4	
31	97322-08020	N/S BOLT	4	
32	92902-08600	WASHER, Plate	4	
33	92902-08200	WASHER	4	
34	92902-08100	WASHER, sPring	4	
35	95302-08600	NUT	4	


FIG. 25 BODY



REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	J21-W7811-00	PANEL, body shell	1	
2	J10-78119-00	PLATE 3	1	
3	90267-40075	RIVET, blind	7	
4	J17-78121-00	REINFORCEMENT 1	1	
5	98901-06016	SCREW, blind	6	
6	90185-06098	NUT, self-locking	6	
7	J10-78137-00	PLATE 4	1	
8	90267-40075	RIVET, blind	4	
9	J17-78272-00	COVER, fuel inlet	1	
10	J10-77764-00	LABEL, warning 4	1	
11	J10-78238-01	FASTENER, upper	1	
12	93430-06005	CIRCLIP	1	
13	J17-78275-00	HINGE, fuel inlet	1	
14	90201-08732	WASHER, Plate	1	
15	J10-78239-00	FASTENER, lower	1	
16	90267-32019	RIVET, blind	2	
17	90480-35242	GROMMET	2	
18	90267-40075	RIVET, blind	2	
19	90201-04M06	WASHER, Plate	2	
20	J18-78115-00	COWL, front	1	
21	J17-77165-00	TRIM 1	1	
22	J17-78232-00	MAT, main floor 2	1	
23	J17-78233-00	MAT, main floor 3	1	
24	90267-63047	RIVET, blind	24	
25	J10-78291-00	EMBLEM 1	1	
26	92902-05200	WASHER	2	
27	95702-05300	NUT, nylon	2	
28	J17-77151-00	PAD 1	1	


22222

FIG. 25 BODY




REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
29	J17-77152-00	PAD 2	1	
30	J10-77768-00	LABEL, warning	1	
31	90269-06028	RIVET	2	10
32	J11-78287-00	ASH TRAY	1	
33	J11-78286-00	LID, ash tray	1	
34	91701-06026	PIN, clevis	1	
35	92902-06600	WASHER	1	
36	90501-08256	SPRING, compression	1	
37	91401-20015	PIN, cotter	1	
38	J11-77767-00	LABEL, warning 7	1	
39	J10-77711-00	PANEL, instrument	1	
40	J10-78245-00	SEAL 1	1	
41	J10-77741-00	INDICATOR 1	1	
42	90480-48243	GROMMET	1	
43	90464-25050	CLAMP	2	
44	97701-50130	SCREW, tapping	2	
45	90201-05036	WASHER, Plate	2	
46	90480-07241	GROMMET	2	
47	90201-08310	WASHER, Plate	2	
48	98902-08025	SCREW, blind	2	10
49	97302-06020	BOLT	3	
50	92902-06100	WASHER, spring	3	
51	90201-06075	WASHER, Plate	3	

FIG. 26 BODY FITTING




REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	J17-77145-00	HINGE 1	1	
2	J17-78221-00	SHEET, body mounting 1	2	
3	98502-05018	SCREW, Pan head	4	
4	92901-05600	WASHER, Plate	4	
5	95602-05100	NUT, u	4	
6	J17-78123-00	REINFORCEMENT 3	2	
7	J10-77146-00	HINGE 2	2	
8	91701-08118	PIN, clevis	2	
9	91401-25015	PIN, cotter	2	
10	98980-06020	SCREW, bind	8	
11	98980-06025	SCREW, bind	2	
12	90202-08085	WASHER, Plate	2	
13	90201-06697	WASHER, Plate	8	
14	90201-06697	WASHER, Plate	2	
15	90185-06098	NUT, self-locking	10	
16	97322-08020	BOLT	4	N/S
17	92902-08100	WASHER, spring	4	
18	92902-08600	WASHER, Plate	4	N/S
19	J10-77125-00	STAY 1	1	
20	J10-77766-00	LABEL, warning 6	1	
21	91701-08020	PIN, clevis	2	
22	J17-7712F-00	SPACER, stay	2	
23	90468-16065	CLIP	2	
24	J10-77188-00	STOPPER	1	N/S
25	91701-06012	PIN, clevis	1	N/S
26	90206-06060	WASHER, wave	1	
27	92902-06200	WASHER	1	
28	437-83525-00	CLIP	1	

FIG. 26 BODY FITTING




REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
29	J17-78156-00	STOPPER, lock	1	
30	91312-06035	BOLT	2	
31	J17-78231-00	MAT, main floor 1	1	
32	J17-78271-00	SERVICE LID, Pedal	1	
33	J17-78191-00	PANEL, rear fender 1	1	
34	J10-77765-00	LABEL, warning 5	1	
35	97302-06020	BOLT	4	
36	92902-06100	WASHER, sPring	4	
37	90201-061E8	WASHER, Plate	4	
38	J17-78192-00	PANEL, rear fender 2	1	
39	97302-06020	BOLT	4	
40	92902-06100	WASHER, sPring	4	
41	90201-061E8	WASHER, Plate	4	
42	J17-78198-00	RETAINER, flap	2	
43	J17-78199-00	FLAP, rear 2	2	2
44	90267-40075	RIVET, blind	6	
45	90201-05034	WASHER, Plate	6	

FIG. 27 CARRIER



REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	J10-78351-00-9E ✓	SUPPORT, ba& uPPer	1	ivory white
2	J10-78352-00-9E ✓	SUPPORT, ba& lower 1	1	ivory white
3	J10-78353-00-9E ✓	SUPPORT, ba& lower 2	1	ivory white
4	92701-08045 ✓	SCREW, flat head	4	
5	90202-08022 ✗	WASHER, Plate	4	
6	92990-08100 ✗	WASHER, sPring	4	
7	95380-08800 ✗	NUT, crown	4	
8	J10-78356-00 ✓	PAD, ba& suPPort	1	
9	J10-78355-00 ✓	BAND	1	
10	J10-78367-00 ✓	PLATE, anchor	1	
11	92902-06200 ✓	WASHER	4	
12	98980-06016 ✗	SCREW, bind	2	
13	92990-06100 ✗	WASHER, sPring	2	
14	95380-06800 ✗	NUT	2	
15	J17-78157-00 ✗	BASE, lock	1	
16	J17-78368-00 ✗	LEVER, lock	1	
17	J17-78369-00 ✗	PIN, lever	1	
18	90386-06108 ✗	BUSH	2	
19	93430-05033 ✓	CIRCLIP	1	
20	92503-06008 ✓	SCREW, Pan head	4	
21	92902-06100 ✓	WASHER, sPring	4	
22	J10-78139-00 ✓	CAP, end	2	
23	90179-10280 ✓	NUT	2	
24	97322-06065 ✗	BOLT	4	
25	92902-06100 ✓	WASHER, sPring	4	
26	92902-06600 ✓	WASHER	4	
27	J10-78366-01 ✓	CLAMP, suPPort	2	
28	J10-78357-01 ✓	HOLDER 1	1	

FIG. 27 CARRIER



REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
29	J10-78358-00 ✓	HOLDER 2	1	
30	90502-10013 ✓	SPRING, conical	2	
31	97702-50125 ✓	SCREW, tapping	2	
32	J10-78292-00 ✓	EMBLEM 2	1	
33	J10-77762-01 ✓	LABEL, warning 2	1	
34	92901-05600 ✓	WASHER, Plate	2	




FIG. 28 SUN ROOF

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	J11-78314-00	COVER, sun roof	1	
2	J18-78301-00	FRAME COMP., roof	1	
3	J18-78311-00	FRAME, sun roof	1	
4	J11-78316-00	DAMPER	1	
5	J18-78312-00	SUPPORT, sun roof 1	1	
6	J18-78313-00	SUPPORT, sun roof 2	1	
7	J18-78336-00	MEMBER, cross roof	1	
8	J18-W7831-00	SUN-ROOF BRACKET KIT	1	
9	97701-60116	•SCREW, tapping	10	
10	90201-06557	•WASHER, Plate	10	
11	90202-06008	•WASHER, Plate	20	
12	J11-78335-01	•LOCK, side wind	2	
13	90249-05136	•PIN	4	
14	93430-04003	•CIRCLIP	4	
15	92680-08050	•SCREW, oval head	2	U
16	90201-08310	•WASHER, Plate	2	
17	97375-08060	•BOLT	4	
18	95680-08100	•NUT, u	4	
19	J11-78329-00	•SPACER 2	8	
20	J11-78343-00	•RETAINER	4	
21	95602-08100	•NUT, u	10	
22	J18-78328-00	•SPACER 1	2	
23	J11-77271-00	•DAMPER, noise 11	8	
24	J11-77272-00	•DAMPER, noise 12	1	
25	J11-78338-00	•SPACER 3	2	
26	90506-23204	•SPRING, tension	2	
27	92990-08100	•WASHER, spring	4	
28	95380-08800	•NUT, crown	4	

FIG. 28 SUN ROOF

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
29	J18-78349-00	CAP, support roof	4	
30	92990-08600	WASHER, Plate	8	






FIG. 29 SEAT




REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	J10-78401-02 <i>N/S</i>	SEAT SUB-ASSY, cushion	1	UR
2	J10-78361-00-93 <i>N/S</i>	ARM REST 1	1	
3	97302-10030 <i>N/S</i>	BOLT	1	
4	92901-10100 <i>N/S</i>	WASHER, sPrin8	1	
5	92902-10600 <i>N/S</i>	WASHER, Plate	1	
6	92680-08035 <i>X</i>	SCREW, oval head	2	
7	92990-08500 <i>X</i>	WASHER	2	
8	97302-08025 <i>X</i>	BOLT	4	
9	92902-08100 <i>X</i>	WASHER, sPrin8	4	
10	90201-08310 <i>X</i>	WASHER, Plate	4	
11	J10-78439-00 <i>N/S</i>	WASHER, seat	4	
12	90480-42282 <i>N/S</i>	GROMMET	2	
13	J10-78403-02 <i>N/S</i>	SEAT SUB-ASSY, cushion 2	1	UR
14	J10-78362-00-93 <i>N/S</i>	ARM REST 2	1	
15	97302-10030 <i>N/S</i>	BOLT	1	
16	92901-10100 <i>N/S</i>	WASHER, sPrin8	1	
17	92902-10600 <i>N/S</i>	WASHER, Plate	1	
18	92680-08035 <i>X</i>	SCREW, oval head	2	
19	92990-08500 <i>X</i>	WASHER	2	
20	97302-08025 <i>X</i>	BOLT	4	
21	92902-08100 <i>X</i>	WASHER, sPrin8	4	
22	90201-08310 <i>X</i>	WASHER, Plate	4	
23	J10-78439-00 <i>N/S</i>	WASHER, seat	4	

FIG. 30 D.C. GENERATOR




REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	J10-81100-10	STARTER GENERATOR ASSY	1	
2	J10-81150-10	ARMATURE ASSY	1	
3	J10-81157-10	BEARING 1 (6202 SD)	1	MS
4	J10-81158-10	BEARING 2 (6203 SD)	1	MS
5	J10-81159-10	HOLDER, bearing	1	MS
6	J10-81175-10	STOPPER 1	1	
7	J10-81110-10	STATOR ASSY	1	T
8	J10-81160-10	FIELD COIL ASSY	1	T
9	J10-81148-10	SCREW 4	2	
10	95301-06600	NUT	4	
11	92901-06600	WASHER, Plate	2	
12	92901-06100	WASHER, sPring	4	
13	J10-81146-10	SCREW 2	4	MS
14	J10-81165-10	BRACKET, starter generator 1	1	MS
15	J10-81166-10	BRACKET, starter generator 2	1	MS
16	J10-81147-10	SCREW 3	2	
17	95301-06600	NUT	4	
18	92901-06600	WASHER, Plate	2	
19	92901-06100	WASHER, sPring	4	
20	J10-81119-10	BRUSH HOLDER ASSY	1	
21	J10-81111-10	BRUSH	4	
22	J10-81113-10	SPRING, brush	4	
23	J10-81115-10	WIRE, lead	2	
24	98501-05016	SCREW, Pan head	2	
25	98503-04010	SCREW, Pan head	4	
26	J10-81163-10	KEY	1	
27	95301-14600	NUT	1	
28	92901-06100	WASHER, sPring	1	

FIG. 30 D.C GENERATOR




REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
29	98501-05018 ✓	•SCREW, Pan head	3	
30	J10-81129-10 ✓	•COVER, brush	3	
31	J10-81139-10 ✓	•COVER, brush 2	1	
32	J10-81145-10 N/3 ✓	•SCREW .1	2	
33	92901-06600 ✓	•WASHER, Plate	2	
34	92901-06100 ✓	•WASHER, sPring	2	

FIG. 31 STARTER PULLEY



REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	J17-87183-00	INSULATOR, Generator	1	
2	98501-05008	SCREW, Pan head	4	
3	92902-05100	WASHER, sPring	4	
4	J10-81161-00	PULLEY	1	
5	J10-87172-00	FAN, Generator	1	
6	92502-06025	SCREW, Pan head	2	
7	92902-06100	WASHER, sPring	2	
8	92902-06600	WASHER	2	
9	J10-81173-00	BELT	1	
10	90101-12545	BOLT	1	
11	92902-12600	WASHER, Plate	2	
12	92902-12100	WASHER, sPring	1	
13	95302-12600	NUT	1	
14	J17-81170-00	TENSIONER ASSY	1	
15	97302-08025	BOLT	1	
16	90109-08653	BOLT	1	
17	92902-08600	WASHER, Plate	2	
18	92902-08100	WASHER, sPring	2	
19	95302-08600	NUT	2	
20	90101-06410	BOLT	1	
21	95302-06700	NUT	1	


FIG. 32 C.D.I MAGNETO



REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	J10-85500-20 ✓	C.D.I. MAGNETO ASSY	1	
2	8G8-85511-20 ✓	.COIL, source	1	
3	J10-85580-20 ✓	.COIL, Pulser	1	
4	J10-85515-20 ✓	.LEAD WIRE ASSY	1	
5	104-81328-20 ✓	.CLAMP	2	
6	98501-05020 ✓	.SCREW, Pan head	2	
7	92901-05100 ✓	.WASHER, sPring	2	
8	98501-04020 ✓	.SCREW, Pan head	2	
9	92901-04100 ✓	.WASHER, sPring	2	
10	98501-04008 ✓	.SCREW, Pan head	1	
11	92901-04100 ✓	.WASHER, sPring	1	
12	J10-85550-20 ✓	.ROTOR ASSY	1	
13	98901-06014 ✓	SCREW, bind	2	
14	90201-06043 ✓	WASHER, Plate	2	
15	J10-85540-20 ✓	C.D.I. UNIT ASSY	1	
16	2A7-85546-00 ✓	BAND	1	
17	J17-21245-00 ✓	BOX	1	
18	J10-81910-10 ✓	VOLTAGE REGULATOR ASSY	1	
19	97301-06016 ✓	BOLT	2	
20	92902-06100 ✓	WASHER, sPring	2	
21	92902-06600 ✓	WASHER	2	
22	90201-06043 ✓	WASHER, Plate	2	
23	95302-06600 ✓	NUT	2	
24	J17-81950-00 ✓	RELAY ASSY	2	
25	95301-08700 ✓	.NUT	8	
26	92902-08100 ✓	.WASHER, sPring	8	
27	92902-08600 ✓	.WASHER, Plate	4	
28	J17-86126-00 ✓	PLATE, connecting	2	

FIG. 32 C.D.I MAGNETO

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
29	J17-86127-00	PLATE, conecting 2	2	
30	92902-08200	WASHER	4	
31	92902-08100	WASHER, sPrinG	4	
32	95302-08600	NUT	4	






FIG. 33 ELECTRICAL 1

REF. NO.	PART NO.	DESCRIPTION	QTY	REMARKS
1	J11-82110-70 <i>N/S</i>	BATTERY ASSY (F.B. N50)	1	
2	J10-82115-00 ✓	WIRE, Plus lead	1	
3	J17-82116-00 ✗	WIRE, minus lead	1	
4	J17-82105-00 ✗	WIRE HARNESS	1	
5	1E6-82150-00 ✓	FUSE HOLDER ASSY	1	
6	1E6-82151-00 ✓	.FUSE (6V-10A)	2	
7	J14-82150-00 ✓	FUSE HOLDER ASSY	1	
8	1E6-82151-00 ✓	.FUSE (6V-10A)	2	
9	J17-82133-00 ✗	SCREW, fitting	2	
10	J17-82136-00 ✗	PLATE, battery fitting	1	
11	J17-82122-00 ✗	SEAT, battery	1	
12	95702-06300 ✓	NUT, nylon	2	
13	92902-06200 ✓	WASHER	2	
14	J17-82310-21 ✗	IGNITION COIL ASSY	1	
15	92502-06025 <i>N/S</i>	SCREW, Pan head	2	
16	92902-06100 <i>N/S</i>	WASHER, spring	2	
17	90465-06038 ✓	CLAMP	1	
18	90462-08056 ✗	CLAMP	1	
19	8G8-82318-00 ✗	WIRE, sub-lead	1	
20	512-82370-10 ✓	PLUG CAP ASSY	1	with noise sup- Presser
21	J17-82508-20 ✗	MAIN SWITCH ASSY	1	
22	J17-82511-20 ✗	.KEY, main switch	2	10
23	J17-82550-00 ✗	STOP SWITCH ASSY	1	8
24	90465-08028 <i>N/S</i>	CLAMP	1	
25	J17-82590-21 ✗	WIRE HARNESS ASSY	1	
26	J17-86177-00 ✗	WIRE, lead 7	1	
27	J17-82318-00 ✗	WIRE, sub-lead	1	
28	366-82591-00 <i>N/S</i>	BAND	1	





FIG. 33 ELECTRICAL 1

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
29	256-83936-00 <i>MS</i>	BAND, switch cord	1	
30	90464-12036 <i>X</i>	CLAMP	4	
31	J10-83383-02 <i>X</i>	BUZZER	1	
32	97301-06016 <i>X</i>	BOLT	1	
33	92902-06100 <i>X</i>	WASHER, sPring	1	
34	92902-06600 <i>X</i>	WASHER	1	
35	95302-06600 <i>X</i>	NUT	1	
36	90201-06043 <i>X</i>	WASHER, Plate	1	

FIG. 34 SPECIAL TOOLS



REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	90890-01135-00	CRANKCASE SEPARATOR		
2	90890-01051-00	RING NUT WRENCH (Ignition Switch)		90890-01268
3	90890-01235-00	ROTOR HOLDING TOOL		
4	90890-90058-00	CRANKSHAFT SETTING POT		90890-01174
5	ACC-11401-01-00	SPECIAL ADAPTOR (16x1.0x20 UNF)		90890-01287
6	90890-90067-00	ADAPTOR (16x1.0)		90890-01280
7	90890-01202-00	SPACER (Large)		
8	90890-90059-00	SPACER (Small)		90890-01818
9	90890-90060-00	SETTING BOLT		90890-01275
10	90890-90105-10	UNIVERSAL MAGNETO/SHEAVE PULLER		90890-01990
11	90890-01876-00	PRIMARY SHEAVE PULLER		
12	90890-02300-00	CRANKSHAFT JIG		
13	90890-02204-00	PRESS PLATE (2 Reg.)		
14	90890-02203-00	PRESS PIN		
15	ACC-11401-02-00	SPECIAL PRESS PLATES (PR.)		
16	90890-02213-00	WIDTH GAUGE (55.75mm)		
17	90890-02202-00	PRESS BOX		
18	ACC-11401-03-00	SECONDARY SHEAVE HOLDER		
19	90890-01886-00	SOCKET WRENCH (Brake Adjusting)		

NUMERICAL INDEX

PART NO.	REF. NO.	PART NO.	REF. NO.	PART NO.	REF. NO.
J17-W2211-00	11- 1	J10-14122-00	7-10	J10-21773-00	15- 5
J17-W2351-00	13- 1	J17-14141-00	7- 4	J17-21776-00	10- 8
J17-W2352-00	13-17	620-14142-32	7-11	J10-22123-00	11- 2
J17-W2355-00	13-41	796-14181-00	7- 3	J17-2214F-00	11-16
J17-W2511-00	13-53	796-14184-00	7- 2	J17-2217J-00	11-15
J17-W2561-00	16-28	796-14185-00	7-15	J10-22210-00	11- 5
J10-W4631-00	22-33	796-14186-00	7-14	J17-22501-00	12- 1
J10-W4641-00	22-37	353-14190-10	7-13	J17-22567-00	12-15
J17-W4642-00	22-38	127-14195-00	7-12	J17-22568-00	12-16
J21-W7811-00	25- 1	620-14211-00	7- 9	J17-22571-00	12- 2
J18-W7831-00	28- 8	620-14212-00	7- 8	J17-22572-00	12- 3
J17-11111-00	1- 1	732-14237-00	7- 6	J17-22573-00	12- 5
J10-11181-00	1- 2	J10-14243-00	7-17	J17-2258E-00	12-22
J17-11311-00	1- 4	J10-14244-00	7- 7	J10-23350-00	13-50
881-11351-01	1- 5	J10-1441F-00	6-28	J10-23444-00	14- 7
J10-11400-00	2- 6	J17-14410-00	6-21	J10-23459-00	14-11
J10-11412-00	2- 7	J10-14411-00	6-22	J10-23462-00	14- 9
J10-11422-00	2- 8	J17-14412-00	6-25	J17-23510-00	13- 7
J10-11610-00	2- 2	J10-14416-00	6-26		13-23
J10-11610-10	2- 2	J10-14417-00	6-30	J11-23512-00	13- 8
J10-11610-20	2- 2	J10-14436-00	6-32	J10-23516-02	13-33
J10-11631-00-96	2- 1	J10-14450-10	6-27	J11-23522-00	13-24
J10-11631-00-98	2- 1	J10-14453-00	6-18	J10-23526-00	13- 3
818-11633-00	2- 3	J10-14581-00	7-16		13-19
J10-11635-00	2- 1	J17-14610-00	8- 7	J10-23583-01	13-42
J10-11636-00	2- 1	J17-14612-00	8- 1	J10-23811-00-9E	14-18
881-11651-00	2-12	8F3-14613-00	8- 3	J10-23814-00	14-17
8F3-11681-00	2- 9	888-14633-00	8- 2	J17-23816-00	14- 1
8G8-12611-01	3-12	J17-1468U-00	8-10	J10-23818-00	14- 8
J17-12616-00	3-16	J10-14715-00	8- 8	J17-23826-01	14-21
J17-12621-00	3-14	J10-14833-00	19-21	J10-23831-00	14-22
J10-12631-00	3- 9	J10-14836-00	19-20		14-27
J17-12644-00	6-31	J10-14864-00	19-23	J10-23836-09	14- 2
J10-12651-00	3- 1	256-14944-19	7- 5	J10-23838-00	14-20
J10-12652-00	3- 2	8H4-15100-00	9- 1	J10-23840-00	14-19
J17-13101-00	4- 1	J10-15416-00	5- 1	J10-23841-10	14-23
126-13116-00	4- 6	J10-15426-00	5-11		14-28
137-13148-00	5- 8	J10-15466-00	5-10	J10-23845-10	14-24
J10-13175-00	5- 4	801-17688-10	21- 4		14-29
137-13176-00	5- 3		21- 6	J10-23876-00	14- 4
J10-13188-00	5- 5	J17-21245-00	32-17	J10-23877-00	14- 6
J10-13283-00	4-12	J17-21411-00	11- 8	J17-24111-00	15- 1
J17-13586-00	6- 7	J10-21486-00	11-12	J17-24129-00	15-32
345-13610-70	6- 1	J10-21744-00	15- 8	J17-2414H-00	15-33
345-13613-70	6- 2	J10-21745-00	10- 5	J17-24173-00	15-29
345-13616-70	6- 3	J17-21751-00	10- 1	J10-24311-00	15- 6
314-13621-02	6- 6	J17-21756-00	10- 4	J10-24312-00	15-10
J17-14101-00	7- 1	863-21771-00	10- 2	J10-24313-00	15-17

NUMERICAL INDEX

PART NO.	REF. NO.	PART NO.	REF. NO.	PART NO.	REF. NO.
J10-24366-00	15-15	J10-27281-00	17- 7	J17-7712F-00	26-22
J10-24410-02	15-22		17-23	J10-77125-00	26-19
J10-24461-00	15- 4	J10-27282-00	17- 8	J17-77145-00	26- 1
8E4-24461-00	22-18		17-24	J10-77146-00	26- 7
812-24461-00	9- 3	J10-27286-00	17-13	J17-77151-00	25-28
809-24560-01	15-12		17-29	J17-77152-00	25-29
J17-24611-00	15- 2	J17-27290-00	17-17	J17-77165-00	25-21
J10-24612-00	15- 3	J10-27852-00	18-10	J10-77188-00	26-24
J11-25100-00	13-61	J17-27853-00	18- 2	J11-77271-00	28-23
J11-25102-00	13-62	J10-27871-01	18- 5	J11-77272-00	28-24
	23- 9	J17-27872-00	18- 3	J11-77279-01	12-23
J17-25118-00	13-54	J17-27874-00	18- 1	J17-77525-00	24- 6
787-25170-00	13-64	J10-27911-00	19- 4		24-22
	23-11	J10-27912-00	19- 1	J10-77711-00	25-39
J11-25300-00	23- 8	J10-27913-00	19- 3	J10-77741-00	25-41
J17-25330-00	17- 4	J10-27921-01	19- 8	J10-77762-01	27-33
	17-20	J10-27922-00	19- 9	J10-77764-00	25-10
J17-25340-00	17- 3	J10-27927-00	19- 5	J10-77765-00	26-34
	17-19	J17-27951-00	19-14	J10-77766-00	26-20
J17-25654-00	16- 7	J10-27959-00	19-18	J11-77767-00	25-38
J17-25670-00	16-11	J10-27981-00	18-26	J10-77768-00	25-30
J17-25672-00	16-34	J10-46210-00	20- 1	J17-78106-00	24- 1
J17-25673-00	16-39	J10-46220-01	20- 5	J17-78107-00	24-17
J17-25679-00	16-23	J10-46223-01	20- 6	J18-78115-00	25-20
J10-25681-00	16-48	J17-46230-00	20- 7	J10-78119-00	25- 2
J17-25685-00	16-49	J10-46232-00	20- 8	J17-78121-00	25- 4
J17-26311-00	18-17	J10-46236-00	20- 9	J17-78123-00	26- 6
J10-26325-00	6-13	J17-46241-00	20-22	J10-78137-00	25- 7
J10-26331-02	6-12	J10-46244-00	20- 4	J10-78139-00	27-22
J17-26339-09	6-15	J10-46249-00	20-18	J17-78156-00	26-29
J17-26341-01	16-55	J10-46253-01	20-12	J17-78157-00	27-15
J17-26351-01	16-56	J17-46254-00	20-19	J17-78162-00	24- 2
J17-27204-00	17- 6	J17-46260-00	21- 1		24-18
J17-27205-00	17-22	J17-46270-00	21- 2	J17-78164-00	24- 7
J17-27206-00	17- 5	J10-46284-00	21- 5	J17-78165-00	24- 8
	17-21	J11-46311-00	22- 1	J10-78167-01	24- 3
J17-27208-00	17- 2	J10-46312-00	22-13		24-19
J17-27209-00	17-18	J10-46319-00	22-20	J10-78168-01	24- 4
J10-27211-00	16- 4	J10-46321-00	22-30		24-20
J17-27228-00	16-40	J17-46331-00	22-31	J10-78174-01	24-28
J17-27231-00	16-35	J17-46361-00	22-34	J10-78179-00	24-23
J17-27232-00	16-36	J17-46362-00	22-35	J17-78181-00	12- 9
J17-27238-00	17-11	J10-46414-00	22-39	J17-78187-00	12-11
J17-27245-00	16- 3	J10-46415-00	22-40	J17-78189-00	12-12
J17-27246-00	16-24	J17-46510-00	23- 6	J17-78191-00	26-33
J17-27250-00	16- 1	J17-46521-00	23- 7	J17-78192-00	26-38
J17-27258-00	17-27	J10-46540-00	23- 1	J17-78198-00	26-42
J17-27280-00	17- 1	835-47559-00	22-24	J17-78199-00	26-43

NUMERICAL INDEX

NUMERICAL INDEX

PART NO.	REF. NO.	PART NO.	REF. NO.	PART NO.	REF. NO.	PART NO.	REF. NO.	PART NO.	REF. NO.	PART NO.	REF. NO.
J17-78221-00	26- 2	J10-81110-10	30- 7	256-83936-00	18-18	90179-08378	16-22	90201-12588	21- 9	90381-15040	13-21
J17-78231-00	26-31	J10-81111-10	30-21		33-29	90179-10280	13-37	90201-20272	22-36	90384-05163	16-12
J17-78232-00	25-22	J10-81113-10	30-22	J10-85500-20	32- 1		27-23	90201-20275	19- 7	90384-10162	16-29
J17-78233-00	25-23	J10-81115-10	30-23	8G8-85511-20	32- 2	90179-12262	13-65	90202-06008	28-11	90384-12164	16-13
J10-78238-01	25-11	J10-81119-10	30-20	J10-85515-20	32- 4		23-12	90202-08022	27- 5	90384-14080	16- 2
J10-78239-00	25-15	J10-81129-10	30-30	J10-85540-20	32-15	90185-06098	10-11	90202-08085	26-12		18-12
J10-78245-00	25-40	J10-81139-10	30-31	2A7-85546-00	32-16		25- 6	90202-08110	19-11	90385-08034	19-15
J17-78249-00	12- 7	J10-81145-10	30-32	J10-85550-20	32-12		26-15	90202-08111	15-34	90386-06108	27-18
J17-78271-00	26-32	J10-81146-10	30-13	J10-85580-20	32- 3	90185-08106	13-44	90202-10129	20-20	90387-06026	6-36
J17-78272-00	25- 9	J10-81147-10	30-16	J17-85710-00	15- 9	90185-12061	14-37	90202-12133	17-16	90387-062E2	15-35
J17-78275-00	25-13	J10-81148-10	30- 9	J17-86126-00	32-28	90185-12093	13-39		17-32	90387-090G6	12-20
J11-78286-00	25-33	J10-81150-10	30- 2	J17-86127-00	32-29		13-46	90202-20130	21-12	90387-107F8	16- 6
J11-78287-00	25-32	J10-81157-10	30- 3	J17-86177-00	33-26		13-49	90206-06060	26-26	90387-137F6	13-47
J10-78291-00	25-25	J10-81158-10	30- 4	J10-87172-00	31- 5	90201-04M06	25-19	90206-11016	5- 7	90387-137F7	13-40
J10-78292-00	27-32	J10-81159-10	30- 5	J17-87183-00	31- 1	90201-04756	3-11	90209-14219	13-58	90387-21690	19- 2
J18-78301-00	28- 2	J10-81160-10	30- 8	90101-06410	31-20	90201-05034	12-14	90209-24073	2-10	90387-47686	20- 3
J18-78311-00	28- 3	J10-81161-00	31- 4	90101-06555	16-15		26-45	90214-16027	13-14	90401-06001	4- 2
J18-78312-00	28- 5	J10-81163-10	30-26	90101-10419	11- 3	90201-05036	25-45		13-30	90430-06180	4- 3
J18-78313-00	28- 6	J10-81165-10	30-14	90101-10447	16- 8	90201-06043	32-14	90215-13146	20-17	90430-08119	14-10
J11-78314-00	28- 1	J10-81166-10	30-15	90101-12545	31-10		32-22	90215-16161	14-36	90430-14043	22-22
J11-78316-00	28- 4	J17-81170-00	31-14	90102-12046	13-48		33-36	90249-05136	28-13	90430-14175	14-42
J18-78328-00	28-22	J10-81173-00	31- 9	90105-08225	13-43	90201-06071	10-10	90249-14129	16-52	90430-31003	10- 3
J11-78329-00	28-19	J10-81175-10	30- 6	90105-10224	13-36	90201-06074	8-13	90267-32019	25-16	90445-05214	4- 4
J11-78335-01	28-12	104-81328-20	32- 5	90105-12226	13-45	90201-06075	25-51	90267-40054	12- 4	90445-09069	15-25
J18-78336-00	28- 7	J10-81910-10	32-18	90106-08040	18- 8	90201-061E8	26-37		12-13	90445-09635	4- 8
J11-78338-00	28-25	J17-81950-00	32-24	90106-10034	11- 9		26-41		15-19	90445-10449	15-27
J11-78343-00	28-20	J17-82105-00	33- 4	90109-08653	31-16	90201-06557	3- 8	90267-40075	12- 6	90445-11151	15-20
J18-78349-00	28-29	J11-82110-70	33- 1	90109-08657	17-12		6-35		25- 3	90445-11288	15-16
J10-78351-00-9E	27- 1	J10-82115-00	33- 2	90109-08659	17-28		28-10		25- 8	90445-11634	4-13
J10-78352-00-9E	27- 2	J17-82116-00	33- 3	90109-08669	16-20	90201-06697	26-13		25-18	90460-41145	6-19
J10-78353-00-9E	27- 3	J17-82122-00	33-11	90109-10643	13- 9		26-14		26-44	90460-41146	6-11
J10-78355-00	27- 9	J17-82133-00	33- 9		13-25	90201-06750	16-31	90267-40077	24- 5	90460-50035	6-20
J10-78356-00	27- 8	J17-82136-00	33-10	90116-08254	1- 6	90201-06765	15-36		24-21	90461-10054	15-18
J10-78357-01	27-28	J14-82150-00	33- 7	90149-03132	6-14	90201-06778	11-17	90267-40090	12- 8	90462-08056	3- 6
J10-78358-00	27-29	1E6-82150-00	33- 5	90149-05129	20-13	90201-08107	15-30	90267-48040	3-10		33-18
J10-78361-00-93	29- 2	1E6-82151-00	33- 6	90170-05190	19-24	90201-08310	25-47		12-10	90464-12036	10- 7
J10-78362-00-93	29-14		33- 8	90170-08024	14-12		28-16	90267-63047	25-24		33-30
J10-78366-01	27-27	J17-82310-21	33-14	90170-10047	11-14		29-10	90269-06028	25-31	90464-25050	25-43
J10-78367-00	27-10	J17-82318-00	33-27	90170-12054	14-25		29-22	90269-65032	6-33	90465-06011	22-23
J17-78368-00	27-16	8G8-82318-00	33-19		14-30	90201-08624	4-15	90280-05013	2-18	90465-06038	33-17
J17-78369-00	27-17	512-82370-10	33-20	90170-12055	14-26	90201-08732	25-14	90280-05022	21- 7	90465-08028	3- 7
J10-78401-02	29- 1	J17-82508-20	33-21		14-31	90201-08766	24-14	90340-14029	14-39		22-27
		J17-82511-20	33-22	90170-16182	2-19	90201-105F2	13-11	90340-14036	22-21		33-24
J10-78403-02	29-13	J17-82550-00	33-23	90171-10035	13-12		13-27	90380-12051	16-14	90467-08017	15-26
		J17-82590-21	33-25		13-28	90201-114E6	6-37	90380-12105	16-45	90467-09005	4-10
J10-78439-00	29-11	366-82591-00	33-28	90171-12023	21-10	90201-121F0	13-10	90381-15032	13- 2	90467-09006	15-28
	29-23	J10-83383-02	33-31	90179-08261	16-53		13-26		13-18	90467-10026	4-11
J10-81100-10	30- 1	437-83525-00	26-28	90179-08278	1- 7	90201-123F2	16-43	90381-15040	13- 5	90467-10035	4-14

NUMERICAL INDEX

PART NO.	REF. NO.	PART NO.	REF. NO.
90467-11009	10-6	91490-25025	13-29
	15-11		13-60
	15-13	91490-30015	16-51
	15-21	91609-35028	18-11
90468-02033	4-5	91609-60025	18-4
90468-04092	15-7	91701-05010	6-16
90468-05112	19-25	91701-06012	26-25
90468-10049	6-17	91701-06026	25-34
90468-16065	26-23	91701-08018	16-58
90480-07241	25-46	91701-08020	26-21
90480-13238	6-23	91701-08118	26-8
90480-14100	6-29	91701-10022	16-50
90480-14239	6-24	91702-05012	18-19
90480-35242	25-17	91810-03014	22-43
90480-42282	29-12	91810-05016	22-19
90480-48243	25-42	91810-18027	5-13
90501-08256	25-36	91830-21014	9-2
90501-08430	4-9	92501-06012	5-15
90501-08486	15-14	92501-06018	5-14
90501-32696	20-14		15-23
90501-45600	21-8	92502-06010	22-28
90502-10013	27-30	92502-06016	3-3
90506-12277	16-38	92502-06025	31-6
90506-20074	8-6		33-15
90506-20281	17-9	92502-06045	9-4
	17-25	92502-06055	9-5
90506-23204	28-26	92502-06065	9-6
90506-26191	17-10	92503-06008	27-20
	17-26	92680-08035	29-6
90506-26282	18-16		29-18
90508-14548	16-33	92680-08050	28-15
90508-16460	18-22	92701-08045	27-4
90508-23542	16-19	92901-04100	32-9
90508-26557	16-44		32-11
90508-40398	19-16	92901-05100	32-7
90508-40543	16-5	92901-05600	16-41
90560-05001	18-23		26-4
90560-12180	20-16		27-34
91312-06035	26-30	92901-06100	30-12
91401-16010	18-20		30-19
91401-20015	25-37		30-28
91401-25015	26-9		30-34
91401-30025	13-34	92901-06600	30-11
	13-59		30-18
	14-34		30-33
	21-11	92901-08100	22-8
91490-25015	16-59		22-11
91490-25025	13-13	92901-08600	22-9

PART NO.	REF. NO.
92901-08600	22-12
92901-10100	11-10
	11-13
	14-41
	16-10
	22-26
	23-5
	29-4
	29-16
92902-05100	8-12
	20-11
	31-3
92902-05200	25-26
92902-06100	5-21
	6-9
	15-24
	16-17
	16-47
	17-14
	17-30
	18-7
	18-15
	22-29
	25-50
	26-36
	26-40
	27-21
	27-25
	31-7
	32-20
	33-16
	33-33
92902-06200	16-16
	26-27
	27-11
	33-13
92902-06600	3-4
	3-18
	5-22
	6-10
	25-35
	27-26
	31-8
	32-21
	33-34
92902-08100	5-17
	8-5
	12-18

PART NO.	REF. NO.
92902-08100	14-15
	16-21
	17-34
	22-42
	23-3
	24-10
	24-15
	24-30
	24-34
	26-17
	29-9
	29-21
	31-18
	32-26
	32-31
92902-08200	16-25
	24-26
	24-33
	32-30
92902-08600	5-18
	12-19
	24-11
	24-13
	24-25
	24-32
	26-18
	31-17
	32-27
92902-10600	11-11
	29-5
	29-17
	31-12
92902-12100	14-38
92902-12200	14-33
92902-12600	14-33
	31-11
92902-16100	2-20
92903-03100	6-5
92990-06100	27-13
92990-08100	27-6
	28-27
92990-08500	29-7
	29-19
92990-08600	28-30
93101-10090	5-2
93102-22082	14-3
93102-22189	22-6
	22-17
93102-25017	22-5

PART NO.	REF. NO.
93102-30128	2-17
93102-30188	2-15
93104-08058	19-13
93104-15005	14-13
93109-20014	21-3
93112-53004	5-12
93210-10166	16-30
93210-14104	18-13
93210-15414	13-6
	13-22
93210-27458	20-21
93306-00511	13-55
93306-00801	22-4
	22-16
93306-20324	22-14
93306-20401	22-3
	22-15
93306-20437	13-56
93306-20501	22-2
93306-20618	2-14
93306-30621	2-13
93306-90601	20-2
93310-218A6	2-5
93310-424E8	2-11
93332-00010	14-5
	14-16
93342-22502	19-6
93410-10025	5-9
93410-25017	22-32
93410-28051	20-15
93430-04003	16-42
	28-14
93430-05033	27-19
93430-06005	19-12
	25-12
93430-07012	18-21
93430-09019	16-57
93450-20026	2-4
93450-72048	2-16
93603-22028	5-6
93700-06004	13-4
	13-20
94118-85507	13-63
94118-85508	23-10
94701-00168	1-3
95301-06600	30-10
	30-17
95301-08700	13-16

PART NO.	REF. NO.
95301-08700	13-32
	16-54
	18-9
	32-25
95301-08800	24-27
95301-14600	30-27
95302-05700	19-19
	19-22
95302-06600	11-18
	16-18
	17-15
	17-31
	19-17
	32-23
	33-35
95302-06700	16-37
	18-25
	31-21
95302-08600	24-16
	24-35
	31-19
	32-32
95302-12600	31-13
95302-12900	14-32
95302-14900	13-57
95380-06800	27-14
95380-08800	27-7
	28-28
95602-05100	26-5
95602-06100	15-37
	16-32
95602-08100	15-31
	28-21
95602-10100	11-7
	16-9
95612-08100	8-9
	16-27
95612-10100	11-4
	13-52
95680-08100	28-18
95702-05300	25-27
95702-06300	33-12
95702-08100	12-21
95702-12300	13-35
95702-16300	14-35
95802-06050	3-15
95822-06012	3-13
95822-06035	5-19

NUMERICAL INDEX

PART NO.	REF. NO.	PART NO.	REF. NO.	PART NO.	REF. NO.
95822-12085	13-38	97701-50130	25-44		
97301-06016	3- 5	97701-60116	28- 9		
	10- 9	97702-50125	27-31		
	32-19	98501-04008	19-10		
	33-32		32-10		
97302-06014	18-14	98501-04020	32- 8		
97302-06020	25-49	98501-05008	31- 2		
	26-35	98501-05016	4- 7		
	26-39		30-24		
97302-06022	6-34	98501-05018	30-29		
97302-06025	18- 6	98501-05020	20-10		
	18-24		32- 6		
97302-06030	6- 8	98502-03008	6- 4		
97302-06060	3-17	98502-05012	8-11		
97302-08014	24-24	98502-05018	26- 3		
97302-08020	14-14	98503-04010	30-25		
97302-08025	29- 8	98901-06014	32-13		
	29-20	98901-06016	25- 5		
	31-15	98902-08025	25-48		
97302-08030	13-15	98980-06016	27-12		
	13-31	98980-06020	26-10		
97302-08065	12-17	98980-06025	26-11		
97302-10030	29- 3				
	29-15				
97302-10050	11- 6	SPECIAL TOOLS			
	14-40	ACC-11401-01-00	35- 5		
97312-08025	16-26	ACC-11401-02-00	35-15		
97312-08030	22-41	ACC-11401-03-00	35-18		
97321-08035	22- 7	90890-01051-00	35- 2		
97321-08045	22-10	90890-01135-00	35- 1		
97322-06016	16-46	90890-01202-00	35- 7		
97322-06030	5-20	90890-01235-00	35- 3		
97322-06065	27-24	90890-01876-00	35-11		
97322-08016	17-33	90890-01886-00	35-19		
	24- 9	90890-02202-00	35-17		
	24-29	90890-02203-00	35-14		
97322-08020	24-31	90890-02204-00	35-13		
	26-16	90890-02213-00	35-16		
97322-08025	8- 4	90890-02300-00	35-12		
	23- 2	90890-90058-00	35- 4		
	24-12	90890-90059-00	35- 8		
97322-08035	5-16	90890-90060-00	35- 9		
97322-10020	22-25	90890-90067-00	35- 6		
	23- 4	90890-90105-10	35-10		
97322-10050	13-51				
97375-08060	28-17				
97602-03108	7-18				

PARTS NAME INDEX

PARTS NAME INDEX

PARTS NAME INDEX

DESCRIPTION	REF. NO.
AIR CLEANER ASSY	6-21
AIR SHROUD, cylinder 1	3- 1
AIR SHROUD, cylinder 2	3- 2
AIR VALVE ASSY	13-64
*	23-11
ANCHOR BODY COMP.	17- 5
*	17-21
ARM REST 1	29- 2
ARM REST 2	29-14
ARM, accelerator Pedal	18- 3
ARM, idler	14-21
ARM, knuckle 1	13- 8
ARM, knuckle 2	13-24
ARM, Pitman	14- 1
ARMATURE ASSY	30- 2
ASH TRAY	25-32
BACKING PLATE ASSY (L.H)	17-17
BACKING PLATE ASSY (R.H)	17- 1
BACKING PLATE SUB ASSY 1	17- 2
BACKING PLATE SUB ASSY 2	17-18
BAND	27- 9
*	32-16
*	33-28
BAND, muffler	8- 8
BAND, switch cord	18-18
*	33-29
BAND, tank fitting	10- 8
BAND, tank fitting 1	15-29
BASE, lock	27-15
BATTERY ASSY (F.B. N50)	33- 1
BEARING	13-55
*	13-56
*	14- 5
*	14-16
*	19- 6
*	22-14
BEARING (B600B)	22- 4
*	22-16
BEARING (B6204)	22- 3
*	22-15
BEARING (B6205)	22- 2
BEARING (B6206)	2-14
BEARING (B6306)	2-13
BEARING (B6906)	20- 2
BEARING 1 (6202 SD)	30- 3
BEARING 2 (6203 SD)	30- 4
BEARING, cylindrical	2- 5
*	2-11

DESCRIPTION	REF. NO.
BELT	20-22
*	31- 9
BODY, caP	10- 2
*	15- 2
BODY, float chamber 1	7- 3
BOLT	3- 5
*	3-17
*	5-16
*	5-20
*	6- 8
*	6-34
*	8- 4
*	10- 9
*	11- 3
*	11- 6
*	11- 9
*	12-17
*	13- 9
*	13-15
*	13-25
*	13-31
*	13-51
*	14- 4
*	14-11
*	14-14
*	14-40
*	16- 8
*	16-15
*	16-20
*	16-26
*	16-46
*	17-12
*	17-28
*	17-33
*	18- 6
*	18- 8
*	18-14
*	18-24
*	20-18
*	22- 7
*	22-10
*	22-25
*	22-41
*	23- 2
*	23- 4
*	24- 9
*	24-12
*	24-24

DESCRIPTION	REF. NO.
BOLT	24-29
*	24-31
*	25-49
*	26-16
*	26-30
*	26-35
*	26-39
*	27-24
*	28-17
*	29- 3
*	29- 8
*	29-15
*	29-20
*	31-10
*	31-15
*	31-16
*	31-20
*	32-19
*	33-32
BOLT, flange	3-13
*	3-15
*	5-19
*	13-38
BOLT, stud	1- 6
BOLT, union	4- 2
BOLT, washer based	13-36
*	13-43
*	13-45
BOLT, with hole	13-48
BOOT	6-15
BOX	32-17
BRACKET	7-16
BRACKET, accelerator Pedal	18- 1
BRACKET, engine 1	11- 8
BRACKET, Pedal	16- 7
BRACKET, starter Generator 1	30-14
BRACKET, starter Generator 2	30-15
BRACKET, throttle	18-26
BRAKE ARM COMP.	16- 1
BRAKE SHOE COMP.	17- 3
*	17- 4
*	17-19
*	17-20
BREATHER	15- 8
BRUSH	30-21
BRUSH HOLDER ASSY	30-20
BUMPER SUB-ASSY, front	24- 1
BUMPER SUB-ASSY, rear	24-17

PARTS NAME INDEX

DESCRIPTION	REF. NO.
BUMPER, rubber 1	24- 3
*	24-19
BUMPER, rubber 2	24- 4
*	24-20
BUSH	13- 3
*	13-19
*	13-42
*	19-15
*	27-18
BUSH 1	11- 2
BUSH, bimetal formed	16- 2
*	16-12
*	16-13
*	16-29
*	18-12
BUSH, solid	13- 2
*	13- 5
*	13-18
*	13-21
*	16-14
*	16-45
BUZZER	33-31
C.D.I. MAGNETO ASSY	32- 1
C.D.I. UNIT ASSY	32-15
CABLE, brake	16-55
*	16-56
CABLE, starter 1	6-12
CABLE, throttle 1	18-17
CAM	20- 6
CAP 2	22-24
CAP, cleaner case 1	6-25
CAP, end	27-22
CAP, support roof	28-29
CARBURETOR ASSY 1	7- 1
CASE, air cleaner 1	6-22
CASE, differential	22-37
CASE, fan	3-14
CASE, transmission 1	22- 1
CASE, transmission 2	22-13
CIRCLIP	2- 4
*	2-16
*	5- 9
*	16-42
*	16-57
*	18-21
*	19-12
*	20-15
*	22-32

PARTS NAME INDEX

DESCRIPTION	REF. NO.
CIRCLIP	25-12
*	27-19
*	28-14
CLAMP	3- 6
*	3- 7
*	10- 7
*	15-18
*	22-23
*	22-27
*	25-43
*	32- 5
*	33-17
*	33-18
*	33-24
*	33-30
CLAMP, fuel Pipe 1	15-15
CLAMP, hose	6-11
*	6-19
*	6-20
CLAMP, support	27-27
CLIP	4- 5
*	4-10
*	4-11
*	4-14
*	6-17
*	10- 6
*	15- 7
*	15-11
*	15-13
*	15-21
*	15-26
*	15-28
*	19-25
*	26-23
*	26-28
COIL, Pulser	32- 3
COIL, source	32- 2
COLLAR	6-36
*	12-20
*	13-40
*	13-47
*	15-35
*	16- 6
*	19- 2
*	20- 3
COLUMN, steering	14-18
COVER 1	5- 1
*	6-30

PARTS NAME INDEX

DESCRIPTION	REF. NO.
COVER 2	5-11
COVER, brush	30-30
COVER, brush 2	30-31
COVER, dust	17-13
*	17-29
COVER, fan case	3-16
COVER, fuel inlet	25- 9
COVER, hub dust	13-54
COVER, side 1	15-32
COVER, steering	14- 8
COVER, sun roof	28- 1
COWL, front	25-20
CRANK 1	2- 7
CRANK 2	2- 8
CRANKCASE ASSY	9- 1
CRANKSHAFT ASSY	2- 6
CUP 1	18-10
CYLINDER 1	1- 4
DAMPER	16-23
*	28- 4
DAMPER 1	11-16
DAMPER 2	11-12
DAMPER, brake	16-39
DAMPER, noise 11	28-23
DAMPER, noise 12	28-24
DAMPER, noise 19	12-23
DEFLECTOR 1	3- 9
DEFLECTOR 3	6-31
DRUM	23- 7
ELEMENT ASSY, air cleaner	6-27
EMBLEM 1	25-25
EMBLEM 2	27-32
END, rod 2	16-36
EQUALIZER, brake	16-48
EXHAUST PIPE ASSY 1	8- 7
FAN	3-12
FAN, Generator	31- 5
FASTENER, lower	25-15
FASTENER, upper	25-11
FIELD, COIL ASSY	30- 8
FILTER ASSY	15-12
FLAP, front fender	12-11
FLAP, front fender (R.H)	12-12
FLAP, rear 2	26-43
FLOAT	7-15
FORK, Governor	19- 9
FRAME COMP.	12- 1
FRAME COMP., roof	28- 2

PARTS NAME INDEX

DESCRIPTION	REF. NO.
FRAME, sun roof	28-3
FRONT LOWER ARM COMP.(L.H)	13-1
FRONT LOWER ARM COMP.(R.H)	13-17
FRONT WHEEL ASSY	13-61
FUEL LEVEL GAUGE ASSY	15-9
FUEL PUMP ASSY	15-22
FUSE (6V-10A)	33-6
*	33-8
FUSE HOLDER ASSY	33-5
*	33-7
GASKET	4-3
*	7-6
*	10-3
*	14-10
*	14-42
*	22-20
*	22-22
GASKET 2	5-10
GASKET, air cleaner	6-26
GASKET, cap	15-3
GASKET, cylinder	1-5
GASKET, cylinder head 1	1-2
GASKET, exhaust pipe	8-3
GASKET, float chamber	7-2
GASKET, pump case	4-6
GASKET, valve seat	6-6
GEAR, counter 1	22-34
GEAR, counter 2	22-35
GEAR, differential side	22-39
GEAR, drive	5-5
GEAR, input 1	22-31
GEAR, ring	22-38
GROMMET	6-23
*	16-24
*	16-29
*	15-5
*	25-17
*	25-42
*	25-46
*	29-12
HEAD, cylinder 1	1-1
HINGE 1	26-1
HINGE 2	26-7
HINGE, fuel inlet	25-13
HOLDER	19-4
HOLDER 1	27-28
HOLDER 2	27-29
HOLDER, bearing	30-5

PARTS NAME INDEX

DESCRIPTION	REF. NO.
HOLDER, handle upper	14-17
HOLDER, nozzle	7-7
HOOK	6-32
HOSE	4-4
*	4-8
*	4-13
*	15-16
*	15-20
*	15-25
*	15-27
HUB, front	13-53
IGNITION COIL ASSY	33-14
INDICATOR 1	25-41
INSULATOR, generator	31-1
JET, main (#095.0)	7-5
JET, Pilot (#32.5)	7-11
JET, senser	4-12
JOINT	19-21
*	19-23
JOINT, air cleaner 1	6-18
JOINT, carburetor 1	6-7
JOINT, universal 1	14-23
*	14-28
JOINT, universal 2	14-24
*	14-29
KEY	30-26
KEY, main switch	33-22
KEY, woodruff	2-18
*	21-7
KING PIN, steering knuckle	13-33
KNOB, starter	6-13
KNUCKLE, steering comp.	13-7
*	13-23
LABEL, warning	25-30
LABEL, warning 2	27-33
LABEL, warning 4	25-10
LABEL, warning 5	26-34
LABEL, warning 6	26-20
LABEL, warning 7	25-38
LEAD WIRE ASSY	32-4
LEVER ASSY 1	17-6
LEVER ASSY 2	17-22
LEVER, lock	27-16
LEVER, speed limiter	19-14
LID, ash tray	25-33
LIFTER	19-5
LOCK, side wind	28-12
MAIN SWITCH ASSY	33-21

PARTS NAME INDEX

DESCRIPTION	REF. NO.
MAT, main floor 1	26-31
MAT, main floor 2	25-22
MAT, main floor 3	25-23
MEMBER, cross roof	28-7
METAL, worm shaft outer	5-3
NAIL, brake	16-24
NEEDLE VALVE ASSY	7-13
NET, filter	10-4
NIPPLE, grease	13-4
*	13-20
NOZZLE, main	7-4
NUT	1-7
*	2-19
*	11-14
*	11-18
*	13-16
*	13-32
*	13-37
*	13-57
*	13-65
*	14-6
*	14-12
*	14-25
*	14-26
*	14-30
*	14-31
*	16-18
*	16-22
*	16-37
*	16-53
*	16-54
*	17-15
*	17-31
*	18-9
*	18-25
*	19-17
*	19-19
*	19-22
*	19-24
*	23-12
*	24-16
*	24-35
*	27-14
*	27-23
*	30-10
*	30-17
*	30-27
*	31-13

PARTS NAME INDEX

DESCRIPTION	REF. NO.
NUT	31-19
*	31-21
*	32-23
*	32-25
*	32-32
*	33-35
NUT, adjusting	17-11
*	17-27
NUT, castle	13-12
*	13-28
*	21-10
NUT, crown	24-27
*	27- 7
*	28-28
NUT, flange	12-21
NUT, nylon	13-35
*	14-35
*	25-27
*	33-12
NUT, ring	8- 1
NUT, self-locking	10-11
*	13-39
*	13-44
*	13-46
*	13-49
*	14-37
*	25- 6
*	26-15
NUT, slotted	14-32
NUT, u	8- 9
*	11- 4
*	11- 7
*	13-52
*	15-31
*	15-37
*	16- 9
*	16-27
*	16-32
*	26- 5
*	28-18
*	28-21
O-RING	13- 6
*	13-22
*	16-30
*	18-13
*	20-21
OIL PUMP ASSY	4- 1
OIL SEAL	2-15

PARTS NAME INDEX

DESCRIPTION	REF. NO.
OIL SEAL	2-17
*	5- 2
*	5-12
*	14- 3
*	14-13
*	19-13
*	21- 3
*	22- 5
*	22- 6
*	22-17
PAD 1	25-28
PAD 2	25-29
PAD, bag support	27- 8
PAD, brake Pedal	16- 3
PAD, front bumper	24- 2
*	24-18
PAD, Parking Pedal	16-34
PANEL 1	12- 2
PANEL 2	12- 3
PANEL 3	12- 5
PANEL, body shell	25- 1
PANEL, instrument	25-39
PANEL, rear fender 1	26-33
PANEL, rear fender 2	26-38
PARKING PEDAL COMP.	16-11
PARTITION, air cleaner case	6-28
PEDAL, accelerator	18- 5
PEDAL, brake	16- 4
PIN	16-52
*	28-13
PIN, clevis	6-16
*	16-50
*	16-58
*	18-19
*	25-34
*	26- 8
*	26-21
*	26-25
PIN, cotter	13-13
*	13-29
*	13-34
*	13-59
*	13-60
*	14-34
*	16-51
*	16-59
*	18-20
*	21-11

PARTS NAME INDEX

DESCRIPTION	REF. NO.
PIN, cotter	25-37
*	26- 9
PIN, crank 1	2- 9
PIN, dowel	5- 6
*	5-13
*	9- 2
*	22-19
*	22-43
PIN, float	7-14
PIN, joint	16-40
PIN, lever	27-17
PIN, Piston	2- 3
PIN, Pitman	14- 2
PIN, shoe hold down	17- 8
*	17-24
PIN, spring	18- 4
*	18-11
PIN, weight	20- 9
PINION, differential	22-40
PIPE 2	15-10
PIPE 3	15-17
PIPE, fuel 1	15- 6
PIPE, joint	9- 3
*	15- 4
*	22-18
PIPE, oil tank breather	10- 5
PISTON (STD)	2- 1
*	2- 1
PISTON (1ST O/S 0.25MM)	2- 1
PISTON (2ND O/S 0.50MM)	2- 1
PISTON RING SET (STD)	2- 2
PISTON RING SET (1ST O/S)	2- 2
PISTON RING SET (2ND O/S)	2- 2
PLATE	7-17
PLATE 1	12- 9
PLATE 3	25- 2
PLATE 4	25- 7
PLATE, anchor	27-10
PLATE, battery fitting	33-10
PLATE, cam thrust	5- 8
PLATE, connecting 1	32-28
PLATE, connecting 2	32-29
PLATE, extension	24-23
PLATE, silencer 1	8-10
PLUG CAP ASSY	33-20
PLUG, spark (NGK BP5HS)	1- 3
PLUG, straight screw	14-39
*	22-21

PARTS NAME INDEX

PARTS NAME INDEX

PARTS NAME INDEX

DESCRIPTION	REF. NO.	DESCRIPTION	REF. NO.	DESCRIPTION	REF. NO.
PRIMARY FIXED SHEAVE COMP.	20- 1	SCREW, adjusting	19-18	SEAT, battery	33-11
PRIMARY SHEAVE CAP COMP.	20- 7	SCREW, bind	25- 5	SEAT, secondary spring	21- 5
PRIMARY SLIDING SHEAVE COMP.	20- 5	*	25-48	SEAT, spring	20- 4
PULLEY	31- 4	*	26-10	SECONDARY FIXED SHEAVE COMP.	21- 1
REAR ARM COMP.	11- 1	*	26-11	SECONDARY SLIDING SHEAVE COMP.	21- 2
REAR AXLE HOUSING COMP.	23- 1	*	27-12	SECTOR, parking brake	16-28
REAR AXLE SHAFT COMP.	23- 6	*	32-13	SERVICE LID, pedal	26-32
REAR WHEEL ASSY	23- 8	SCREW, fitting	33- 9	SHAFT, counter	22-33
REED VALVE ASSY	6- 1	SCREW, flat head	27- 4	SHAFT, governor	19- 8
REED, valve	6- 2	SCREW, oval head	28-15	SHAFT, input	22-30
REINFORCEMENT 1	25- 4	*	29- 6	SHAFT, pedal 1	18- 2
REINFORCEMENT 3	26- 6	*	29-18	SHAFT, worm	5- 4
RELAY ASSY	32-24	SCREW, Pan head	3- 3	SHEET, body mounting 1	26- 2
RETAINER	19- 1	*	4- 7	SHOCK ABSORBER ASSY	13-50
*	28-20	*	5-14	SHOCK ABSORBER ASSY, rear	11- 5
RETAINER, flap	26-42	*	5-15	SHOE, ramp	21- 4
RING	8- 2	*	6- 4	*	21- 6
RIVET	6-33	*	8-11	SLIDER	20-12
*	25-31	*	9- 4	SPACER	18-23
RIVET, blind	3-10	*	9- 5	*	20-16
*	12- 4	*	9- 6	SPACER 1	28-22
*	12- 6	*	15-23	SPACER 2	28-19
*	12- 8	*	19-10	SPACER 3	28-25
*	12-10	*	20-10	SPACER, damper	20-19
*	12-13	*	22-28	SPACER, stay	26-22
*	15-19	*	26- 3	SPRING, brush	30-22
*	24- 5	*	27-20	SPRING, compression	4- 9
*	24-21	*	30-24	*	15-14
*	25- 3	*	30-25	*	20-14
*	25- 8	*	30-29	*	21- 8
*	25-16	*	31- 2	*	25-36
*	25-18	*	31- 6	SPRING, conical	27-30
*	25-24	*	32- 6	SPRING, Pilot adjusting	7- 8
*	26-44	*	32- 8	SPRING, shoe clamp	17- 7
ROD	16-49	*	32-10	*	17-23
*	19-20	*	33-15	SPRING, tension	8- 6
ROD, brake	16-35	SCREW, Pan head with washer	7-18	*	16-38
ROD, connecting	2-12	SCREW, Pilot adjusting	7- 9	*	17- 9
ROD, tension	13-41	SCREW, tapping	25-44	*	17-10
ROD, tie	14-22	*	27-31	*	17-25
*	14-27	*	28- 9	*	17-26
ROTOR ASSY	32-12	SCREW, throttle	7-10	*	18-16
SCREW	6-14	SEAL 1	25-40	*	28-26
*	20-13	SEAL, steering	14- 9	SPRING, torsion	16- 5
SCREW 1	30-32	SEAT SUB-ASSY, cushion 2	29-13	*	16-19
SCREW 2	30-13	*	29-13	*	16-33
SCREW 3	30-16	SEAT SUB-ASSY, cushion	29- 1	*	16-44
SCREW 4	30- 9	*	29- 1	*	18-22

PARTS NAME INDEX

DESCRIPTION	REF. NO.
SPRING, torsion	19-16
STARTER GENERATOR ASSY	30- 1
STATOR ASSY	30- 7
STAY 1	26-19
STAY, front bumper 1	24- 7
STAY, front bumper 2	24- 8
STAY, rear bumper	24-28
STEERING SHAFT ASSY	14-19
STOP SWITCH ASSY	33-23
STOPPER	26-24
STOPPER 1	30- 6
STOPPER, lock	26-29
STOPPER, reed valve	6- 3
SUN-ROOF BRACKET KIT	28- 8
SUPPORT 1	12-15
SUPPORT 2	12-16
SUPPORT, bag lower 1	27- 2
SUPPORT, bag lower 2	27- 3
SUPPORT, bag upper	27- 1
SUPPORT, front cowl	12-22
SUPPORT, sun roof 1	28- 5
SUPPORT, sun roof 2	28- 6
TANK, fuel	15- 1
TANK, oil	10- 1
TENSIONER ASSY	31-14
TENSIONER 1	11-15
TIRE	13-63
*	23-10
TRIM 1	25-21
TRIM, cover Panel	15-33
TRIM, floor	12- 7
VOLTAGE REGULATOR ASSY	32-18
WASHER	2-10
*	2-20
*	3- 4
*	3-18
*	5-22
*	6-10
*	13-58
*	14- 7
*	14-38
*	16-16
*	16-25
*	24-26
*	24-33
*	25-26
*	25-35
*	26-27

PARTS NAME INDEX

DESCRIPTION	REF. NO.
WASHER	27-11
*	27-26
*	29- 7
*	29-19
*	31- 8
*	32-21
*	32-30
*	33-13
*	33-34
WASHER 1	24- 6
*	24-22
WASHER, claw	13-14
*	13-30
WASHER, lock	14-36
*	20-17
WASHER, needle valve	7-12
WASHER, Plate	3- 8
*	3-11
*	4-15
*	5-18
*	6-35
*	6-37
*	8-13
*	10-10
*	11-11
*	11-17
*	12-14
*	12-19
*	13-10
*	13-11
*	13-26
*	13-27
*	14-33
*	15-30
*	15-34
*	15-36
*	16-31
*	16-41
*	16-43
*	17-16
*	17-32
*	19- 7
*	19-11
*	20-20
*	21- 9
*	21-12
*	22- 9
*	22-12

PARTS NAME INDEX

DESCRIPTION	REF. NO.
WASHER, Plate	22-36
*	24-11
*	24-13
*	24-14
*	24-25
*	24-32
*	25-14
*	25-19
*	25-45
*	25-47
*	25-51
*	26- 4
*	26-12
*	26-13
*	26-14
*	26-18
*	26-37
*	26-41
*	26-45
*	27- 5
*	27-34
*	28-10
*	28-11
*	28-16
*	28-30
*	29- 5
*	29-10
*	29-17
*	29-22
*	30-11
*	30-18
*	30-33
*	31-11
*	31-17
*	32-14
*	32-22
*	32-27
*	33-36
WASHER, seat	29-11
*	29-23
WASHER, spring	5-17
*	5-21
*	6- 5
*	6- 9
*	8- 5
*	8-12
*	11-10
*	11-13

COPY RIGHT: ALL RIGHTS RESERVED
NO PART OF THIS PUBLICATION MAY BE
REPRODUCED WITHOUT PERMISSION.



PRINTED IN JAPAN
First edition Nov., 1981

TG