

YAMAHA

PARTS CATALOGUE

G1-AM4 (J32)

24J32-700E1

FOREWORD

This Parts Catalogue is related to the parts in use for the Yamaha Golf Car G1-AM4 (J32).
When you are ordering replacement parts for the G1-AM4 (J32), refer to this Parts Catalogue and quote both part numbers and part names correctly.

1. Modifications or additions which have been made after issue of the Parts Catalogue will be announced in the Yamaha Parts News.

It is advisable that according to the Yamaha Parts news you make necessary corrections to the Parts Catalogue on hand to keep it up-to-date.

2. Abbreviations

The following abbreviations are used in this Parts Catalogue.

- U.R. Use size (thickness) and/or number as required.
- U.N. Use as many as you need.
- A.P. Alternate Parts
- L.M. Local Made
- F# Frame No. (Applicable machine No.)

3. The parts marked with (*) in the parts number column of this Catalogue are not supplied with by Yamaha, those have to be found locally.
4. Parts, which are to be supplied in the form of assemblies, are listed with an indentation of one letter's space, and a dot (.) is put against the name of each part.

EXAMPLE CARBURETOR ASS'Y
. JET, pilot

5. Initial Serial No.

(A) Frame Serial No.	J32-000101 and following
(B) Engine Serial No.	J32-000101 and following






FIG. 1 CYLINDER




REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	J10-11111-00	HEAD, cylinder 1	1	
2	J10-11181-00	GASKET, cylinder head 1	1	
3	94701-00108	PLUG, sPark (NGK BP6HS)	1	
4	J10-11311-00	CYLINDER 1	1	
5	881-11351-01	GASKET, cylinder	1	
6	90116-08254	BOLT, stud	4	
7	90179-08278	NUT	4	
8	J24-11127-00	ABSORBER 3	1	


J24100-3010

B2

FIG. 2 CRANKSHAFT, PISTON




REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	J10-11631-00-96	PISTON (STD)	1	UR
	J10-11631-00-98	PISTON (STD)	1	UR
	J10-11635-00	PISTON (0.25MM O/S)	1	AP
	J10-11636-00	PISTON (0.50MM O/S)	1	AP
2	J10-11610-00	PISTON RING SET (STD)	1	
	J10-11610-10	PISTON RING SET (1ST O/S)	1	AP
	J10-11610-20	PISTON RING SET (2ND O/S)	1	AP
3	818-11633-00	PIN, Piston	1	
4	93450-20026	CIRCLIP	2	
5	93310-218A6	BEARING, cylindrical	1	
6	J10-11400-00	CRANKSHAFT ASSY	1	
7	J10-11412-00	.CRANK 1	1	
8	J10-11422-00	.CRANK 2	1	
9	857-11681-00	.PIN, crank 1	1	
10	90209-24073	.WASHER	2	
11	93310-42497	.BEARING, cylindrical	1	
12	881-11651-00	.ROD, connectin	1	
13	93306-30621	BEARING (B6306)	1	
14	93306-20618	BEARING (B6206)	1	
15	93102-30188	OIL SEAL	1	
16	93450-72048	CIRCLIP	1	
17	93102-30128	OIL SEAL	1	
18	90280-05013	KEY, woodruff	1	
19	90170-16182	NUT	1	
20	92902-16100	WASHER	1	

J24100-3020

B3

FIG. 3 AIR SHROUD. FAN




J24100-3030

B4

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	J10-12651-00	AIR SHROUD, cylinder 1	1	
2	J24-12652-00	AIR SHROUD, cylinder 2	1	
3	92502-06016	SCREW, Pan head	5	
4	92902-06600	WASHER	5	
5	97301-06016	BOLT	4	
6	90462-08056	CLAMP	1	
7	90201-06557	WASHER, Plate	4	
8	J10-12631-00	DEFLECTOR 1	1	
9	90267-48040	RIVET, blind	3	
10	90201-04756	WASHER, Plate	3	
11	8G8-12611-01	FAN	1	
12	95822-06012	BOLT, flange	6	
13	J17-12621-00	CASE, fan	1	
14	95802-06050	BOLT, flange	1	
15	J24-12616-00	COVER, fan case	1	
16	97302-06060	BOLT	4	
17	92902-06600	WASHER	4	

FIG. 4 OIL PUMP




REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	J24-13101-00	OIL PUMP ASSY	1	
2	90401-06001	.BOLT, union	1	
3	90430-06180	.GASKET	1	
4	90445-05214	.HOSE	1	
5	90468-02033	.CLIP	2	
6	126-13116-00	GASKET, Pump case	1	
7	98501-05016	SCREW, Pan head	2	
8	90445-09635	HOSE	1	
9	90501-08430	SPRING, compression	1	
10	90467-09005	CLIP	1	
11	90467-09026	CLIP	1	
12	J10-13283-00	JET, senser	1	
13	90445-11634	HOSE	1	
14	90467-10035	CLIP	2	
15	90201-08624	WASHER, Plate	1	


J24100-3040

B5

FIG. 5 PUMP DRIVE GEAR




REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	J10-15416-00	COVER 1	1	
2	93101-10090	OIL SEAL	1	
3	137-13176-00	METAL, worm shaft outer	1	
4	J10-13175-00	SHAFT, worm	1	
5	J10-13188-00	GEAR, drive	1	
6	93603-22028	PIN, dowel	1	
7	90206-11016	WASHER, wave	1	
8	137-13148-00	PLATE, cam thrust	1	
9	93410-10025	CIRCLIP	1	
10	J10-15466-00	GASKET 2	1	
11	J10-15426-00	COVER 2	1	
12	93112-53004	OIL SEAL	1	
13	91810-18027	PIN, dowel	2	
14	92501-06018	SCREW, Pan head	1	
15	92501-06012	SCREW, Pan head	1	
16	97322-08035	BOLT	1	
17	92902-08100	WASHER, sPring	1	
18	92902-08600	WASHER, Plate	1	
19	95822-06035	BOLT, flange	2	
20	97322-06030	BOLT	1	
21	92902-06100	WASHER, sPring	1	
22	92902-06600	WASHER	1	



J24100-3050

B6


FIG. 6 INTAKE



REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	885-13610-00	REED VALVE ASSY	1	
2	1L8-13613-00	.REED, valve	2	
3	885-13616-01	.STOPPER, reed valve	2	
4	97602-03108	.SCREW, Pan head with washer	4	
5	10V-13621-00	GASKET, valve seat	1	
6	J24-13586-00	JOINT, carburetor 1	1	
7	97302-06030	BOLT	4	
8	92902-06100	WASHER, sPrin8	4	
9	92902-06600	WASHER	4	
10	90460-41146	CLAMP, hose	1	
11	J10-26331-02	CABLE, starter 1	1	
12	J10-26325-00	.KNOB, starter	1	
13	90149-03132	.SCREW	1	
14	J17-26339-09	.BOOT	1	
15	91701-05010	PIN, clevis	1	
16	90468-10049	CLIP	1	
17	J10-14453-00	JOINT, air cleaner 1	1	
18	90460-41191	CLAMP, hose	1	
19	90460-53239	CLAMP, hose	1	
20	J17-14410-00	AIR CLEANER ASSY	1	
21	J10-14411-00	.CASE, air cleaner 1	1	
22	90480-13238	.GROMMET	2	
23	90480-14239	.GROMMET	2	
24	J17-14412-00	.CAP, cleaner case 1	1	
25	J10-14416-00	.GASKET, air cleaner	1	
26	J10-14450-10	ELEMENT ASSY, air cleaner	1	
27	J10-1441F-00	PARTITION, air cleaner case	1	
28	90480-14100	GROMMET	1	

B7


FIG. 6 INTAKE



REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
29	J10-14417-00	COVER 1	1	
30	J17-12644-00	DEFLECTOR 3	1	
31	J10-14436-00	HOOK	3	
32	90269-65032	RIVET	1	
33	97302-06022	BOLT	2	
34	90201-06557	WASHER, Plate	1	
35	90387-06026	COLLAR	2	
36	90201-114E6	WASHER, Plate	1	
37	J24-13581-00	CHAMBER, air	1	
38	J24-14388-00	VALVE, vacuum control	1	
39	90468-08104	CLIP	2	
40	90468-02025	CLIP	1	
41	90462-08056	CLAMP	1	

B8


FIG. 7 CARBURETOR



REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	J24-14101-00	CARBURETOR ASSY 1	1	
2	796-14184-00	.GASKET, float chamber	1	
3	796-14181-00	.BODY, float chamber 1	1	
4	J17-14141-00	.NOZZLE, main	1	
5	256-14944-19	.JET, main (# 95)	1	
6	732-14237-00	.GASKET	1	
7	J10-14244-00	.HOLDER, nozzle	1	
8	620-14212-00	.SPRING, Pilot adjusting	2	
9	620-14211-00	.SCREW, Pilot adjusting	1	
10	J10-14122-00	.SCREW, throttle	1	
11	620-14142-32	.JET, Pilot (# 32.5)	1	
12	127-14195-00	.WASHER, needle valve	1	
13	353-14190-10	.NEEDLE VALVE ASSY	1	
14	796-14186-00	.PIN, float	1	
15	796-14185-00	.FLOAT	1	
16	J10-14581-00	.BRACKET	1	
17	J10-14243-00	.PLATE	1	
18	97602-03108	.SCREW, Pan head with washer	2	


J24100-3070

FIG. B EXHAUST




J24100-3080

B10

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	J24-14612-00	NUT, ring	1	
2	888-14633-00	RING	2	
3	J10-14613-00	GASKET, exhaust pipe	1	
4	97322-08025	BOLT	2	
5	92902-08100	WASHER, spring	2	
6	90506-20074	SPRING, tension	2	
7	J24-14610-00	EXHAUST PIPE ASSY 1	1	
8	J10-14715-01	BAND, muffler	2	
9	95612-08100	NUT, u	2	
10	J10-14813-01	SHAFT, butterfly	1	
11	J10-14812-02	VALVE, butterfly	1	
12	98580-03008	SCREW, Pan head	2	
13	93430-05033	CIRCLIP	2	
14	J10-14815-00	GASKET	1	
15	J10-14818-00	COVER, gasket	1	
16	J10-14836-00	ROD	1	
17	J10-14833-01	JOINT	1	
18	95302-05700	NUT	1	
19	J10-14864-01	JOINT	1	
20	90170-05190	NUT	1	
21	J24-14842-00	PLATE, connecting rod	1	
22	J10-14837-00	CONNECTER, rod	1	
23	J10-14833-01	JOINT	1	
24	95302-05700	NUT	1	
25	J10-14864-01	JOINT	1	
26	90170-05190	NUT	1	
27	J10-14802-00	CONNECTER COMP.	1	
28	90464-07034	CLAMP	2	

FIG. 8 EXHAUST




REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
29	92901-05600	WASHER, Plate	2	
30	92902-05100	WASHER, sPring	2	
31	95302-05600	NUT	2	
32	93430-06005	CIRCLIP	2	
33	90506-06201	SPRING, tension	1	
34	J24-14846-00	BOOT, actuator	4	
34	90468-05112	Cinclip		


J24100-3080

B11

FIG. 9 CRANKCASE


REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	8F3-15100-00	CRANKCASE ASSY	1	
2	91830-21014	.PIN, dowel	2	
3	812-24461-00	PIPE, Joint	1	
4	92502-06045	SCREW, Pan head	5	
5	92502-06055	SCREW, Pan head	1	
6	92502-06065	SCREW, Pan head	1	
7	18A-15138-00	NOZZLE 1	1	



J24100-3090

B12

FIG. 10 OIL TANK




REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	J17-21751-00	TANK, oil	1	
2	863-21771-00	BODY, cap	1	
3	90430-31003	GASKET	1	
4	J17-21756-00	NET, filter	1	
5	J10-21745-00	PIPE, oil tank breather	1	
6	90467-11009	CLIP	2	
7	90464-12036	CLAMP	1	
8	J17-21776-00	BAND, tank fitting	1	
9	97301-06016	BOLT	2	
10	90201-06071	WASHER, Plate	2	
11	90185-06098	NUT, self-locking	2	

 J24100-3100

B13

FIG. 11 REAR SUSPENSION




REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	J17-W2211-00	REAR ARM COMP.	1	
2	J10-22123-00	BUSH 1	2	
3	90101-10419	BOLT	2	
4	95612-10100	NUT, u	2	
5	J10-22210-00	SHOCK ABSORBER ASSY, rear	2	
6	97302-10050	BOLT	4	
7	95602-10100	NUT, u	4	
8	J17-21411-00	BRACKET, engine 1	1	
9	90106-10034	BOLT	4	
10	92901-10100	WASHER, sPrinR	4	
11	90201-10131	WASHER, Plate	4	
12	J10-21486-00	DAMPER 2	4	
13	92901-10100	WASHER, sPrinR	8	
14	90170-10047	NUT	8	
15	J17-2217J-00	TENSIONER 1	1	
16	J17-2214F-00	DAMPER 1	1	
17	90201-06778	WASHER, Plate	1	
18	95302-06600	NUT	2	

J24100-3110

B14


FIG. 12 FRAME



REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	J17-22501-00	FRAME COMP.	1	
2	J31-22571-00	PANEL 1	1	
3	J31-22572-00	PANEL 2	1	
4	90267-40054	RIVET, blind	20	
5	J17-22573-00	PANEL 3	1	
6	90267-40076	RIVET, blind	8	
7	J17-78249-00	TRIM, floor	2	
8	90267-40090	RIVET, blind	6	
9	J17-78181-00	PLATE 1	2	
10	90267-48040	RIVET, blind	4	
11	J17-78187-00	FLAP, front fender	1	
12	J17-78189-00	FLAP, front fender (R.H.)	1	
13	90267-40075	RIVET, blind	5	
14	90201-05034	WASHER, Plate	5	
15	J17-22567-00	SUPPORT 1	1	
16	J17-22568-00	SUPPORT 2	1	
17	97302-08065	BOLT	2	
18	92902-08100	WASHER, spring	2	
19	92902-08600	WASHER, Plate	2	
20	90387-09066	COLLAR	2	
21	95702-08100	NUT, flange	2	
22	J17-2258E-00	SUPPORT, front cowl	1	
23	J11-77279-01	DAMPER, noise 19	1	
24	J24-2255V-00	PLATE, battery cover	1	
25	90267-32063	RIVET, blind	4	
26	J24-2255Y-00	PAD, battery cover	1	

J24100-3120

FIG. 13 FRONT SUSPENSION. WHEEL




J32700-4130

C2

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	J17-W2351-00	FRONT LOWER ARM COMP.(L.H)	1	
2	90381-15032	.BUSH, solid	1	
3	J10-23526-00	.BUSH	1	
4	93700-06004	.NIPPLE, Grease	1	
5	90381-15040	.BUSH, solid	1	
6	93210-15414	.O-RING	1	
7	90201-067F9	.WASHER, Plate	1	
8	J17-23510-00	KNUCKLE, steering comp.	1	
9	J11-23512-00	ARM, knuckle 1	1	
10	90109-10643	BOLT	2	
11	90201-121F0	WASHER, Plate	2	
12	90201-105F2	WASHER, Plate	2	
13	90171-10035	NUT, castle	2	
14	91490-25025	PIN, cotter	2	
15	90214-16027	WASHER, claw	1	
16	97302-08030	BOLT	1	
17	95301-08700	NUT	1	
18	J17-W2352-00	FRONT LOWER ARM COMP.(R.H)	1	
19	90381-15032	.BUSH, solid	1	
20	J10-23526-00	.BUSH	1	
21	93700-06004	.NIPPLE, Grease	1	
22	90381-15040	.BUSH, solid	1	
23	93210-15414	.O-RING	1	
24	90201-067F9	.WASHER, Plate	1	
25	J17-23510-00	KNUCKLE, steering comp.	1	
26	J11-23522-00	ARM, knuckle 2	1	
27	90109-10643	BOLT	2	
28	90201-121F0	WASHER, Plate	2	


FIG. 13 FRONT SUSPENSION, WHEEL



J32700-4130

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
29	90201-105F2	WASHER, Plate	2	
30	90171-10035	NUT, castle	2	
31	91490-25025	PIN, cotter	2	
32	90214-16027	WASHER, claw	1	
33	97302-08030	BOLT	1	
34	95301-08700	NUT	1	
35	J10-23516-02	KING PIN, steering knuckle	2	
36	91401-30025	PIN, cotter	2	
37	95702-12300	NUT, nylon	2	
38	90105-10224	BOLT, washer based	2	
39	90179-10280	NUT	2	
40	J17-W2355-00	ROD, tension	2	
41	J10-23583-01	BUSH	1	
42	90105-08225	BOLT, washer based	2	
43	90185-08106	NUT, self-locking	2	
44	90105-12226	BOLT, washer based	1	
45	90185-12093	NUT, self-locking	1	
46	90387-137F6	COLLAR	1	
47	90102-12046	BOLT, with hole	2	
48	90185-12093	NUT, self-locking	2	
49	J10-23350-00	SHOCK ABSORBER ASSY	2	
50	97322-10050	BOLT	4	
51	95612-10100	NUT, u	4	
52	J17-W2511-00	HUB, front	2	
53	J17-25118-00	COVER, hub dust	2	
54	93306-00511	BEARING	2	
55	93306-20437	BEARING	2	
56	95302-14900	NUT	2	

FIG. 13 FRONT SUSPENSION. WHEEL




J32700-4130

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
57	90209-14219	WASHER	2	
58	91401-30025	PIN, cotter	2	
59	91490-25025	PIN, cotter	7	
60	J11-25100-00	FRONT WHEEL ASSY	2	
61	J11-25102-00	WHEEL RIM ASSY, front	1	
62	94118-85507	TIRE	1	
63	93900-00015	VALVE, rim	1	
64	90179-12262	NUT	8	

C4


FIG. 14 STEERING



REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	J24-23816-00	ARM, Pitman	1	
2	J10-23836-09	.PIN, Pitman	2	
3	93102-22082	OIL SEAL	1	
4	J10-23876-00	BOLT	1	
5	93332-00010	BEARING	1	
6	J10-23877-00	NUT	1	
7	J10-23444-00	WASHER	1	
8	J10-23818-00	COVER, steering	1	
9	J10-23462-00	SEAL, steering	2	
10	90430-08119	GASKET	1	
11	J10-23459-00	BOLT	1	
12	90170-08024	NUT	1	
13	93104-15005	OIL SEAL	1	
14	97302-08020	BOLT	4	
15	92902-08100	WASHER, spring	4	
16	93332-00010	BEARING	1	
17	J10-23814-00	HOLDER, handle upper	1	
18	J10-23811-01-9E	COLUMN, steering	1	Ivory white
19	J10-23840-00	STEERING SHAFT ASSY	1	
20	J10-23838-00	WHEEL, steering	1	
21	J24-23826-00	ARM, idler	1	
22	J10-23831-00	ROD, tie	1	
23	J10-23841-10	JOINT, universal 1	1	
24	J10-23845-10	JOINT, universal 2	1	
25	90170-12054	NUT	1	
26	90170-12055	NUT	1	
27	J10-23831-00	ROD, tie	1	
28	J10-23841-10	JOINT, universal 1	1	

J24100-3140

FIG. 14 STEERING




J24100-3140

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
29	J10-23845-10	JOINT, universal 2	1	
30	90170-12054	NUT	1	
31	90170-12055	NUT	1	
32	95302-12900	NUT, slotted	4	
33	92902-12600	WASHER, Plate	2	
34	91401-30025	PIN, cotter	4	
35	95702-16300	NUT, nylon	1	
36	90215-16161	WASHER, lock	1	
37	90185-12061	NUT, self-locking	1	
38	92902-12200	WASHER	1	
39	90340-14029	PLUG, straight screw	1	
40	97302-10050	BOLT	4	
41	92901-10100	WASHER, spring	4	
42	90430-14175	GASKET	1	

C6

FIG. 15 FUEL TANK




J24100-3150

C8

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
29	J17-24173-00	BAND, tank fitting 1	2	
30	90201-08107	WASHER, Plate	2	
31	95602-08100	NUT, u	2	
32	J17-24129-01	COVER, side 1	1	
33	90202-08111	WASHER, Plate	4	
34	90201-06765	WASHER, Plate	4	
35	95602-06100	NUT, u	4	


FIG. 16 BRAKE



J31100-4160

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	J17-27250-00	BRAKE ARM COMP.	1	
2	90384-14080	.BUSH, bimetal formed	2	
3	J17-27245-00	PAD, brake Pedal	1	
4	J10-27211-00	PEDAL, brake	1	
5	90508-40543	SPRING, torsion	1	
6	90387-107F8	COLLAR	1	
7	J17-25654-00	BRACKET, Pedal	1	
8	90101-10447	BOLT	1	
9	95602-10100	NUT, u	1	
10	92901-10100	WASHER, sPrin8	1	
11	J17-25670-00	PARKING PEDAL COMP.	1	
12	90384-05163	.BUSH, bimetal formed	1	
13	90384-12164	.BUSH, bimetal formed	1	
14	90380-12051	.BUSH, solid	1	
15	90101-06555	BOLT	1	
16	92902-06200	WASHER	1	
17	92902-06100	WASHER, sPrin8	1	
18	95302-06600	NUT	1	
19	90508-23542	SPRING, torsion	1	
20	90109-08669	BOLT	1	
21	92902-08100	WASHER, sPrin8	1	
22	90179-08378	NUT	1	
23	J17-25679-00	DAMPER	1	
24	J17-27246-00	NAIL, brake	1	
25	92902-08200	WASHER	3	
26	97302-08025	BOLT	2	
27	95602-08100	NUT, u	2	
28	J17-W2561-00	SECTOR, Parkin8 brake	1	

FIG. 16 BRAKE




J31100-4160

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
29	90384-10162	BUSH, bimetal formed	1	
30	J17-27221-00	SEAL, shaft	2	
31	90201-064H0	WASHER, Plate	1	
32	95602-06100	NUT, u	1	
33	90508-14548	SPRING, torsion	1	
34	J17-25672-00	PAD, Parking Pedal	1	
35	J17-27231-00	ROD, brake	1	
36	J17-27232-00	END, rod 2	1	
37	95302-06700	NUT	2	
38	90506-12277	SPRING, tension	1	
39	J17-25673-00	DAMPER, brake	2	
40	J17-27228-00	PIN, Joint	1	
41	92901-05600	WASHER, Plate	1	
42	93430-04003	CIRCLIP	1	
43	90201-123F2	WASHER, Plate	1	
44	90508-26557	SPRING, torsion	1	
45	90380-12105	BUSH, solid	1	
46	90201-104G8	WASHER, Plate	2	
47	97322-06016	BOLT	4	
48	92902-06100	WASHER, spring	4	
49	J10-25681-00	EQUALIZER, brake	1	
50	J17-25685-00	ROD	1	
51	91701-10022	PIN, clevis	1	
52	91490-30015	PIN, cotter	1	
53	90249-14129	PIN	1	
54	90179-08261	NUT	1	
55	95301-08700	NUT	1	
56	J17-26341-01	CABLE, brake	1	

C10


FIG. 16 BRAKE



J31100-4160

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
57	J17-26351-01	CABLE, brake	1	
58	93430-09019	CIRCLIP	4	
59	91701-08018	PIN, clevis	4	
60	91490-25015	PIN, collar	4	

FIG. 17 BRAKE 2




REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	J17-27280-01	BACKING PLATE ASSY 1	1	
2	J17-27208-00	BACKING PLATE SUB ASSY 1	1	
3	J17-25340-00	BRAKE SHOE COMP.	1	
4	J17-25330-00	BRAKE SHOE COMP.	1	
5	J17-27206-00	ANCHOR BODY COMP.	1	
6	J17-27204-01	LEVER ASSY 1	1	
7	J10-27281-00	SPRING, shoe clamp	2	
8	J10-27282-00	PIN, shoe hold down	2	
9	90506-20281	SPRING, tension	1	
10	90506-26191	SPRING, tension	1	
11	J17-27238-00	NUT, adjusting	1	
12	90109-08657	BOLT	1	
13	J10-27286-00	COVER, dust	1	
14	92902-06100	WASHER, spring	2	
15	95302-06600	NUT	2	
16	90201-121H8	WASHER, Plate	1	
17	90201-121H9	WASHER, Plate	1	
18	J17-27290-01	BACKING PLATE ASSY 2	1	
19	J17-27209-00	BACKING PLATE SUB ASSY 2	1	
20	J17-25340-00	BRAKE SHOE COMP.	1	
21	J17-25330-00	BRAKE SHOE COMP.	1	
22	J17-27206-00	ANCHOR BODY COMP.	1	
23	J17-27205-01	LEVER ASSY 2	1	
24	J10-27281-00	SPRING, shoe clamp	2	
25	J10-27282-00	PIN, shoe hold down	2	
26	90506-20281	SPRING, tension	1	
27	90506-26191	SPRING, tension	1	
28	J17-27258-00	NUT, adjusting	1	



J31100-4170


FIG. 17 BRAKE 2

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
29	90109-08659	.BOLT	1	
30	J10-27286-00	.COVER, dust	1	
31	92902-06100	.WASHER, spring	2	
32	95302-06600	.NUT	2	
33	90201-121H8	.WASHER, Plate	1	
34	90201-121H9	.WASHER, Plate	1	
35	97322-08016	BOLT	8	
36	92902-08100	WASHER, spring	8	



J31100-4170

FIG. 18 ACCELERATOR




REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	J17-27874-00	BRACKET, accelerator Pedal	1	
2	J17-27853-00	SHAFT, Pedal	1	
3	J17-27872-00	ARM, accelerator Pedal	1	
4	91609-60025	PIN, sPring	1	
5	J10-27871-01	PEDAL, accelerator	1	
6	97302-06025	BOLT	1	
7	92902-06100	WASHER, sPring	1	
8	90106-08040	BOLT	1	
9	95301-08700	NUT	1	
10	91609-35028	PIN, sPring	1	
11	90384-14080	BUSH, bimetal formed	2	
12	93210-14104	O-RING	4	
13	97302-06014	BOLT	4	
14	92902-06100	WASHER, sPring	4	
15	90506-26282	SPRING, tension	1	
16	J17-26311-00	CABLE, throttle	1	
17	256-83936-00	BAND, switch cord	1	
18	91702-05012	PIN, clevis	1	
19	91401-16010	PIN, cotter	1	
20	93430-07012	CIRCLIP	1	
21	90508-16460	SPRING, torsion	1	
22	90560-05001	SPACER	1	
23	97302-06025	BOLT	1	
24	95302-06700	NUT	1	
25	J10-27981-00	BRACKET, throttle	1	

J24100-3180

C14


FIG. 19 GOVERNOR



REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	J10-27912-00	RETAINER	1	
2	90387-21690	COLLAR	1	
3	J10-27913-00	WEIGHT	12	
4	J10-27911-00	HOLDER	1	
5	J10-27927-00	LIFTER	1	
6	93342-22502	BEARING	1	
7	90201-20275	WASHER, Plate	1	
8	J10-27921-01	SHAFT, Governor	1	
9	J10-27922-00	FORK, Governor	1	
10	98501-04008	SCREW, Pan head	2	
11	90202-08110	WASHER, Plate	2	
12	93430-06005	CIRCLIP	1	
13	93104-08058	OIL SEAL	1	
14	J10-27951-01	LEVER, speed limiter	1	
15	90385-08034	BUSH	2	
16	90508-40398	SPRING, torsion	1	
17	95302-06600	NUT	1	
18	J10-27959-00	SCREW, adjusting	1	
19	J10-14836-00	ROD	1	
20	J10-14833-01	JOINT	1	
21	95302-05700	NUT	1	
22	J10-14864-01	JOINT	1	
23	90170-05190	NUT	1	
24	J24-14842-00	PLATE, connecting rod	1	
25	90468-05112	CLIP	2	

J24100-3190

FIG. 20 PRIMARY SHEAVE




REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	J10-46210-00	PRIMARY FIXED SHEAVE COMP.	1	
2	93306-90601	BEARING (B6906)	1	
3	90387-47686	COLLAR	1	
4	J10-46244-00	SEAT, sPring	1	
5	J10-46220-01	PRIMARY SLIDING SHEAVE COMP.	1	
6	93210-27458	O-RING	2	
7	J10-46223-01	CAM	1	
8	J17-46230-00	PRIMARY SHEAVE CAP COMP.	1	
9	J10-46232-00	WEIGHT 1	4	
10	J10-46236-00	PIN, weight	4	
11	98501-05020	SCREW, Pan head	8	
12	92902-05100	WASHER, sPring	8	
13	J10-46253-01	SLIDER	4	
14	90149-05129	SCREW	4	
15	90501-32557	SPRING, comPrission	1	
16	93410-28051	CIRCLIP	1	
17	90560-12180	SPACER	1	
18	90215-13146	WASHER, lock	1	
19	J10-46249-00	BOLT	1	
20	J17-46254-00	SPACER, damPer	4	
21	90202-10129	WASHER, Plate	8	
22	J17-46241-00	V-BELT	1	



J24100-3200

D2

FIG. 21 SECONDARY SHEAVE




REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	J17-46260-00	SECONDARY FIXED SHEAVE COMP.	1	
2	J17-46270-00	SECONDARY SLIDING SHEAVE COMP.	1	
3	93109-20014	.OIL SEAL	2	
4	801-17688-10	.SHOE, ramp	3	
5	J11-46284-00	SEAT, secondary spring	1	
6	J17-17688-00	SHOE, ramp	3	
7	90280-05022	KEY, woodruff	1	
8	90501-45600	SPRING, compression	1	
9	90201-12588	WASHER, Plate	1	
10	90171-12023	NUT, castle	1	
11	91401-30025	PIN, cotter	1	
12	90202-20130	WASHER, Plate	1	



J31100-4210

D3

FIG. 22 TRANSMISSION 1




J24100-3220

D4

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	J10-46311-00	CASE, transmission 1	1	
2	93306-20501	BEARING (B6205)	1	
3	93306-20401	BEARING (B6204)	1	
4	93306-00801	BEARING (B6008)	1	
5	93102-25017	OIL SEAL	1	
6	93102-22189	OIL SEAL	1	
7	97321-08035	BOLT	9	
8	92901-08100	WASHER, sPrin8	9	
9	92901-08600	WASHER, Plate	9	
10	97321-08045	BOLT	2	
11	92901-08100	WASHER, sPrin8	2	
12	92901-08600	WASHER, Plate	2	
13	J10-46312-00	CASE, transmission 2	1	
14	93306-20324	BEARING	1	
15	93306-20401	BEARING (B6204)	1	
16	93306-00801	BEARING (B6008)	1	
17	93102-22189	OIL SEAL	1	
18	8E4-24461-00	PIPE, Joint	1	
19	91810-05016	PIN, dowel	2	
20	J10-46319-00	GASKET	1	
21	90340-14036	PLUG, straight screw	2	
22	90430-14043	GASKET	2	
23	90465-06011	CLAMP	1	
24	835-47559-00	CAP 2	1	
25	97322-10020	BOLT	2	
26	92901-10100	WASHER, sPrin8	2	
27	90465-08028	CLAMP	1	
28	92502-06010	SCREW, Pan head	1	

FIG. 22 TRANSMISSION 1




REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
29	92902-08100	WASHER, sPrinG	1	
30	J10-46321-00	SHAFT, inPut	1	
31	J10-46331-02	GEAR, inPut 1	1	
32	93410-25017	CIRCLIP	1	
33	J10-W4631-00	SHAFT, counter	1	
34	J10-46361-02	GEAR, counter 1	1	
35	J17-46362-00	GEAR, counter 2	1	
36	90201-20272	WASHER, Plate	1	
37	J10-W4641-00	CASE, differential	1	
38	J17-W4642-00	GEAR, rinG	1	
39	J10-46414-00	GEAR, differential side	2	
40	J10-46415-00	PINION, differential	4	
41	97312-08030	BOLT	4	
42	92902-08100	WASHER, sPrinG	4	
43	91810-03014	PIN, dowel	2	

J24100-3220

D5

FIG. 23 REAR AXLE. WHEEL




J25700-3230

D6

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	J10-46540-00	REAR AXLE HOUSING COMP.	2	
2	97322-08025	BOLT	12	
3	92902-08100	WASHER, sPring	12	
4	97322-10020	BOLT	8	
5	92901-10100	WASHER, sPring	8	
6	J17-46510-00	REAR AXLE SHAFT COMP.	2	
7	J17-46521-00	DRUM	2	
8	J11-25300-00	REAR WHEEL ASSY	2	
9	J11-25102-00	WHEEL RIM ASSY, front	1	
10	94118-85508	TIRE	1	
11	93900-00015	VALVE, rim	1	
12	90179-12262	NUT	8	

FIG. 24 WINDSHIELD




REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	J18-78321-00	WINDSHIELD	1	
2	J11-78323-00	BRACKET 1	2	
3	J11-78324-00	BRACKET 2	2	
4	92580-06020	SCREW, Pan head	4	
5	90201-065F3	WASHER, Plate	12	
6	90480-10332	GROMMET	12	
7	92580-06040	SCREW, Pan head	8	
8	95780-06300	NUT, flange	8	
9	J11-78325-00	BRACKET 3	2	
10	J11-77279-01	DAMPER, noise 19	2	
11	92990-06200	WASHER, Plain	10	
12	J11-77275-00	DAMPER, noise 15	2	
13	J18-78326-00	BRACKET 4	2	
14	90462-15125	CLAMP	2	
15	92580-06020	SCREW, Pan head	2	
16	92580-06016	SCREW, Pan head	8	
17	95680-06100	NUT, u	2	
18	92990-06600	WASHER, Plate	10	
19	92990-06100	WASHER, sPring	2	



J27010-3290

D7


FIG. 25 BUMPER



J24100-3240

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	J17-78106-00	BUMPER SUB-ASSY, front	1	
2	J17-78162-00	PAD, front bumper	1	
3	J10-78167-01	BUMPER, rubber 1	1	
4	J10-78168-01	BUMPER, rubber 2	1	
5	90267-40077	RIVET, blind	8	
6	J17-77525-00	WASHER 1	4	
7	J17-78164-00	STAY, front bumper 1	1	
8	J17-78165-00	STAY, front bumper 2	1	
9	97322-08016	BOLT	4	
10	92902-08100	WASHER, spring	4	
11	92902-08600	WASHER, plate	4	
12	97322-08025	BOLT	4	
13	92902-08600	WASHER, plate	4	
14	90201-08766	WASHER, plate	4	
15	92902-08100	WASHER, spring	4	
16	95302-08600	NUT	4	
17	J17-78107-00	BUMPER SUB-ASSY, rear	1	
18	J17-78162-00	PAD, front bumper	1	
19	J10-78167-01	BUMPER, rubber 1	1	
20	J10-78168-01	BUMPER, rubber 2	1	
21	90267-40077	RIVET, blind	8	
22	J17-77525-00	WASHER 1	4	
23	J10-78179-00	PLATE, extension	1	
24	97302-08014	BOLT	2	
25	92902-08600	WASHER, plate	2	
26	92902-08200	WASHER	2	
27	92902-08100	WASHER, spring	2	
28	95301-08800	NUT, crown	2	

FIG. 25 BUMPER




REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
29	J10-78174-01	STAY, rear bumper	2	
30	97322-08016	BOLT	4	
31	92902-08100	WASHER, spring	4	
32	97322-08020	BOLT	4	
33	92902-08600	WASHER, plate	4	
34	92902-08200	WASHER	4	
35	92902-08100	WASHER, spring	4	
36	95302-08600	NUT	4	

J24100-3240

D9


FIG. 26 BODY



REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	J32-W7811-00	PANEL, body shell	1	
2	J10-78119-00	PLATE 3	1	
3	90267-40075	RIVET, blind	7	
4	J17-78121-00	REINFORCEMENT 1	1	
5	98901-06016	SCREW, blind	6	
6	90185-06098	NUT, self-locking	6	
7	J17-78272-00	COVER, fuel inlet	1	
8	J24-77764-00	LABEL, warning 4	1	
9	J10-78238-01	FASTENER, upper	1	
10	93430-06005	CIRCLIP	1	
11	J17-78275-00	HINGE, fuel inlet	1	
12	90201-08732	WASHER, Plate	1	
13	J10-78239-00	FASTENER, lower	1	
14	90267-32019	RIVET, blind	2	
15	90480-35242	GROMMET	2	
16	90267-40075	RIVET, blind	2	
17	90201-04M06	WASHER, Plate	2	
18	J18-78115-01	COWL, front	1	
19	J17-77165-00	TRIM 1	1	
20	J17-78232-00	MAT, main floor 2	1	
21	J17-78233-00	MAT, main floor 3	1	
22	90267-63047	RIVET, blind	24	
23	J10-78291-00	EMBLEM 1	1	
24	92902-05200	WASHER	2	
25	95702-05300	NUT, nylon	2	
26	J17-77151-00	PAD 1	1	
27	J17-77152-00	PAD 2	1	
28	J10-77768-00	LABEL, warning	1	

J25700-3250

FIG. 26 BODY




J25700-3250

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
29	90269-06028	RIVET	2	
30	J11-78287-00	ASH TRAY	1	
31	J11-78286-00	LID, ash tray	1	
32	91701-06026	PIN, clevis	1	
33	92902-06600	WASHER	1	
34	90501-08256	SPRING, compression	1	
35	91402-20012	PIN, cotter	1	
36	J11-77767-00	LABEL, warning 7	1	
37	J10-77711-00	PANEL, instrument	1	
38	J10-78245-00	SEAL 1	1	
39	J10-77741-00	INDICATOR 1	1	
40	90480-48243	GROMMET	1	
41	90464-25050	CLAMP	2	
42	97701-50130	SCREW, tapping	2	
43	90201-05036	WASHER, Plate	2	
44	90480-07241	GROMMET	2	
45	90201-08310	WASHER, Plate	2	
46	98902-08025	SCREW, blind	2	
47	97302-06020	BOLT	3	
48	92902-06100	WASHER, spring	3	
49	90201-06075	WASHER, Plate	3	

D11

FIG. 27 BODY FITTING




J31100-4260

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	J31-77145-00	HINGE 1	1	
2	J17-78221-00	SHEET, body mounting 1	2	
3	98502-05018	SCREW, Pan head	4	
4	92901-05600	WASHER, Plate	4	
5	J31-78123-00	REINFORCEMENT 3	2	
6	J10-77146-00	HINGE 2	2	
7	91701-08118	PIN, clevis	2	
8	91401-25015	PIN, collar	2	
9	98980-06020	SCREW, blind	8	
10	98980-06025	SCREW, blind	2	
11	90202-08085	WASHER, Plate	2	
12	90201-06697	WASHER, Plate	8	
13	90201-06697	WASHER, Plate	2	
14	90201-08730	WASHER, Plate	2	
15	90185-06098	NUT, self-locking	10	
16	97322-08020	BOLT	4	
17	92902-08100	WASHER, spring	4	
18	92902-08600	WASHER, Plate	4	
19	J10-77125-00	STAY 1	1	
20	J10-77766-00	LABEL, warning 6	1	
21	91701-08020	PIN, clevis	2	
22	J17-7712F-00	SPACER, stay	2	
23	90468-16065	CLIP	2	
24	J10-77188-00	STOPPER	1	
25	91701-06012	PIN, clevis	1	
26	90206-06060	WASHER, wave	1	
27	92902-06200	WASHER	2	
28	437-83525-00	CLIP	1	

D12

FIG. 27 BODY FITTING




J31100-4260

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
29	J17-78156-00	STOPPER, lock	1	
30	91312-06035	BOLT	2	
31	J31-78231-00	MAT, main floor 1	1	
32	J31-78234-00	MAT, main floor 4	1	
33	J31-78235-00	SHEET, main floor	1	
34	J31-78271-00	SERVICE LID, Pedal	1	
35	90267-48040	RIVET, blind	16	
36	J24-78191-00	PANEL, rear fender 1	1	
37	97302-06020	BOLT	4	
38	92902-06100	WASHER, sPring	4	
39	90201-061E8	WASHER, Plate	4	
40	J24-78192-00	PANEL, rear fender 2	1	
41	97302-06020	BOLT	4	
42	92902-06100	WASHER, sPring	4	
43	90201-061E8	WASHER, Plate	4	
44	J24-78199-00	FLAP, rear 2	2	
45	90267-40075	RIVET, blind	4	
46	90201-05034	WASHER, Plate	4	
47	90269-06028	RIVET	2	

D13

FIG. 28 SUN ROOF




J32700-4280

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	J11-78314-00	COVER, sun roof	1	
2	J18-78301-00	FRAME COMP., roof	1	
3	J18-78311-00	FRAME, sun roof	1	
4	J11-78316-00	DAMPER	1	
5	J18-78312-00	SUPPORT, sun roof 1	1	
6	J18-78313-00	SUPPORT, sun roof 2	1	
7	J18-78336-01	MEMBER, cross roof	1	
8	J18-W7831-01	SUN-ROOF BRACKET KIT	1	
9	97701-60116	.SCREW, tapping	10	
10	90201-06557	.WASHER, Plate	10	
11	90202-06008	.WASHER, Plate	20	
12	J11-78335-01	.LOCK, side wind	2	
13	90249-05136	.PIN	4	
14	93430-04003	.CIRCLIP	4	
15	92680-08055	.SCREW, oval head	2	
16	90201-08310	.WASHER, Plate	2	
17	97395-08060	.BOLT	4	
18	95680-08100	.NUT, u	4	
19	J11-78329-00	.SPACER 2	8	
20	J11-78343-00	.RETAINER	4	
21	95602-08100	.NUT, u	10	
22	J18-78328-00	.SPACER 1	2	
23	J11-77271-00	.DAMPER, noise 11	8	
24	J11-77272-00	.DAMPER, noise 12	1	
25	J11-78338-00	.SPACER 3	2	
26	90506-23204	.SPRING, tension	2	
27	92990-08100	.WASHER, spring	4	
28	95380-08800	.NUT, crown	4	

D14


FIG. 28 SUN ROOF



REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
29	J18-78349-00	.CAP, support roof	4	
30	92990-08600	.WASHER, Plate	8	
31	90185-08097	.NUT, self-locking	2	
32	92990-08600	.WASHER, Plate	2	

D15


FIG. 29 CARRIER



REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	J10-78351-00-9E	SUPPORT, ba& upper	1	Ivory white
2	J10-78352-00-9E	SUPPORT, ba& lower 1	1	Ivory white
3	J10-78353-00-9E	SUPPORT, ba& lower 2	1	Ivory white
4	92701-08045	SCREW, flat head	4	
5	90202-08022	WASHER, Plate	4	
6	92990-08100	WASHER, sPrin&	4	
7	95380-08800	NUT, crown	4	
8	J10-78356-00	PAD, ba& suPPort	1	
9	J10-78355-00	BAND	1	
10	J10-78367-00	PLATE, anchor	1	
11	92990-06200	WASHER, Plain	4	
12	98980-06016	SCREW, blind	2	
13	92990-06100	WASHER, sPrin&	2	
14	95380-06800	NUT	2	
15	J17-78157-00	BASE, lock	1	
16	J17-78368-00	LEVER, lock	1	
17	J17-78369-00	PIN, lever	1	
18	90386-06108	BUSH	2	
19	93430-05033	CIRCLIP	1	
20	J17-78157-00	BASE, lock	1	
21	J17-78368-00	LEVER, lock	1	
22	J17-78369-00	PIN, lever	1	
23	90386-06108	BUSH	2	
24	93430-05033	CIRCLIP	1	
25	92580-06010	SCREW, Pan head	4	
26	92990-06100	WASHER, sPrin&	4	
27	J10-78139-00	CAP, end	2	
28	90179-10280	NUT	2	

E2


FIG. 29 CARRIER



REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
29	97322-06065	BOLT	4	
30	92902-06100	WASHER, spring	4	
31	92902-06600	WASHER	4	
32	J10-78366-01	CLAMP, support	2	
33	J10-78357-01	HOLDER 1	1	
34	J10-78358-00	HOLDER 2	1	
35	90502-10013	SPRING, conical	2	
36	97702-50125	SCREW, tapping	2	
37	J10-78292-00	EMBLEM 2	1	
38	J10-77762-01	LABEL, warning 2	1	
39	92901-05600	WASHER, plate	2	

E3

FIG. 30 SEAT




REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	J24-78401-01	SEAT SUB-ASSY, cushion	2	
2	97302-08025	BOLT	6	
3	92902-08100	WASHER, sPring	6	
4	97302-08030	BOLT	2	
5	92902-08100	WASHER, sPring	2	
6	90201-08310	WASHER, Plate	8	
7	J10-78439-00	WASHER, seat	8	
8	90480-35346	GROMMET	2	
9	J24-78361-00	ARM REST 1	1	
10	J24-78362-00	ARM REST 2	1	
11	J24-78348-00	SPACER, armrest	2	
12	J24-78347-00	SPACER, armrest	2	
13	92502-08030	SCREW, Pan head	2	
14	92902-08600	WASHER, Plate	2	
15	92902-08100	WASHER, sPring	2	
16	J24-78346-00	SUPPORT, armrest	1	
17	J24-78345-00	WASHER, armrest	2	
18	92502-08025	SCREW, Pan head	2	
19	92902-08600	WASHER, Plate	2	
20	92902-08100	WASHER, sPring	2	
21	90201-08310	WASHER, Plate	2	
22	95602-08100	NUT, u	4	

J31100-4280

E4


FIG. 31 MAGNETO



J31100-4290

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	J10-85500-20	C.D.I. MAGNETO ASSY	1	
2	868-85511-20	.COIL, source	1	
3	J10-85580-20	.COIL, Pulsar	1	
4	J10-85515-20	.LEAD WIRE ASSY	1	
5	104-81328-20	.CLAMP	2	
6	98501-05020	.SCREW, Pan head	2	
7	92901-05100	.WASHER, sPrin&	2	
8	98501-04020	.SCREW, Pan head	2	
9	92901-04100	.WASHER, sPrin&	2	
10	98501-04008	.SCREW, Pan head	1	
11	92901-04100	.WASHER, sPrin&	1	
12	J10-85550-20	.ROTOR ASSY	1	
13	98902-06014	SCREW, bind	2	
14	90201-06043	WASHER, Plate	2	
15	J10-85540-20	C.D.I. UNIT ASSY	1	
16	2A7-85546-00	BAND	1	
17	J17-21245-00	BDX	1	
18	J10-81910-10	VOLTAGE REGULATOR ASSY	1	
19	97301-06016	BOLT	2	
20	92902-06100	WASHER, sPrin&	2	
21	92902-06600	WASHER	2	
22	90201-06043	WASHER, Plate	2	
23	95302-06600	NUT	2	
24	J17-81950-00	RELAY ASSY	2	
25	95301-08700	.NUT	8	
26	92902-08100	.WASHER, sPrin&	8	
27	92902-08600	.WASHER, Plate	4	
28	J24-82532-00	CAP	4	


FIG. 31 MAGNETO



REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
29	J17-86126-00	PLATE, conecting 1	2	
30	J17-86127-00	PLATE, conecting 2	2	
31	92902-08200	WASHER	4	
32	92902-08100	WASHER, sPring	4	
33	95302-08600	NUT	4	
34	J27-81950-00	RELAY ASSY	1	


J31100-4290

FIG. 32 STARTING MOTOR




J24100-3290

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	J10-81100-10	STARTER GENERATOR ASSY	1	
2	J10-81150-10	.ARMATURE ASSY	1	
3	J10-81157-10	.BEARING 1 (6202 SD)	1	
4	J10-81158-10	.BEARING 2 (6203 SD)	1	
5	J10-81159-10	.HOLDER, bearing	1	
6	J10-81175-10	.STOPPER 1	1	
7	J10-81110-10	.STATOR ASSY	1	
8	J10-81160-10	.FIELD COIL ASSY	1	
9	J10-81148-10	.SCREW 4	2	
10	95301-06600	..NUT	4	
11	92901-06600	..WASHER, Plate	2	
12	92901-06100	..WASHER, sPring	4	
13	J10-81146-10	.SCREW 2	4	
14	J10-81165-10	.BRACKET, starter Generator 1	1	
15	J10-81166-10	.BRACKET, starter Generator 2	1	
16	J10-81147-10	.SCREW 3	2	
17	95301-06600	..NUT	4	
18	92901-06600	..WASHER, Plate	2	
19	92901-06100	..WASHER, sPring	4	
20	J10-81119-10	.BRUSH HOLDER ASSY	1	
21	J10-81111-10	.BRUSH	4	
22	J10-81113-10	.SPRING, brush	4	
23	J10-81115-10	.WIRE, lead	2	
24	98501-05016	.SCREW, Pan head	2	
25	98503-04010	.SCREW, Pan head	4	
26	J10-81163-10	.KEY	1	
27	95301-14600	.NUT	1	
28	92901-06100	..WASHER, sPring	1	

E7

FIG. 32 STARTING MOTOR




REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
29	98501-05018	•SCREW, Pan head	3	
30	J10-81129-10	•COVER, brush	3	
31	J10-81139-10	•COVER, brush 2	1	
32	J10-81145-10	•SCREW 1	2	
33	92901-06600	•WASHER, Plate	2	
34	92901-06100	•WASHER, sPrInB	2	

J24100-3290

E8


FIG. 33 STARTER PULLEY



REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	J17-87183-00	INSULATOR, Generator	1	
2	98501-05008	SCREW, Pan head	4	
3	92902-05100	WASHER, sPring	4	
4	J10-81161-01	PULLEY	1	
5	J10-87172-00	FAN, Generator	1	
6	92502-06025	SCREW, Pan head	2	
7	92902-06100	WASHER, sPring	2	
8	92902-06600	WASHER	2	
9	J10-81173-00	BELT	1	
10	90101-12545	BOLT	1	
11	92902-12600	WASHER, Plate	2	
12	92902-12100	WASHER, sPring	1	
13	95302-12600	NUT	1	
14	J17-81170-00	TENSIONER ASSY	1	
15	97302-08020	BOLT	1	
16	90109-08653	BOLT	1	
17	92902-08600	WASHER, Plate	2	
18	92902-08100	WASHER, sPring	2	
19	95302-08600	NUT	2	
20	90101-06410	BOLT	1	
21	95302-06700	NUT	1	


J24100-3300

FIG. 34 ELECTRICAL 1




REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	J16-82110-70	BATTERY ASSY	1	
2	J10-82115-00	WIRE, Plus lead	1	
3	J17-82116-00	WIRE, minus lead	1	
4	J17-82105-00	WIRE HARNESS	1	
5	1E6-82150-00	FUSE HOLDER ASSY	1	
6	1E6-82151-00	.FUSE (6V-10A)	2	
7	J14-82150-00	FUSE HOLDER ASSY	1	
8	1E6-82151-00	.FUSE (6V-10A)	2	
9	J17-82133-00	SCREW, fitting	2	
10	J17-82136-00	PLATE, battery fitting	1	
11	J17-82122-00	SEAT, battery	1	
12	95702-06300	NUT, nylon	2	
13	92902-06200	WASHER	2	
14	J17-82310-21	IGNITION COIL ASSY	1	
15	92502-06025	SCREW, Pan head	2	
16	92902-06100	WASHER, spring	2	
17	90465-06038	CLAMP	1	
18	90464-12036	CLAMP	1	
19	8G8-82318-00	WIRE, sub-lead	1	
20	512-82370-10	PLUG CAP ASSY	1	with noise sup- Presser
21	J17-82508-20	MAIN SWITCH ASSY	1	
22	J17-82511-20	.KEY, main switch	2	
23	J17-82550-01	STOP SWITCH ASSY	1	
24	90465-08028	CLAMP	1	
25	J27-82590-20	WIRE HARNESS ASSY	1	
26	J17-86177-00	WIRE, lead 7	1	
27	J17-82318-00	WIRE, sub-lead	1	
28	366-82591-00	BAND	1	

J24100-3320

E10

FIG. 34 ELECTRICAL 1




REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
29	256-83936-00	BAND, switch cord	1	
30	90464-12036	CLAMP	4	
31	J10-83383-02	BUZZER	1	
32	97301-06016	BOLT	1	
33	92902-06100	WASHER, sPrinE	1	
34	92902-06600	WASHER	1	
35	95302-06600	NUT	1	
36	90201-06043	WASHER, Plate	1	

FWD
J24100-3320

E11

FIG. 35 SPECIAL TOOLS



REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	90890-01135-00	CRANKCASE SEPARATOR		
2	90890-01051-00	RING NUT WRENCH (Ignition Switch)		
3	90890-01235-00	ROTOR HOLDING TOOL		
4	90890-90058-00	CRANKSHAFT SETTING POT		
5	ACC-11401-01-00	SPECIAL ADAPTOR (16x1.0½x20 UNF)		
6	90890-90067-00	ADAPTOR (16x1.0)		
7	90890-01202-00	SPACER (Large)		
8	90890-90059-00	SPACER (Small)		
9	90890-90060-00	SETTING BOLT		
10	90890-90105-00	UNIVERSAL MAGNETO/SHEAVE PULLER		
11	90890-01876-00	PRIMARY SHEAVE PULLER		
12	90890-02300-00	CRANKSHAFT JIG		
13	90890-02204-00	PRESS PLATE (2 Reg.)		
14	90890-02203-00	PRESS PIN		
15	ACC-11401-02-00	SPECIAL PRESS PLATES (PR.)		
16	90890-02213-00	WIDTH GAUGE (55.75mm)		
17	90890-02202-00	PRESS BOX		
18	ACC-11401-03-00	SECONDARY SHEAVE HOLDER		
19	90890-01886-00	SOCKET WRENCH (Brake Adjusting)		

J24100-3330

NUMERICAL INDEX

NUMERICAL INDEX

PART NO.	GRID NO.	PART NO.	GRID NO.	PART NO.	GRID NO.	PART NO.	GRID NO.	PART NO.	GRID NO.	PART NO.	GRID NO.
J17-W2211-00	B-14	10V-13621-00	B- 7	8F3-15100-00	B-12	J10-23841-10	C- 5	J17-27231-00	C-10	J10-46415-00	D- 5
J17-W2351-00	C- 2	J24-14101-00	B- 9	18A-15138-00	B-12	J10-23845-10	C- 5	J17-27232-00	C-10	J17-46510-00	D- 6
J17-W2352-00	C- 2	J10-14122-00	B- 9	J10-15416-00	B- 6		C- 6	J17-27238-00	C-12	J17-46521-00	D- 6
J17-W2355-00	C- 3	J17-14141-00	B- 9	J10-15426-00	B- 6	J10-23876-00	C- 5	J17-27245-00	C- 9	J10-46540-00	D- 6
J17-W2511-00	C- 3	620-14142-32	B- 9	J10-15466-00	B- 6	J10-23877-00	C- 5	J17-27246-00	C- 9	835-47559-00	D- 4
J17-W2561-00	C- 9	796-14181-00	B- 9	J17-17688-00	D- 3	J17-24111-00	C- 7	J17-27250-00	C- 9	J17-7712F-00	D-12
J10-W4631-00	D- 5	796-14184-00	B- 9	801-17688-10	D- 3	J17-24129-01	C- 8	J17-27258-00	C-12	J10-77125-00	D-12
J10-W4641-00	D- 5	796-14185-00	B- 9	J17-21245-00	E- 5	J17-24173-00	C- 8	J17-27280-01	C-12	J31-77145-00	D-12
J17-W4642-00	D- 5	796-14186-00	B- 9	J17-21411-00	B-14	J10-24311-00	C- 7	J10-27281-00	C-12	J10-77146-00	D-12
J32-W7811-00	D-10	353-14190-10	B- 9	J10-21486-00	B-14	J10-24312-00	C- 7	J10-27282-00	C-12	J17-77151-00	D-1
J18-W7831-01	D-14	127-14195-00	B- 9	J10-21745-00	B-13	J10-24313-00	C- 7	J10-27286-00	C-12	J17-77152-00	D-10
J10-11111-00	B- 2	620-14211-00	B- 9	J17-21751-00	B-13	J10-24366-00	C- 7		C-13	J17-77165-00	D-1
J24-11127-00	B- 2	620-14212-00	B- 9	J17-21756-00	B-13	J10-24410-02	C- 7	J17-27290-01	C-12	J10-77188-00	D-1
J10-11181-00	B- 2	732-14237-00	B- 9	863-21771-00	B-13	J24-24460-00	C- 7	J17-27853-00	C-14	J11-77271-00	D-14
J10-11311-00	B- 2	J10-14243-00	B- 9	J10-21773-00	C- 7	J10-24461-00	C- 7	J10-27871-01	C-14	J11-77272-00	D-14
881-11351-01	B- 2	J10-14244-00	B- 9	J17-21776-00	B-13	8E4-24461-00	D- 4	J17-27872-00	C-14	J11-77275-00	D- 7
J10-11400-00	B- 3	J24-14388-00	B- 8	J10-22123-00	B-14	812-24461-00	B-12	J17-27874-00	C-14	J11-77279-01	B-15
J10-11412-00	B- 3	J10-1441F-00	B- 7	J17-2214F-00	B-14	809-24560-01	C- 7	J10-27911-00	C-15		D- 7
J10-11422-00	B- 3	J17-14410-00	B- 7	J17-2217J-00	B-14	J10-24612-00	C- 7	J10-27912-00	C-15	J17-77525-00	D- 8
J10-11610-00	B- 3	J10-14411-00	B- 7	J10-22210-00	B-14	J24-24620-00	C- 7	J10-27913-00	C-15	J10-77711-00	D-11
J10-11610-10	B- 3	J17-14412-00	B- 7	J17-22501-00	B-15	J11-25100-00	C- 4	J10-27921-01	C-15	J10-77741-00	D-11
J10-11610-20	B- 3	J10-14416-00	B- 7	J24-2255V-00	B-15	J11-25102-00	C- 4	J10-27922-00	C-15	J10-77762-01	E- 3
J10-11631-00-96	B- 3	J10-14417-00	B- 8	J24-2255Y-00	B-15		D- 6	J10-27927-00	C-15	J24-77764-00	D-10
J10-11631-00-98	B- 3	J10-14436-00	B- 8	J17-22567-00	B-15	J17-25118-00	C- 3	J10-27951-01	C-15	J10-77766-00	D-12
818-11633-00	B- 3	J10-14450-10	B- 7	J17-22568-00	B-15	J11-25300-00	D- 6	J10-27959-00	C-15	J11-77767-00	D-11
J10-11635-00	B- 3	J10-14453-00	B- 7	J31-22571-00	B-15	J17-25330-00	C-12	J10-27981-00	C-14	J10-77768-00	D-10
J10-11636-00	B- 3	J10-14581-00	B- 9	J31-22572-00	B-15	J17-25340-00	C-12	J10-46210-00	D- 2	J17-78106-00	D- 8
881-11651-00	B- 3	J24-14610-00	B-10	J17-22573-00	B-15	J17-25654-00	C- 9	J10-46220-01	D- 2	J17-78107-00	D- 8
857-11681-00	B- 3	J24-14612-00	B-10	J17-2258E-00	B-15	J17-25670-00	C- 9	J10-46223-01	D- 2	J18-78115-01	D-10
8G8-12611-01	B- 4	J10-14613-00	B-10	J10-23350-00	C- 3	J17-25672-00	C-10	J17-46230-00	D- 2	J10-78119-00	D-10
J24-12616-00	B- 4	888-14633-00	B-10	J10-23444-00	C- 5	J17-25673-00	C-10	J10-46232-00	D- 2	J17-78121-00	D-10
J17-12621-00	B- 4	J10-14715-01	B-10	J10-23459-00	C- 5	J17-25679-00	C- 9	J10-46236-00	D- 2	J31-78123-00	D-12
J10-12631-00	B- 4	J10-14802-00	B-10	J10-23462-00	C- 5	J10-25681-00	C-10	J17-46241-00	D- 2	J10-78139-00	E- 2
J17-12644-00	B- 8	J10-14812-02	B-10	J17-23510-00	C- 2	J17-25685-00	C-10	J10-46244-00	D- 2	J17-78156-00	D-13
J10-12651-00	B- 4	J10-14813-01	B-10	J11-23512-00	C- 2	J17-26311-00	C-14	J10-46249-00	D- 2	J17-78157-00	E- 2
J24-12652-00	B- 4	J10-14815-00	B-10	J10-23516-02	C- 3	J10-26325-00	B- 7	J10-46253-01	D- 2	J17-78162-00	D- 8
J24-13101-00	B- 5	J10-14818-00	B-10	J11-23522-00	C- 2	J10-26331-02	B- 7	J17-46254-00	D- 2	J17-78164-00	D- 8
126-13116-00	B- 5	J10-14833-01	B-10	J10-23526-00	C- 2	J17-26339-09	B- 7	J17-46260-00	D- 3	J17-78165-00	D- 8
137-13148-00	B- 6		C-15	J10-23583-01	C- 3	J17-26341-01	C-10	J17-46270-00	D- 3	J10-78167-01	D- 8
J10-13175-00	B- 6	J10-14836-00	B-10	J10-23811-01-9E	C- 5	J17-26351-01	C-11	J11-46284-00	D- 3	J10-78168-01	D- 8
137-13176-00	B- 6		C-15	J10-23814-00	C- 5	J17-27204-01	C-12	J10-46311-00	D- 4	J10-78174-01	D- 8
J10-13188-00	B- 6	J10-14837-00	B-10	J24-23816-00	C- 5	J17-27205-01	C-12	J10-46312-00	D- 4	J10-78179-00	D- 8
J10-13283-00	B- 5	J24-14842-00	B-10	J10-23818-00	C- 5	J17-27206-00	C-12	J10-46319-00	D- 4	J17-78181-00	B-1
J24-13581-00	B- 8		C-15	J24-23826-00	C- 5	J17-27208-00	C-12	J10-46321-00	D- 5	J17-78187-00	B-15
J24-13586-00	B- 7	J24-14846-00	B-11	J10-23831-00	C- 5	J17-27209-00	C-12	J10-46331-02	D- 5	J17-78189-00	B-15
885-13610-00	B- 7	J10-14864-01	B-10	J10-23836-09	C- 5	J10-27211-00	C- 9	J10-46361-02	D- 5	J24-78191-00	D-13
1L8-13613-00	B- 7		C-15	J10-23838-00	C- 5	J17-27221-00	C-10	J17-46362-00	D- 5	J24-78192-00	D-13
885-13616-01	B- 7	256-14944-19	B- 9	J10-23840-00	C- 5	J17-27228-00	C-10	J10-46414-00	D- 5	J24-78199-00	D-13

NUMERICAL INDEX

NUMERICAL INDEX

PART NO.	GRID NO.	PART NO.	GRID NO.	PART NO.	GRID NO.	PART NO.	GRID NO.	PART NO.	GRID NO.	PART NO.	GRID NO.
J17-78221-00	D-12	J10-78366-01	E- 3	512-82370-10	E-10	90170-12054	C- 6	90201-10131	B-14	90280-05013	B- 3
J31-78231-00	D-13	J10-78367-00	E- 2	J17-82508-20	E-10	90170-12055	C- 5	90201-10468	C-10	90280-05022	D- 3
J17-78232-00	D-10	J17-78368-00	E- 2	J17-82511-20	E-10		C- 6	90201-105F2	C- 2	90340-14029	C- 6
J17-78233-00	D-10	J17-78369-00	E- 2	J24-82532-00	E- 5	90170-16182	B- 3		C- 3	90340-14036	D- 4
J31-78234-00	D-13	J24-78401-01	E- 4	J17-82550-01	E-10	90171-10035	C- 2	90201-114E6	B- 8	90380-12051	C- 9
J31-78235-00	D-13			J27-82590-20	E-10		C- 3	90201-121F0	C- 2	90380-12105	C-10
J10-78238-01	D-10	J10-78439-00	E- 4	366-82591-00	E-10	90171-12023	D- 3	90201-121H8	C-12	90381-15032	C- 2
J10-78239-00	D-10	J10-81100-10	E- 7	J10-83383-02	E-11	90179-08261	C-10		C-13	90381-15040	C- 2
J10-78245-00	D-11	J10-81110-10	E- 7	437-83525-00	D-12	90179-08278	B- 2	90201-121H9	C-12	90384-05163	C- 9
J17-78249-00	B-15	J10-81111-10	E- 7	256-83936-00	C-14	90179-08378	C- 9		C-13	90384-10162	C-10
J31-78271-00	D-13	J10-81113-10	E- 7		E-11	90179-10280	C- 3	90201-123F2	C-10	90384-12164	C- 9
J17-78272-00	D-10	J10-81115-10	E- 7	J10-85500-20	E- 5		E- 2	90201-12588	D- 3	90384-14080	C- 9
J17-78275-00	D-10	J10-81119-10	E- 7	868-85511-20	E- 5	90179-12262	C- 4	90201-20272	D- 5		C-14
J11-78286-00	D-11	J10-81129-10	E- 8	J10-85515-20	E- 5		D- 6	90201-20275	C-15	90385-08034	C-15
J11-78287-00	D-11	J10-81139-10	E- 8	J10-85540-20	E- 5	90185-06098	B-13	90202-06008	D-14	90386-06108	E- 2
J10-78291-00	D-10	J10-81145-10	E- 8	2A7-85546-00	E- 5		D-10	90202-08022	E- 2	90387-06026	B- 8
J10-78292-00	E- 3	J10-81146-10	E- 7	J10-85550-20	E- 5		D-12	90202-08085	D-12	90387-09066	B-15
J18-78301-00	D-14	J10-81147-10	E- 7	J10-85580-20	E- 5	90185-08097	D-15	90202-08110	C-15	90387-107F8	C- 9
J18-78311-00	D-14	J10-81148-10	E- 7	J17-85710-00	C- 7	90185-08106	C- 3	90202-08111	C- 8	90387-137F6	C- 3
J18-78312-00	D-14	J10-81150-10	E- 7	J17-86126-00	E- 6	90185-12061	C- 6	90202-10129	D- 2	90387-21690	C-15
J18-78313-00	D-14	J10-81157-10	E- 7	J17-86127-00	E- 6	90185-12093	C- 3	90202-20130	D- 3	90387-47686	D- 2
J11-78314-00	D-14	J10-81158-10	E- 7	J17-86177-00	E-10	90201-04M06	D-10	90206-06060	D-12	90401-06001	B- 5
J11-78316-00	D-14	J10-81159-10	E- 7	J10-87172-00	E- 9	90201-04756	B- 4	90206-11016	B- 6	90430-06180	B- 5
J18-78321-00	D- 7	J10-81160-10	E- 7	J17-87183-00	E- 9	90201-05034	B-15	90209-14219	C- 4	90430-08119	C- 5
J11-78323-00	D- 7	J10-81161-01	E- 9	90101-06410	E- 9		D-13	90209-24073	B- 3	90430-14043	D- 4
J11-78324-00	D- 7	J10-81163-10	E- 7	90101-06555	C- 9	90201-05036	D-11	90214-16027	C- 2	90430-14175	C- 6
J11-78325-00	D- 7	J10-81165-10	E- 7	90101-10419	B-14	90201-06043	E- 5		C- 3	90430-31003	B-13
J18-78326-00	D- 7	J10-81166-10	E- 7	90101-10447	C- 9		E-11	90215-13146	D- 2	90445-05214	B- 5
J18-78328-00	D-14	J17-81170-00	E- 9	90101-12545	E- 9	90201-06071	B-13	90215-16161	C- 6	90445-09069	C- 7
J11-78329-00	D-14	J10-81173-00	E- 9	90102-12046	C- 3	90201-06075	D-11	90249-05136	D-14	90445-09635	B- 5
J11-78335-01	D-14	J10-81175-10	E- 7	90105-08225	C- 3	90201-061E8	D-13	90249-14129	C-10	90445-10449	C- 7
J18-78336-01	D-14	104-81328-20	E- 5	90105-10224	C- 3	90201-064H0	C-10	90267-32019	D-10	90445-11151	C- 7
J11-78338-00	D-14	J10-81910-10	E- 5	90105-12226	C- 3	90201-065F3	D- 7	90267-32063	B-15	90445-11288	C- 7
J11-78343-00	D-14	J17-81950-00	E- 5	90106-08040	C-14	90201-06557	B- 4	90267-40054	B-15	90445-11634	B- 5
J24-78345-00	E- 4	J27-81950-00	E- 6	90106-10034	B-14		B- 8		C- 7	90460-41146	B- 7
J24-78346-00	E- 4	J17-82105-00	E-10	90109-08653	E- 9		D-14	90267-40075	B-15	90460-41191	B- 7
J24-78347-00	E- 4	J16-82110-70	E-10	90109-08657	C-12	90201-06697	D-12		D-10	90460-53239	B- 7
J24-78348-00	E- 4	J10-82115-00	E-10	90109-08659	C-13	90201-067F9	C- 2		D-13	90461-10054	C- 7
J18-78349-00	D-15	J17-82116-00	E-10	90109-08669	C- 9	90201-06765	C- 8	90267-40076	B-15	90462-08056	B- 4
J10-78351-00-9E	E- 2	J17-82122-00	E-10	90109-10643	C- 2	90201-06778	B-14	90267-40077	D- 8		B- 8
J10-78352-00-9E	E- 2	J17-82133-00	E-10	90116-08254	B- 2	90201-08107	C- 8	90267-40090	B-15	90462-15125	D- 7
J10-78353-00-9E	E- 2	J17-82136-00	E-10	90149-03132	B- 7	90201-08310	D-11	90267-48040	B- 4	90464-07034	B-10
J10-78355-00	E- 2	J14-82150-00	E-10	90149-05129	D- 2		D-14		B-15	90464-12036	B-13
J10-78356-00	E- 2	1E6-82150-00	E-10	90170-05190	B-10		E- 4		D-13		E-10
J10-78357-01	E- 3	1E6-82151-00	E-10		C-15	90201-08624	B- 5	90267-63047	D-10		E-11
J10-78358-00	E- 3	J17-82310-21	E-10	90170-08024	C- 5	90201-08730	D-12	90269-06028	D-11	90464-25050	D-11
J24-78361-00	E- 4	J17-82318-00	E-10	90170-10047	B-14	90201-08732	D-10		D-13	90465-06011	D- 4
J24-78362-00	E- 4	8G8-82318-00	E-10	90170-12054	C- 5	90201-08766	D- 8	90269-65032	B- 8	90465-06038	E-10

NUMERICAL INDEX

PART NO.	GRID NO.	PART NO.	GRID NO.	PART NO.	GRID NO.
90465-08028	D-4	91401-30025	C-3	92901-06100	E-7
	E-10		C-4		E-8
90467-08017	C-7		C-6	92901-06600	E-7
90467-09005	B-5		D-3		E-8
90467-09006	C-7	91402-20012	D-11	92901-08100	D-4
90467-09026	B-5	91490-25015	C-11	92901-08600	D-4
90467-10035	B-5	91490-25025	C-2	92901-10100	B-14
90467-11009	B-13		C-3		C-6
	C-7		C-4		C-9
			C-10		D-4
90468-02025	B-8	91490-30015	C-10	92902-08200	C-9
90468-02033	B-5	91609-35028	C-14		D-8
90468-04092	C-7	91609-60025	C-14	92902-05100	B-11
90468-05112	C-15	91701-05010	B-7		D-2
90468-08104	B-8	91701-06012	D-12		E-9
90468-10049	B-7	91701-06026	D-11	92902-05200	D-10
90468-16065	D-12	91701-08018	C-11	92902-06100	B-6
90480-07241	D-11	91701-08020	D-12		B-7
90480-10332	D-7	91701-08118	D-12		C-7
90480-13238	B-7	91701-10022	C-10		C-9
90480-14100	B-7	91702-05012	C-14		C-10
90480-14239	B-7	91810-03014	D-5		C-12
90480-35242	D-10	91810-05016	D-4	92902-12100	C-13
90480-35346	E-4	91810-18027	B-6	92902-12200	C-14
90480-48243	D-11	91830-21014	B-12	92902-12600	D-5
90501-08256	D-11	92501-06012	B-6		D-11
90501-08430	B-5	92501-06018	B-6	92902-16100	D-13
90501-08486	C-7		C-7	92990-06100	E-3
90501-32557	D-2	92502-06010	D-4		E-5
90501-45600	D-3	92502-06016	B-4	92990-06200	E-9
90502-10013	E-3	92502-06025	E-9		E-10
90506-06201	B-11		E-10	92990-06600	E-11
90506-12277	C-10	92502-06045	B-12	92990-08100	C-9
90506-20074	B-10	92502-06055	B-12		D-12
90506-20281	C-12	92502-06065	B-12		E-10
90506-23204	D-14	92502-08025	E-4	92990-08600	B-4
90506-26191	C-12	92502-08030	E-4	93101-10090	B-6
90506-26282	C-14	92580-06010	E-2	93102-22082	C-5
90508-14548	C-10	92580-06016	D-7	93102-22189	D-4
90508-16460	C-14	92580-06020	D-7	93102-25017	D-4
90508-23542	C-9	92580-06040	D-7	93102-30128	B-3
90508-26557	C-10	92680-08055	D-14	93102-30188	B-3
90608-40398	C-15	92701-08045	E-2	93104-08058	C-15
90508-40543	C-9	92901-04100	E-5	93104-15005	C-5
90560-05001	C-14	92901-05100	E-5	93109-20014	D-3
90560-12180	D-2	92901-05600	B-11	93112-53004	B-6
91312-06035	D-13		B-15	93210-14104	C-14
91401-16010	C-14		C-10	93210-15414	C-2
91401-25015	D-12		D-12	93210-27458	D-2
			E-3	93306-00511	C-3

NUMERICAL INDEX

PART NO.	GRID NO.	PART NO.	GRID NO.	PART NO.	GRID NO.
92902-08100	D-5	93306-00801	D-4	95302-06600	C-15
	D-6	93306-20324	D-4		E-5
	D-8	93306-20401	D-4		E-11
	D-9	93306-20437	C-3	95302-06700	C-10
	D-12	93306-20501	D-4		C-14
	E-4	93306-20618	B-3		E-9
	E-5	93306-30621	B-3	95302-08600	D-8
	E-6	93306-90601	D-2		D-9
	E-9	93310-218A6	B-3		E-6
92902-08200	C-9	93310-42497	B-3		E-9
	D-8	93332-00010	C-5	95302-12600	E-9
	D-9	93342-22502	C-15	95302-12900	C-6
	E-6	93410-10025	B-6	95302-14900	C-3
92902-08600	B-6	93410-25017	D-5	95380-06800	E-2
	B-15	93410-28051	D-2	95380-08800	D-14
	D-8	93430-04003	C-10		E-2
	D-9		D-14	95602-06100	C-8
	D-12	93430-05033	B-10		C-10
	E-4		E-2	95602-08100	C-8
	E-5	93430-06005	B-11		C-9
	E-9		C-15		D-14
	E-9		D-10		E-4
92902-12100	C-6	93430-07012	C-14	95602-10100	B-14
92902-12200	C-6	93430-09019	C-11		C-9
92902-12600	E-9	93450-20026	B-3	95612-08100	B-10
	D-13	93450-72048	B-3	95612-10100	B-14
92902-16100	E-3	93603-22028	B-6		C-3
92990-06100	E-5	93700-06004	C-2	95680-06100	D-7
	E-9	93900-00015	C-4	95680-08100	D-14
	E-10		D-6	95702-05300	D-10
92990-06600	D-7	94118-85507	C-4	95702-06300	E-10
92990-08100	D-14	94118-85508	D-6	95702-08100	B-15
	E-2	94701-00108	B-2	95702-12300	C-3
	D-15	95301-06600	E-7	95702-16300	C-6
	B-6	95301-08700	C-2	95780-06300	D-7
	C-5		C-3	95802-06050	B-4
	D-4		C-10	95822-06012	B-4
	D-4		C-14	95822-06035	B-6
	B-3		E-5	97301-06016	B-4
95301-08800	D-8		D-8		B-13
95301-14600	E-7		E-7		E-5
95302-05600	B-11		B-11		E-11
95302-05700	B-10		B-10	97302-06014	C-14
	C-15		C-15	97302-06020	D-11
95302-06600	B-14		B-14		D-13
	C-9		C-9	97302-06022	B-8
	D-2		C-12	97302-06025	C-14
	C-3		C-12	97302-06030	B-7

NUMERICAL INDEX

PART NO.	GRID NO.	PART NO.	GRID NO.	PART NO.	GRID NO.
97302-06060	B- 4	98901-06016	D-10		
97302-08014	D- 8	98902-06014	E- 5		
97302-08020	C- 5	98902-08025	D-11		
	E- 9	98980-06016	E- 2		
97302-08025	C- 9	98980-06020	D-12		
	E- 4	98980-06025	D-12		
97302-08030	C- 2				
	C- 3				
	E- 4	SPECIAL TOOLS			
97302-08065	B-15	ACC-11401-01-00	E 12		
97302-10050	B-14	ACC-11401-02-00	E 12		
	C- 6	ACC-11401-03-00	E 12		
97312-08030	D- 5	90890-01051-00	E 12		
97321-08035	D- 4	90890-01135-00	E 12		
97321-08045	D- 4	90890-01202-00	E 12		
97322-06016	C-10	90890-01235-00	E 12		
97322-06030	B- 6	90890-01876-00	E 12		
97322-06065	E- 3	90890-01886-00	E 12		
97322-08016	C-13	90890-02202-00	E 12		
	D- 8	90890-02203-00	E 12		
	D- 9	90890-02204-00	E 12		
97322-08020	D- 9	90890-02213-00	E 12		
	D-12	90890-02300-00	E 12		
97322-08025	B-10	90890-90058-00	E 12		
	D- 6	90890-90059-00	E 12		
	D- 8	90890-90060-00	E 12		
97322-08035	B- 6	90890-90067-00	E 12		
97322-10020	D- 4	90890-90105-10	E 12		
	D- 6				
97322-10050	C- 3				
97395-08060	D-14				
97602-03108	B- 7				
	B- 9				
97701-50130	D-11				
97701-60116	D-14				
97702-50125	E- 3				
98501-04008	C-15				
	E- 5				
98501-04020	E- 5				
98501-05008	E- 9				
98501-05016	B- 5				
	E- 7				
98501-05018	E- 8				
98501-05020	D- 2				
	E- 5				
98502-05018	D-12				
98503-04010	E- 7				
98580-03008	B-10				

PARTS NAME INDEX

DESCRIPTION	GRID NO.	DESCRIPTION	GRID NO.	DESCRIPTION	GRID NO.
ABSORBER 3	B- 2	BOLT	B- 8	BRACKET, throttle	C-14
AIR CLEANER ASSY	B- 7	*	B-10	BRAKE ARM COMP.	C- 9
AIR SHROUD, cylinder 1	B- 4	*	B-13	BRAKE SHOE COMP.	C-12
AIR SHROUD, cylinder 2	B- 4	*	B-14	BRUSH	E- 7
ANCHOR BODY COMP.	C-12	*	B-15	BRUSH HOLDER ASSY	E- 7
ARM REST 1	E- 4	*	C- 2	BUMPER SUB-ASSY, front	D- 8
ARM REST 2	E- 4	*	C- 3	BUMPER SUB-ASSY, rear	D- 8
ARM, accelerator Pedal	C-14	*	C- 5	BUMPER, rubber 1	D- 8
ARM, idler	C- 5	*	C- 6	BUMPER, rubber 2	D- 8
ARM, knuckle 1	C- 2	*	C- 9	BUSH	C- 2
ARM, knuckle 2	C- 2	*	C-10	*	C- 3
ARM, Pitman	C- 5	*	C-12	*	C-15
ARMATURE ASSY	E- 7	*	C-13	*	E- 2
ASH TRAY	D-11	*	C-14	BUSH 1	B-14
BACKING PLATE ASSY 1	C-12	*	D- 2	BUSH, bimetal formed	C- 9
BACKING PLATE ASSY 2	C-12	*	D- 4	*	C-10
BACKING PLATE SUB ASSY 1	C-12	*	D- 5	*	C-14
BACKING PLATE SUB ASSY 2	C-12	*	D- 6	BUSH, solid	C- 2
BAND	E- 2	*	D- 8	*	C- 9
*	E- 5	*	D- 9	*	C-10
*	E-10	*	D-11	BUZZER	E-11
BAND, muffler	B-10	*	D-12	C.D.I. MAGNETO ASSY	E- 5
BAND, switch cord	C-14	*	D-13	C.D.I. UNIT ASSY	E- 5
*	E-11	*	D-14	CABLE, brake	C-10
BAND, tank fitting	B-13	*	E- 3	*	C-11
BAND, tank fitting 1	C- 8	*	E- 4	CABLE, starter 1	B- 7
BASE, lock	E- 2	*	E- 5	CABLE, throttle 1	C-14
BATTERY ASSY	E-10	*	E- 9	CAM	D- 2
BEARING	C- 3	*	E-11	CAP	E- 5
*	C- 5	BOLT, flange	B- 4	CAP 2	D- 4
*	C-15	*	B- 6	CAP, cleaner case 1	B- 7
*	D- 4	BOLT, stud	B- 2	CAP, end	E- 2
BEARING (B6008)	D- 4	BOLT, union	B- 5	CAP, support roof	D-15
BEARING (B6204)	D- 4	BOLT, washer based	C- 3	CARBURETOR ASSY 1	B- 9
BEARING (B6205)	D- 4	BOLT, with hole	C- 3	CASE, air cleaner 1	B- 7
BEARING (B6206)	B- 3	BOOT	B- 7	CASE, differential	D- 5
BEARING (B6306)	B- 3	BOOT, actuator	B-11	CASE, fan	B- 4
BEARING (B6906)	D- 2	BOX	E- 5	CASE, transmission 1	D- 4
BEARING 1 (6202 SD)	E- 7	BRACKET	B- 9	CASE, transmission 2	D- 4
BEARING 2 (6203 SD)	E- 7	BRACKET 1	D- 7	CHAMBER, air	B- 8
BEARING, cylindrical	B- 3	BRACKET 2	D- 7	CIRCLIP	B- 3
BELT	E- 9	BRACKET 3	D- 7	*	B- 6
BODY CAP ASSY	C- 7	BRACKET 4	D- 7	*	B-10
BODY, cap	B-13	BRACKET, accelerator Pedal	C-14	*	B-11
BODY, float chamber 1	B- 9	BRACKET, engine 1	B-14	*	C-10
BOLT	B- 4	BRACKET, Pedal	C- 9	*	C-11
*	B- 6	BRACKET, starter generator 1	E- 7	*	C-14
*	B- 7	BRACKET, starter generator 2	E- 7	*	C-15

PARTS NAME INDEX

DESCRIPTION	GRID NO.	DESCRIPTION	GRID NO.	DESCRIPTION	GRID NO.
CIRCLIP	D- 2	COVER, side 1	C- 8	FUSE HOLDER ASSY	E-10
*	D- 5	COVER, steering	C- 5	GASKET	B- 5
*	D-10	COVER, sun roof	D-14	*	B- 9
*	D-14	COWL, front	D-10	*	B-10
*	E- 2	CRANK 1	B- 3	*	B-13
CLAMP	B- 4	CRANK 2	B- 3	*	C- 5
*	B- 8	CRANKCASE ASSY	B-12	*	C- 6
*	B-10	CRANKSHAFT ASSY	B- 3	*	D- 4
*	B-13	CYLINDER 1	B- 2	GASKET 2	B- 6
*	C- 7	DAMPER	C- 9	GASKET, air cleaner	B- 7
*	D- 4	*	D-14	GASKET, cap	C- 7
*	D- 7	DAMPER 1	B-14	GASKET, cylinder	B- 2
*	D-11	DAMPER 2	B-14	GASKET, cylinder head 1	B- 2
*	E- 5	DAMPER, brake	C-10	GASKET, exhaust pipe	B-10
*	E-10	DAMPER, noise 11	D-14	GASKET, float chamber	B- 9
*	E-11	DAMPER, noise 12	D-14	GASKET, pump case	B- 5
CLAMP, fuel pipe 1	C- 7	DAMPER, noise 15	D- 7	GASKET, valve seat	B- 7
CLAMP, hose	B- 7	DAMPER, noise 19	B-15	GEAR, counter 1	D- 5
CLAMP, support	E- 3	*	D- 7	GEAR, counter 2	D- 5
CLIP	B- 5	DEFLECTOR 1	B- 4	GEAR, differential side	D- 5
*	B- 7	DEFLECTOR 3	B- 8	GEAR, drive	B- 6
*	B- 8	DRUM	D- 6	GEAR, input 1	D- 5
*	B-13	ELEMENT ASSY, air cleaner	B- 7	GEAR, ring	D- 5
*	C- 7	EMBLEM 1	D-10	GROMMET	B- 7
*	C-15	EMBLEM 2	E- 3	*	C- 7
*	D-12	END, rod 2	C-10	*	D- 7
COIL, pulser	E- 5	EQUALIZER, brake	C-10	*	D-10
COIL, source	E- 5	EXHAUST PIPE ASSY 1	B-10	*	D-11
COLLAR	B- 8	FAN	B- 4	*	E- 4
*	B-15	FAN, generator	E- 9	HEAD, cylinder 1	B- 2
*	C- 3	FASTENER, lower	D-10	HINGE 1	D-12
*	C- 9	FASTENER, upper	D-10	HINGE 2	D-12
*	C-15	FIELD COIL ASSY	E- 7	HINGE, fuel inlet	D-10
*	D- 2	FILTER ASSY	C- 7	HOLDER	C-15
COLUMN, steering	C- 5	FLAP, front fender	B-15	HOLDER 1	E- 3
CONNECTER COMP.	B-10	FLAP, front fender (R.H)	B-15	HOLDER 2	E- 3
CONNECTER, rod	B-10	FLAP, rear 2	D-13	HOLDER, bearing	E- 7
COVER 1	B- 6	FLOAT	B- 9	HOLDER, handle upper	C- 5
*	B- 8	FORK, governor	C-15	HOLDER, nozzle	B- 9
COVER 2	B- 6	FRAME COMP.	B-15	HOOK	B- 8
COVER, brush	E- 8	FRAME COMP., roof	D-14	HOSE	B- 5
COVER, brush 2	E- 8	FRAME, sun roof	D-14	*	C- 7
COVER, dust	C-12	FRONT LOWER ARM COMP.(L.H)	C- 2	HUB, front	C- 3
*	C-13	FRONT LOWER ARM COMP.(R.H)	C- 2	IGNITION COIL ASSY	E-10
COVER, fan case	B- 4	FRONT WHEEL ASSY	C- 4	INDICATOR 1	D-11
COVER, fuel inlet	D-10	FUEL LEVEL GAUGE ASSY	C- 7	INSULATOR, generator	E- 9
COVER, gasket	B-10	FUEL PUMP ASSY	C- 7	JET, main (# 95)	B- 9
COVER, hub dust	C- 3	FUSE (6V-10A)	E-10	JET, pilot (# 32.5)	B- 9

PARTS NAME INDEX

DESCRIPTION	GRID NO.	DESCRIPTION	GRID NO.	DESCRIPTION	GRID NO.
JET, sensor	B- 5	NUT	C- 4	O-RING	C- 2
JOINT	B-10	*	C- 5	*	C-14
*	C-15	*	C- 6	*	D- 2
JOINT, air cleaner 1	B- 7	*	C- 9	OIL PUMP ASSY	B- 5
JOINT, carburetor 1	B- 7	*	C-10	DIL SEAL	B- 3
JOINT, universal 1	C- 5	*	C-12	*	B- 6
JOINT, universal 2	C- 5	*	C-13	*	C- 5
*	C- 6	*	C-14	*	C-15
KEY	E- 7	*	C-15	*	D- 3
KEY, main switch	E-10	*	D- 6	*	D- 4
KEY, woodruff	B- 3	*	D- 8	PAD 1	D-10
*	D- 3	*	D- 9	PAD 2	D-10
KING PIN, steering knuckle	C- 3	*	E- 2	PAD, bag support	E- 2
KNOB, starter	B- 7	*	E- 5	PAD, battery cover	B-15
KNUCKLE, steering comp.	C- 2	*	E- 6	PAD, brake pedal	C- 9
LABEL, warning	D-10	*	E- 7	PAD, front bumper	D- 8
LABEL, warning 2	E- 3	*	E- 9	PAD, Parking Pedal	C-10
LABEL, warning 4	D-10	*	E-11	PANEL 1	B-15
LABEL, warning 6	D-12	NUT, adjusting	C-12	PANEL 2	B-15
LABEL, warning 7	D-11	NUT, castle	C- 2	PANEL 3	B-15
LEAD WIRE ASSY	E- 5	*	C- 3	PANEL, body shell	D-10
LEVER ASSY 1	C-12	*	D- 3	PANEL, instrument	D-11
LEVER ASSY 2	C-12	NUT, crown	D- 8	PANEL, rear fender 1	D-13
LEVER, lock	E- 2	*	D-14	PANEL, rear fender 2	D-13
LEVER, speed limiter	C-15	*	E- 2	PARKING PEDAL COMP.	C- 9
LID, ash tray	D-11	NUT, flange	B-15	PARTITION, air cleaner case	B- 7
LIFTER	C-15	*	D- 7	PEDAL, accelerator	C-14
LOCK, side wind	D-14	NUT, nylon	C- 3	PEDAL, brake	C- 9
MAIN SWITCH ASSY	E-10	*	C- 6	PIN	C-10
MAT, main floor 1	D-13	*	D-10	*	D-14
MAT, main floor 2	D-10	*	E-10	PIN, clevis	B- 7
MAT, main floor 3	D-10	NUT, ring	B-10	*	C-10
MAT, main floor 4	D-13	NUT, self-locking	B-13	*	C-11
MEMBER, cross roof	D-14	*	C- 3	*	C-14
METAL, worm shaft outer	B- 6	*	C- 6	*	D-11
NAIL, brake	C- 9	*	D-10	*	D-12
NEEDLE VALVE ASSY	B- 9	*	D-12	PIN, cotter	C- 2
NET, filler	B-13	*	D-15	*	C- 3
NIPPLE, grease	C- 2	NUT, slotted	C- 6	*	C- 4
NOZZLE 1	B-12	NUT, u	B-10	*	C- 6
NOZZLE, main	B- 9	*	B-14	*	C-10
NUT	B- 2	*	C- 3	*	C-11
*	B- 3	*	C- 8	*	C-14
*	B-10	*	C- 9	*	D- 3
*	B-11	*	C-10	*	D-11
*	B-14	*	D- 7	*	D-12
*	C- 2	*	D-14	PIN, crank 1	B- 3
*	C- 3	*	E- 4	PIN, dowel	B- 6

PARTS NAME INDEX

DESCRIPTION	GRID NO.	DESCRIPTION	GRID NO.	DESCRIPTION	GRID NO.
PIN, dowel	B-12	REAR WHEEL ASSY	D- 6	SCREW, Pan head	C- 7
*	D- 4	REED VALVE ASSY	B- 7	*	C-15
*	D- 5	REED, valve	B- 7	*	D- 2
PIN, float	B- 9	REINFORCEMENT 1	D-10	*	D- 4
PIN, Joint	C-10	REINFORCEMENT 3	D-12	*	D- 7
PIN, lever	E- 2	RELAY ASSY	E- 5	*	D-12
PIN, Piston	B- 3	*	E- 6	*	E- 2
PIN, Pitman	C- 5	RELEASE VALVE ASSY	C- 7	*	E- 4
PIN, shoe hold down	C-12	RETAINER	C-15	*	E- 5
PIN, sPring	C-14	*	D-14	*	E- 7
PIN, weiRht	D- 2	RING	B-10	*	E- 8
PINION, differential	D- 5	RIVET	B- 8	*	E- 9
PIPE 2	C- 7	*	D-11	*	E-10
PIPE 3	C- 7	*	D-13	SCREW, Pan head with washer	B- 7
PIPE, fuel 1	C- 7	RIVET, blind	B- 4	*	B- 9
PIPE, Joint	B-12	*	B-15	SCREW, Pilot adjusting	B- 9
*	C- 7	*	C- 7	SCREW, tapping	D-11
*	D- 4	*	D- 8	*	D-14
PIPE, oil tank breather	B-13	*	D-10	*	E- 3
PISTON (STD)	B- 3	*	D-13	SCREW, throttle	B- 9
PISTON (0.25MM O/S)	B- 3	ROD	B-10	SEAL 1	D-11
PISTON (0.50MM O/S)	B- 3	*	C-10	SEAL, shaft	C-10
PISTON RING SET (STD)	B- 3	*	C-15	SEAL, steering	C- 5
PISTON RING SET (1ST O/S)	B- 3	ROD, brake	C-10	SEAT SUB-ASSY, cushion	E- 4
PISTON RING SET (2ND O/S)	B- 3	ROD, connecting	B- 3	SEAT, battery	E-10
PLATE	B- 9	ROD, tension	C- 3	SEAT, secondary sPring	D- 3
PLATE 1	B-15	ROD, tie	C- 5	SEAT, sPring	D- 2
PLATE 3	D-10	ROTOR ASSY	E- 5	SECONDARY FIXED SHEAVE COMP.	D- 3
PLATE, anchor	E- 2	SCREW	B- 7	SECONDARY SLIDING SHEAVE COMP.	D- 3
PLATE, battery cover	B-15	*	D- 2	SECTOR, parking brake	C- 9
PLATE, battery fitting	E-10	SCREW 1	E- 8	SERVICE LID, Pedal	D-13
PLATE, cam thrust	B- 6	SCREW 2	E- 7	SHAFT, butterfly	B-10
PLATE, connecting 1	E- 6	SCREW 3	E- 7	SHAFT, counter	D- 5
PLATE, connecting 2	E- 6	SCREW 4	E- 7	SHAFT, Governor	C-15
PLATE, connecting rod	B-10	SCREW, adjusting	C-15	SHAFT, inPut	D- 5
*	C-15	SCREW, blind	D-10	SHAFT, Pedal 1	C-14
PLATE, extension	D- 8	*	D-11	SHAFT, worm	B- 6
PLUG CAP ASSY	E-10	*	D-12	SHEET, body mounting 1	D-12
PLUG, sPark (NGK BP6HS)	B- 2	*	E- 2	SHEET, main floor	D-13
PLUG, straight screw	C- 6	*	E- 5	SHOCK ABSORBER ASSY	C- 3
*	D- 4	SCREW, fitting	E-10	SHOCK ABSORBER ASSY, rear	B-14
PRIMARY FIXED SHEAVE COMP.	D- 2	SCREW, flat head	E- 2	SHOE, ramp	D- 3
PRIMARY SHEAVE CAP COMP.	D- 2	SCREW, oval head	D-14	SLIDER	D- 2
PRIMARY SLIDING SHEAVE COMP.	D- 2	SCREW, Pan head	B- 4	SPACER	C-14
PULLEY	E- 9	*	B- 5	*	D- 2
REAR ARM COMP.	B-14	*	B- 6	SPACER 1	D-14
REAR AXLE HOUSING COMP.	D- 6	*	B-10	SPACER 2	D-14
REAR AXLE SHAFT COMP.	D- 6	*	B-12	SPACER 3	D-14

PARTS NAME INDEX

DESCRIPTION	GRID NO.	DESCRIPTION	GRID NO.	DESCRIPTION	GRID NO.
SPACER, armrest	E-4	TIRE	C-4	WASHER, Plate	C-6
SPACER, damper	D-2	+	D-6	*	C-8
SPACER, stay	D-12	TRIM 1	D-10	*	C-10
SPRING, brush	E-7	TRIM, floor	B-15	*	C-12
SPRING, compression	B-5	V-BELT	D-2	*	C-13
*	C-7	VALVE, butterfly	B-10	*	C-15
+	D-2	VALVE, rim	C-4	*	D-2
*	D-3	+	D-6	*	D-3
*	D-11	VALVE, vacuum control	B-8	*	D-4
SPRING, conical	E-3	VOLTAGE REGULATOR ASSY	E-5	*	D-5
SPRING, Pilot adjusting	B-9	WASHER	B-3	*	D-7
SPRING, shoe clamp	C-12	+	B-4	+	D-8
SPRING, tension	B-10	*	B-6	+	D-9
*	B-11	*	B-7	+	D-10
*	C-10	*	C-4	+	D-11
*	C-12	*	C-5	*	D-12
*	C-14	*	C-6	*	D-13
*	D-14	+	C-9	*	D-14
SPRING, torsion	C-9	*	D-8	*	D-15
*	C-10	*	D-9	*	E-2
*	C-14	*	D-10	*	E-3
*	C-15	*	D-11	*	E-4
STARTER GENERATOR ASSY	E-7	*	D-12	*	E-5
STATOR ASSY	E-7	+	E-3	*	E-7
STAY 1	D-12	*	E-5	+	E-8
STAY, front bumper 1	D-8	+	E-6	+	E-9
STAY, front bumper 2	D-8	+	E-9	+	E-11
STAY, rear bumper	D-9	+	E-10	+	E-4
STEERING SHAFT ASSY	C-5	+	E-11	+	B-6
STOP SWITCH ASSY	E-10	WASHER 1	D-8	*	B-7
STOPPER	D-12	WASHER, armrest	E-4	*	B-10
STOPPER 1	E-7	WASHER, claw	C-2	*	B-11
STOPPER, lock	D-13	+	C-3	*	B-14
STOPPER, reed valve	B-7	WASHER, lock	C-6	*	B-15
SUN-ROOF BRACKET KIT	D-14	+	D-2	*	C-5
SUPPORT 1	B-15	WASHER, needle valve	B-9	*	C-6
SUPPORT 2	B-15	WASHER, plain	D-7	*	C-7
SUPPORT, armrest	E-4	+	E-2	*	C-9
SUPPORT, bag lower 1	E-2	WASHER, Plate	B-4	+	C-10
SUPPORT, bag lower 2	E-2	+	B-5	*	C-12
SUPPORT, bag upper	E-2	*	B-6	*	C-13
SUPPORT, front cowl	B-15	*	B-8	*	C-14
SUPPORT, sun roof 1	D-14	+	B-11	*	D-2
SUPPORT, sun roof 2	D-14	+	B-13	*	D-4
TANK, fuel	C-7	+	B-14	*	D-5
TANK, oil	B-13	*	B-15	*	D-6
TENSIONER ASSY	E-9	+	C-2	*	D-7
TENSIONER 1	B-14	+	C-3	*	D-8

PARTS NAME INDEX

DESCRIPTION	GRID NO.	DESCRIPTION	GRID NO.	DESCRIPTION	GRID NO.
WASHER, spring	D-9				
*	D-11				
*	D-12				
*	D-13				
*	D-14				
*	E-2				
*	E-3				
*	E-4				
*	E-5				
*	E-6				
*	E-7				
*	E-8				
*	E-9				
*	E-10				
*	E-11				
WASHER, wave	B-6				
*	D-12				
WEIGHT	C-15				
WEIGHT 1	D-2				
WHEEL RIM ASSY, front	C-4				
*	D-6				
WHEEL, steering	C-5				
WINDSHIELD	D-7				
WIRE HARNESS	E-10				
WIRE HARNESS ASSY	E-10				
WIRE, lead	E-7				
WIRE, lead 7	E-10				
WIRE, minus lead	E-10				
WIRE, plus lead	E-10				
WIRE, sub-lead	E-10				
SPECIAL TOOLS					
ADAPTOR (16x1.0)	E 12				
CRANKCASE SEPARATOR	E 12				
CRANKSHAFT JIG	E 12				
CRANKSHAFT SETTING POT	E 12				
PRESS BOX	E 12				
PRESS PIN	E 12				
PRESS PLATE (2 Reg.)	E 12				
PRIMARY SHEAVE PULLER	E 12				
RING NUT WRENCH (Ignition Switch)	E 12				
ROTOR HOLDING TOOL	E 12				
SECONDARY SHEAVE HOLDER	E 12				
SETTING BOLT	E 12				
SOCKET WRENCH (Brake Adjusting)	E 12				
SPACER (Large)	E 12				
SPACER (Small)	E 12				
SPECIAL ADAPTOR (16x1.0 x20 UNF)	E 12				
SPECIAL PRESS PLATER (PR)	E 12				
UNIVERSAL MAGNETO/SHEAVE PULLER	E 12				
WIDTH GAUGE	E 12				