

YAMAHA

PARTS CATALOGUE

G5-AN9 (J501)

YMMC (U.S.A) PRODUCTION MODEL

19J50-110E1



FOREWORD

This Parts Catalogue is related to the parts in use for the Yamaha G5-AN9 (J501). When you are ordering replacement parts for the G5-AN9 (J501), refer to this Parts Catalogue and quote both part numbers and part names correctly.

1. *Modifications or additions which have been made after issue of the Parts Catalogue will be announced in the Yamaha Parts News.*

It is advisable that according to the Yamaha Parts news you make necessary corrections to the Parts Catalogue on hand to keep it up-to-date.

2. **Abbreviations**

The following abbreviations are used in this Parts Catalogue.

- U.R. Use size (thickness) and/or number as required.
- U.N. Use as many as you need.
- A.P. Alternate Parts
- L.M. Local Made
- F# Frame No. (Applicable machine No.)

3. The parts marked with (*) in the parts number column of this Catalogue are not supplied with by Yamaha, those have to be found locally.

4. Parts, which are to be supplied in the form of assemblies, are listed with an indentation of one letter's space, and a dot (.) is put against the name of each part.

EXAMPLE CARBURETOR ASS'Y
 .JET, pilot
 .NOZZLE, main

5. **Indication of No. of constituent parts for assembly**



The numeral appearing to the right of each constituent part under the description indicates the quantity of such parts for each individual assembly unit.

EXAMPLE

Part No.	Description	Q'ty	Remarks
2F5-83310-60	FRONT FLASHER LIGHT ASS'Y	2	
115-83311-60	.BULB (6V-18W)	1	
1M1-83309-60	.REFLECTOR	1	

6. **Initial Serial No.**

Ⓐ Frame Serial No.	J50-100101 and following
Ⓑ Engine Serial No.	J50-100101 and following




7. Applicable colors of graphics are represented in the "Remarks" column by the letter(s) appropriately picked out of the full word(s) showing such colors.

EXAMPLE

Part No.	Description	Q'ty	Remarks
2N4-24110-00-X5	FUEL TANK COMP.	1	MAXIM RED
3J1-24240-10	.GRAPHIC, fuel tank set	1	for MXR

8. This Parts Catalogue contains modified specs as opposed to the preceding one. The modified items are asterisked (*) before their respective Ref. Nos. For the convenience of reference, Table Comparison between old and new is provided at the end of this catalogue.

FIG. 1 CYLINDER




REF. NO.	PART NO.	DESCRIPTION	QTY	REMARKS
1	J38-11102-00	CYLINDER HEAD ASSY	1	
2	J38-11133-09	.GUIDE, intake valve	2	
3	99510-12016	PIN, dowel	2	
4	95811-08070	BOLT, flange	3	
5	95812-08045	BOLT, flange	3	
6	J38-11181-00	GASKET, cylinder head 1	1	
7	95612-08818	BOLT, stud	2	
X 8	94701-00343	PLUG, spark (BRSES)	1	
9	J38-11191-00	COVER, cylinder head 1	1	
10	J38-11116-00	.JOINT, breather	2	
11	J38-24461-00	.PIPE, joint	1	
12	J38-11193-00	GASKET, head cover 1	1	
13	91316-06025	BOLT	4	
14	92990-08600	WASHER, plate	4	
15	90445-130F8	HOSE	1	
16	90467-12052	CLIP	2	



J50100-9010


FIG. 2 CRANKSHAFT • PISTON



REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	J38-11400-00	CRANKSHAFT ASSY	1	
2	J38-11631-01-A0	PISTON (STD)	1	
	J38-11635-01	PISTON (0.25MM O/S)	1	AP
	J38-11636-01	PISTON (0.50MM O/S)	1	AP
3	J38-11610-00	PISTON RING SET (STD)	1	
	J38-11610-10	PISTON RING SET (1ST O/S)	1	AP
	J38-11610-20	PISTON RING SET (2ND O/S)	1	AP
4	7A9-11633-00	PIN, piston	1	
5	93450-19047	CIRCLIP	2	
6	J38-11650-00	CONNECTING ROD ASSY	1	
7	J38-11654-00	.BOLT, connecting rod	2	
8	90179-08327	.NUT	2	
9	J38-11656-00	BEARING, con-rod (BROWN)	2	UR
	J38-11656-10	BEARING, con-rod (BRACK)	2	UR
	J38-11656-20	BEARING, con-rod (BLUE)	2	UR
10	J38-11657-00	SPLASHER, oil	1	
11	90280-05013	KEY, woodruff	1	
12	92901-16100	WASHER, spring	1	
13	90170-16182	NUT	1	
14	J38-11500-00	BALANCER ASSY	1	
15	J38-11496-00	.BOSS, buffer	1	
16	90501-21133	.SPRING, compression	6	
17	93605-10090	.PIN, dowel	3	
18	J38-11531-00	.GEAR, balanca wt	1	
19	90201-201G9	.WASHER, plate	1	
20	90387-155R3	COLLAR	2	
21	90387-152M7	COLLAR	1	

FWD
J38100-7020

FIG. 3 CAMSHAFT • VALVE




REF. NO.	PART NO.	DESCRIPTION	QTY	REMARKS
1	J38-12111-01	VALVE, intake	1	
2	J38-12121-01	VALVE, exhaust	1	
3	90501-264A9	SPRING, compression	2	
4	J38-12117-01	RETAINER, valve spring	2	
5	J38-12118-00	COTTER, valve	2	
6	J38-12151-01	ARM, valve rocker	1	
7	J38-12161-01	ARM, valve rocker 2	1	
8	J38-12156-00	SHAFT, rocker 2	1	
9	J38-12154-00	ROD, valve push	2	
10	J38-12153-00	LIFTER, valve	2	
11	J38-12171-00	CAMSHAFT 1	1	
12	J38-12159-00	SCREW, valve adjusting	2	
13	J38-12152-00	SUPPORT, rocker arm	1	
14	95811-06030	BOLT, flange	2	
15	91810-09014	PIN, dowel	2	
16	5H0-12119-00	SEAL, valve stem	1	
17	90170-06128	NUT	2	



J38100-8030

FIG. 4 AIR SHROUD . FAN




REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	J38-12621-01	CASE, fan	1	
2	95801-08020	BOLT, flange	5	
3	97780-60516	SCREW, tapping	4	
4	J38-12640-00	FAN-CASE COVER COMP.	1	
5	J38-12651-01	AIR SHROUD, cylinder 1	1	
6	J38-12652-00	AIR SHROUD, cylinder 2	1	
7	92502-08016	SCREW, pan head	4	
8	92990-06600	WASHER, plate	4	
9	90109-06513	BOLT	4	



J50100-9040


FIG. 5 INTAKE



REF. NO.	PART NO.	DESCRIPTION	QTY	REMARKS
1	J38-13556-00	GASKET, manifold	1	
2	J38-13596-00	JOINT, carburetor 2	1	
3	J38-13557-00	GASKET	1	
4	92501-06030	SCREW, pan head	2	
5	92990-06100	WASHER, spring	2	
6	92990-06600	WASHER, plate	2	
7	95601-06200	NUT, self-locking	2	
8	J38-14453-00	JOINT, air cleaner 1	1	
9	90460-43279	CLAMP, hose	1	
10	90460-53239	CLAMP, hose	1	
11	J38-14411-00	CASE, air cleaner 1	1	
12	90480-14100	GROMMET	2	
13	J38-14412-00	CAP, cleaner case 1	1	
14	55K-14476-00	SEAL	1	
15	J38-14450-00	ELEMENT ASSY, air cleaner	1	
16	J38-14484-00	PLATE, cleaner case fitting	1	
17	J38-14479-00	FUNNEL	1	
18	J38-14419-00	PIPE	1	
19	90480-18277	GROMMET	1	
20	90480-13238	GROMMET	2	
21	J10-14436-00	HOOK	4	
22	J38-14416-00	GASKET, air cleaner	1	
23	J38-1441F-00	PARTITION, air cleaner case	1	
24	90267-40073	RIVET, blind	4	
25	J10-14417-00	COVER 1	1	
26	J38-1446A-00	SURGE TANK ASSY	1	
27	92990-04200	WASHER, plain	4	
28	90119-06097	BOLT, with washer	2	


FIG. 5 INTAKE

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
29	90387-07390	COLLAR	2	
30	J38-26312-00	CABLE, throttle 2	1	
31	91701-05010	PIN, clevis	1	
32	90468-10049	CLIP	1	
33	99001-07600	CIRCLIP	1	
34	J50-F6331-00	CABLE, starter 1	1	
35	91701-05010	PIN, clevis	1	
36	90468-10049	CLIP	1	
37	90468-07179	CLIP	1	
38	90464-26114	CLAMP	1	
39	90464-16115	CLAMP	2	
40	90468-10049	CLIP	1	
41	91701-05010	PIN, clevis	1	



J50100-9050

FIG. 6 CARBURETOR




REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	J50-14101-00	CARBURETOR ASSY 1	1	
2	98501-05008	.SCREW, pan head	1	
3	92990-05100	.WASHER, spring	1	
4	J38-14243-00	.PLATE	1	
5	75G-14211-00	.SCREW, pilot adjusting	1	
6	620-14212-00	.SPRING, pilot adjusting	2	
7	J10-14122-00	.SCREW, throttle	1	
8	J38-14186-00	.PIN, float	1	
9	J38-14185-00	.FLOAT	1	
10	620-14142-72	.JET, pilot (# 72.5)	1	UR STD
	620-14142-67	.JET, pilot (# 67.5)	1	AP FOR HIGH LANDS
11	J38-14133-00	.SPRING, throttle stop	1	
12	J38-14581-00	.BRACKET	1	
13	92501-06010	.SCREW, pan head	1	
14	92990-06100	.WASHER, spring	1	
15	98701-05008	.SCREW, flat head	2	
16	J38-14291-00	.BRACKET 1	1	
17	3G2-1423E-42	.JET, main (#106.3)	1	UR STD
	3G2-1423E-41	.JET, main (#103.8)	1	AP FOR HIGH LANDS
18	796-14184-00	.GASKET, float chamber	1	
19	127-14198-00	.GASKET	1	
20	7R1-14162-00	.BOLT, holding	1	
21	J10-14597-00	.WASHER	1	
22	J38-14150-00	.NEEDLE ASSY	1	
23	J38-14141-00	.NOZZLE, main	1	

FWD

J38110-5060

FIG. 7 EXHAUST




REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	J38-14710-01	MUFFLER ASSY 1	1	
2	J38-14613-00	GASKET, exhaust pipe	1	
3	95380-08600	NUT	2	
4	92990-08100	WASHER, spring	2	
5	J38-14771-00	STAY, muffler 1	1	
6	95026-10020	BOLT, flange	2	
7	90119-08119	BOLT, with washer	2	



J55100-9070


FIG. 8 CRANKCASE



J50100-9080

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	J38-15100-02	CRANKCASE ASSY	1	
2	J38-15148-00	.NOZZLE 2	1	
3	J38-15155-00	.NOZZLE 3	1	
4	J38-15123-00	PLATE, baffle 1	1	
5	90159-05117	SCREW, with washer	1	
6	93306-30709	BEARING	1	
7	93102-35191	OIL SEAL	1	
8	J38-15361-00	GAUGE, level	1	
9	J38-15411-01	COVER, crankcase 1	1	
10	J38-15112-00	PIPE, oil	1	
11	J38-15363-00	PLUG, oil	1	
12	93306-30621	BEARING (B6306)	1	
13	93102-30195	OIL SEAL	1	
14	93608-12063	PIN, dowel	2	
15	95811-08035	BOLT, flange	9	
16	90340-12097	PLUG, straight screw	1	
17	812-11198-00	GASKET	1	
18	J38-15451-00	GASKET, crankcase cover 1	1	
19	J38-14388-00	VALVE, vacuum control	1	
20	J38-13115-00	CONNECTOR, suction pipe	1	
21	90445-113E4	HOSE	1	
22	90467-10008	CLIP	2	
23	90468-08104	CLIP	1	
24	J38-13161-00	PIPE, delivery 1	1	
25	90445-110E6	HOSE	2	
26	90467-10008	CLIP	4	
27	807-24376-00	PIPE, joint 1	1	
28	90445-09073	HOSE	1	

FIG. 8 CRANKCASE




REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
29	90467-08017	CLIP	2	
30	J38-11355-00	SEAL, cylinder 1	1	
31	90464-15093	CLAMP	1	

J50100-9080


FIG. 9 ENGINE BRACKET

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	J38-21411-02	BRACKET, engine 1	1	
2	J55-F1419-00	BRACKET, engine 2	1	J38-21419-02
3	97011-10025	BOLT	2	
4	92901-10100	WASHER, spring	2	
5	92990-10600	WASHER, plate	2	
6	95021-10040	BOLT, flange	2	
7	J38-21486-00	DAMPER 2	2	
8	J38-21488-00	DAMPER	2	
9	95702-10500	NUT, flange	6	
10	95701-08500	NUT, flange	4	
11	J31-2217J-01	TENSIONER 1	1	
12	J17-2214F-00	DAMPER 1	1	
13	90201-06778	WASHER, plate	1	
14	95303-06600	NUT	2	
16	J38-2141A-00	BRACKET 1	1	



J38100-7090

FIG. 10 REAR ARM . SUSPENSION




REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	J50-F2110-00	REAR ARM COMP.	1	
2	J50-22123-00	.BUSH 1	1	
3	90185-10115	NUT, self-locking	2	
4	J50-22171-00	ARM, rear 1	2	
5	J50-22124-00	.BUSH 2	2	
6	95812-12065	BOLT, flange	4	
7	90185-12072	NUT, self-locking	2	
8	92901-12100	WASHER, spring	2	
9	J50-22172-00	ARM, rear 2	1	
10	J50-22124-00	.BUSH 2	2	
11	95812-12065	BOLT, flange	2	
12	90185-12072	NUT, self-locking	2	
13	J50-F2201-00	DAMPER SUB ASSY	2	
14	95812-12055	BOLT, flange	2	
15	90185-12072	NUT, self-locking	2	
16	97011-08016	BOLT	4	
17	92902-08100	WASHER, spring	4	



J50100-9100


FIG. 11 FRAME

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	J50-F2501-00	FRAME COMP.	1	
2	J50-22571-00	PANEL 1	1	
3	J50-22572-00	PANEL 2	1	
4	90267-40054	RIVET, blind	18	



J50100-9110

FIG. 12 FRONT SUSPENSION • WHEEL




REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	J50-23507-00	FRONT LOWER ARM SUB-ASSY (L.H)	1	
2	J38-23526-00	.BUSH	2	
3	95812-10070	BOLT, flange	2	
4	90185-10115	NUT, self-locking	2	
5	J51-23511-00	KNUCKLE, steering 1	1	
6	J50-23512-00	ARM, knuckle 1	1	
7	90101-12687	BOLT	2	
8	92990-12100	WASHER, spring	2	
9	97022-08040	BOLT	1	
10	92902-08100	WASHER, spring	1	
11	J50-23508-00	FRONT LOWER ARM SUB-ASSY (R.H)	1	
12	J38-23526-00	.BUSH	2	
13	95812-10070	BOLT, flange	2	
14	90185-10115	NUT, self-locking	2	
15	J51-23511-00	KNUCKLE, steering 1	1	
16	J50-23522-00	ARM, knuckle 2	1	
17	90101-12687	BOLT	2	
18	92990-12100	WASHER, spring	2	
19	97022-08040	BOLT	1	
20	92902-08100	WASHER, spring	1	
21	J50-F330E-00	DAMPER ASSY	2	
22	J50-23384-00	.COVER, dust seal 2	1	
23	97090-08020	BOLT	6	
24	92990-08100	WASHER, spring	6	
25	J50-F5110-00	HUB ASSY, front	2	
26	93306-20567	.BEARING	1	
27	J50-25183-00	.COLLAR, wheel	1	
28	93306-00507	.BEARING (B6005)	1	



J50100-9120

FIG. 12 FRONT SUSPENSION • WHEEL



REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
29	93102-35412	.OIL SEAL	1	
30	J17-25118-00	COVER, hub dust	2	
31	90209-32271	WASHER	2	
32	95602-14100	NUT, u	2	
33	90171-10004	NUT, castle	2	
34	91401-25030	PIN, cotter	2	
35	*	FRONT WHEEL ASSY	2	LM
36	90179-12262	NUT	8	



J50100-9120

FIG. 13 STEERING

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	J50-23811-00	COLUMN, steering	1	
2	J50-23828-00	ROD, steering	1	
3	J50-23814-00	HOLDER, handle upper	1	
4	J50-23857-00	WASHER, lock	1	
5	99009-16400	CIRCLIP	1	
6	90201-16245	WASHER, plate	1	
7	J50-F3838-00	WHEEL, steering	1	J42-23838-00
8	J42-23839-00	PIN, cancel	1	
9	98580-04008	SCREW, pan head	3	
10	92902-04100	WASHER, spring	3	
11	90185-12061	NUT, self-locking	1	
12	92902-12200	WASHER, wave	1	
13	92990-08200	WASHER, plain	4	
14	92902-08100	WASHER, spring	4	
15	95380-08600	NUT	4	
16	J50-K8357-00	HOLDER 1	1	
17	J50-K8358-00	HOLDER 2	1	
18	90502-10013	SPRING, conical	2	
19	97706-40525	SCREW, tapping	2	
20	J38-77763-00	LABEL, warning 3	1	
21	J50-77762-00	LABEL, warning 2	1	
22	90201-044A2	WASHER, plate	2	
23	90387-046N7	COLLAR	2	
24	J50-23400-00	STEERING ASSY	1	
25	J50-23824-00	.HOUSING, steering gear	1	
26	J50-2387A-00	.PINION KIT	1	
27	J50-2387E-00	.GEAR, rack	1	
28	J50-2387F-00	.PAD, pressure	1	






FIG. 14 FUEL TANK



J50100-9140

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	J50-F4110-00	FUEL TANK COMP.	1	
2	J50-24611-00	.BODY, cap	1	
3	J50-24112-00	.PIPE	1	
4	90460-68230	.CLAMP, hose	1	
5	J50-24620-00	.BODY CAP ASSY	1	
6	8R4-24560-00	.FILTER ASSY	1	
7	8F3-24664-00	.GASKET	1	
8	J50-85752-00	.SENDER UNIT ASSY, fuel meter	1	
9	J24-24460-01	.RELEASE VALVE ASSY	1	
10	J10-21773-00	.GROMMET	1	
11	95821-08025	BOLT, flange	3	
12	90201-084K7	WASHER, plate	3	
13	97022-06012	BOLT	2	
14	92990-06100	WASHER, spring	2	
15	J50-24410-00	FUEL PUMP ASSY	1	
16	97011-06020	BOLT	2	
17	92990-06100	WASHER, spring	2	
18	92990-06600	WASHER, plate	2	
19	J50-24311-00	PIPE, fuel 1	1	
20	90467-11009	CLIP	2	
21	90445-09222	HOSE	1	
22	90467-08017	CLIP	2	
23	90445-09304	HOSE	1	
24	90467-08017	CLIP	2	
25	90464-23041	CLAMP	2	




J50100-9150

FIG. 15 BRAKE

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	J46-27250-01	BRAKE ARM COMP.	1	
2	90384-14080	.BUSH, bimetal formed	2	
3	J10-27211-00	PEDAL, brake	1	
4	J17-25670-01	PARKING PEDAL COMP.	1	
5	90384-05163	.BUSH, bimetal formed	1	
6	90384-12164	.BUSH, bimetal formed	1	
7	90380-12051	.BUSH, solid	1	
8	90101-06555	BOLT	1	
9	90179-07564	NUT	1	
10	90508-23542	SPRING, torsion	1	
11	90109-08669	BOLT	1	
12	92902-08100	WASHER, spring	1	
13	90179-08378	NUT	1	
14	J17-25679-01	DAMPER	2	
15	92990-08200	WASHER, plain	1	
16	J17-W2581-00	SECTOR, parking brake	1	
17	90384-10162	.BUSH, bimetal formed	1	
18	J17-27221-00	SEAL, shaft	2	
19	92990-10800	WASHER, plate	1	
20	99002-07600	CIRCLIP	1	
21	90508-14548	SPRING, torsion	1	
22	J17-25672-00	PAD, parking pedal	1	
23	J17-27231-00	ROD, brake	1	
24	J17-27232-00	END, rod 2	1	
25	95303-06700	NUT	2	
26	90506-12277	SPRING, tension	1	
27	J17-25673-00	DAMPER, brake	1	
28	J17-27228-00	PIN, joint	1	


FIG. 15 BRAKE



J50100-9150

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
29	92901-05600	WASHER, plate	1	
30	99001-04600	CIRCLIP	1	
31	90201-123F2	WASHER, plate	1	
32	90508-26557	SPRING, torsion	1	
33	90380-12105	BUSH, solid	1	
34	90201-104G8	WASHER, plate	2	
35	J46-27245-00	PAD, brake pedal	1	
36	90508-40543	SPRING, torsion	1	
37	90101-10447	BOLT	1	
38	95602-10100	NUT, u	1	
39	J55-2252M-00	BRACKET, 3	1	
40	J17-27246-00	NAIL, brake	1	
41	97313-08020	BOLT	2	
42	92902-08100	WASHER, spring	2	
43	J17-25673-00	DAMPER, brake	1	
44	90387-107F8	COLLAR	1	
45	J10-25681-00	EQUALIZER, brake	1	
46	J50-25685-00	ROD	1	
47	91701-10022	PIN, clevis	1	
48	91490-30015	PIN, cotter	1	
49	90249-14129	PIN	1	
50	90179-08261	NUT	1	
51	95303-08700	NUT	1	
52	J50-F6341-00	CABLE, brake	1	
53	J50-F6351-00	CABLE, brake	1	
54	99002-09600	CIRCLIP	4	
55	91701-08018	PIN, clevis	4	
56	91490-25015	PIN, cotter	4	


FIG. 15 BRAKE



J50100-9150

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
57	90461-12117	CLAMP	4	
58	95801-06012	BOLT, flange	4	
59	90465-13169	CLAMP	1	

FIG. 16 BRAKE 2




REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	J17-27208-00	BACKING PLATE SUB ASSY 1	1	
2	J17-W2536-00	BRAKE SHOE SET	1	
3	J17-27206-00	ANCHOR BODY COMP.	1	
4	J38-27204-00	LEVER ASSY 1	1	
5	J10-27281-00	SPRING, shoe clamp	2	
6	J10-27282-00	PIN, shoe hold down	2	
7	90506-20281	SPRING, tension	1	
8	90506-26191	SPRING, tension	1	
9	J17-27238-00	NUT, adjusting	1	
10	90109-08657	BOLT	1	
11	J10-27286-00	COVER, dust	1	
12	92990-06100	WASHER, spring	2	
13	95303-06600	NUT	2	
14	90201-121H8	WASHER, plate	1	
15	90201-121H9	WASHER, plate	1	
16	J17-27209-00	BACKING PLATE SUB ASSY 2	1	
17	J17-W2536-00	BRAKE SHOE SET	1	
18	J17-27206-00	ANCHOR BODY COMP.	1	
19	J38-27205-00	LEVER ASSY 2	1	
20	J10-27281-00	SPRING, shoe clamp	2	
21	J10-27282-00	PIN, shoe hold down	2	
22	90506-20281	SPRING, tension	1	
23	90506-26191	SPRING, tension	1	
24	J17-27258-00	NUT, adjusting	1	
25	90109-08659	BOLT	1	
26	J10-27286-00	COVER, dust	1	
27	92990-06100	WASHER, spring	2	
28	95303-06600	NUT	2	



J41100-7060

FIG. 16 BRAKE 2


REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
29	90201-121H8	WASHER, plate	1	
30	90201-121H9	WASHER, plate	1	
31	97012-08018	BOLT	8	
32	92902-08100	WASHER, spring	8	



J41100-7060


FIG. 17 ACCELERATOR

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	J38-27874-00	BRACKET, accelerator pedal	1	
2	J17-27853-00	SHAFT, pedal 1	1	
3	J38-27872-00	ARM, accelerator pedal	1	
4	91609-60028	PIN, spring	1	
5	91609-35028	PIN, spring	1	
6	J14-27871-00	PEDAL, accelerator	1	
7	97001-06025	BOLT	1	
8	92990-06100	WASHER, spring	1	
9	90106-08040	BOLT	1	
10	95303-08700	NUT	1	
11	90384-14080	BUSH, bimetal formed	2	
12	93210-14104	O-RING	4	
13	97021-06016	BOLT	4	
14	92990-06100	WASHER, spring	4	
15	90506-26282	SPRING, tension	1	
16	J50-F6311-00	CABLE, throttle 1	1	
17	91702-05012	PIN, clevis	1	
18	90468-10049	CLIP	1	
19	90508-16460	SPRING, torsion	1	
20	90560-05001	SPACER	1	
21	J38-27981-00	BRACKET, throttle	1	
22	97001-06025	BOLT	1	
23	95303-06700	NUT	1	
24	90465-08334	CLAMP	1	



J50100-9170

FIG. 18 GOVERNOR




REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	J38-27951-00	LEVER, speed limiter	1	
2	95303-06600	NUT	1	
3	90386-08141	BUSH	2	
4	90508-40678	SPRING, torsion	1	
5	J38-27959-00	SCREW, adjusting	1	
6	95701-06300	NUT, nylon	1	
7	J38-27982-00	BRACKET, wire	1	
8	97011-08016	BOLT	1	
9	92902-08100	WASHER, spring	1	
10	J10-27912-00	RETAINER	1	
11	90387-21690	COLLAR	1	
12	J10-27913-00	WEIGHT	12	
13	J10-27911-00	HOLDER	1	
14	J10-27927-00	LIFTER	1	
15	93342-22502	.BEARING	1	
16	90201-20275	WASHER, plate	1	
17	J38-27921-00	SHAFT, governor	1	
18	J10-27922-00	FORK, governor	1	
19	90157-04092	SCREW, pan head	2	
20	90202-08110	WASHER, plate	2	
21	99001-06600	CIRCLIP	1	
22	93109-08008	OIL SEAL	1	



J50100-9180

FIG. 19 PRIMARY SHEAVE




REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	J38-46210-00	PRIMARY FIXED SHEAVE COMP.	1	
2	J38-46220-00	PRIMARY SLIDING SHEAVE COMP.	1	
3	93102-28348	.OIL SEAL	2	
4	J38-46253-00	.SLIDER	3	
5	98901-05008	.SCREW, bind	3	
6	93700-06004	.NIPPLE, grease	1	
7	J38-46251-00	SPIDER	1	
8	J38-46231-00	CAP	1	
9	J38-46205-01	WEIGHT LINK ASSY	3	
10	J38-46238-00	PIN, weight	3	
11	J38-46237-00	PIN, weight 2	3	
12	90113-04050	BOLT, set	12	
13	98501-05008	SCREW, pan head	6	
14	92901-05100	WASHER, spring	6	
15	J38-46249-00	BOLT	1	
16	J55-G6241-00	V-BELT	1	
17	90202-07164	WASHER, plate	6	
18	90387-076U6	COLLAR	3	
19	90202-07186	WASHER, plate	6	

FWD

J50100-9190

FIG. 20 SECONDARY SHEAVE


REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	J55-G6260-00	SECONDARY FIXED SHEAVE COMP.	1	
2	J55-G6270-00	SECONDARY SLIDING SHEAVE COMP.	1	
3	93102-20309	OIL SEAL	2	
4	J38-46284-00	SEAT, secondary spring	1	
5	J17-17688-00	SHOE, ramp	3	
6	90508-45679	SPRING, torsion	1	
7	90202-20130	WASHER, plate	1	
8	90280-05022	KEY, woodruff	1	
9	90201-12588	WASHER, plate	1	
10	95601-12200	NUT, self-locking	1	
11	91401-25030	PIN, cotter	1	



FWD


J39700-6200

FIG. 21 TRANSMISSION 1




REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	J38-46311-00	CASE, transmission 1	1	
2	93306-20541	BEARING (B6205)	1	
3	93306-20401	BEARING (B6204)	1	
4	93306-00803	BEARING (B6008)	1	
5	93102-25017	OIL SEAL	1	
6	93102-22189	OIL SEAL	1	
7	J38-46312-00	CASE, transmission 2	1	
8	93306-20324	BEARING	1	
9	93306-20401	BEARING (B6204)	1	
10	93306-00803	BEARING (B6008)	1	
11	93102-22189	OIL SEAL	1	
12	J38-46319-00	GASKET	1	
13	95811-08040	BOLT, flange	7	
14	95811-08050	BOLT, flange	2	
15	99510-12016	PIN, dowel	2	
16	90340-14036	PLUG, straight screw	1	
17	90430-14043	GASKET	1	
18	90101-08344	BOLT	1	
19	90201-08087	WASHER, plate	1	
20	90465-06100	CLAMP	1	
21	J38-46321-02	SHAFT, input	1	
22	J38-46331-01	GEAR, input 1	1	
23	J38-46351-00	SHAFT, counter	1	
24	J38-46361-01	GEAR, counter 1	1	
25	J38-46362-00	GEAR, counter 2	1	
26	J38-46363-00	GEAR, reverse	1	
27	J38-4636A-00	DOG, clutch	1	
28	90201-204K8	WASHER, plate	2	

FIG. 21 TRANSMISSION 1



REF. NO.	PART NO.	DESCRIPTION	QTY	REMARKS
29	90201-257J2	WASHER, plate	3	
30	90387-252M8	COLLAR	1	
31	J38-46411-01	CASE, differential	1	
32	J38-46421-01	GEAR, ring	1	
33	J38-46414-00	GEAR, differential side	2	
34	J38-46415-00	PINION, differential	2	
35	J38-46417-02	PIN, differential	1	
36	90105-08390	BOLT, washer based	4	
37	91812-16001	PIN, dowel	2	
38	91609-40040	PIN, spring	1	
39	J38-46348-00	SHAFT 2	1	
40	J38-46356-00	GEAR, idler	1	
41	90201-17713	WASHER, plate	3	
42	J38-4633A-00	BAR, shift fork guide	1	
43	J38-46338-00	FORK, shift	1	
44	91609-40020	PIN, spring	1	
45	90101-08344	BOLT	1	
46	90201-08087	WASHER, plate	1	
47	90501-10060	SPRING, compression	1	
48	90249-07190	PIN	1	
49	J38-46384-00	LEVER, shift 3	1	
50	91701-06022	PIN, clevis	1	
51	92990-06200	WASHER, plain	1	
52	91402-20012	PIN, cotter	1	
53	90201-12166	WASHER, plate	1	
54	93102-12224	OIL SEAL	1	
55	835-47559-00	CAP 2	1	
56	95811-08040	BOLT, flange	1	


FIG. 21 TRANSMISSION 1



REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
67	97022-08075	BOLT	1	
68	92902-08100	WASHER, spring	1	
69	95303-08600	NUT	1	
60	93410-25017	CIRCLIP	1	
61	95611-08100	NUT, u	1	
62	J50-G6371-00	WIRE, shift	2	
63	J55-G6383-00	LEVER, shift 2	1	J38-46383-00
64	J50-46382-00	LEVER, shift 1	1	
65	95303-08600	NUT	3	
66	92902-08100	WASHER, spring	3	
67	91402-20020	PIN, cotter	2	
68	7Y8-52625-00	KNOB	1	
69	J50-46394-00	JOINT	1	
70	90461-08108	CLAMP	1	

J50100-9210

FIG. 22 REAR AXLE • WHEEL




J50100-9220

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	J50-46540-00	REAR AXLE HOUSING COMP.	1	
2	J50-46550-00	REAR AXLE HOUSING COMP. 2	1	
3	J50-46510-00	REAR AXLE SHAFT COMP.	1	
4	J50-46520-00	REAR AXLE SHAFT COMP. 2	1	
5	97012-08025	BOLT	12	
6	92902-08100	WASHER, spring	12	
7	97022-10020	BOLT	8	
8	92901-10100	WASHER, spring	8	
9	92990-10600	WASHER, plate	8	
10	*	FRONT WHEEL ASSY	2	LM
11	90179-12262	NUT	8	
12	J55-G6521-00	DRUM	2	J17-46521-00

FIG. 23 BUMPER


REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	J50-K8163-00	COVER, bumper	2	
2	J50-K7511-00	BUMPER, front 1	1	
3	97395-06020	BOLT	2	
4	92990-06100	WASHER, spring	2	
5	90201-06697	WASHER, plate	2	
6	90267-47150	RIVET, blind	2	
7	97313-08020	BOLT	8	
8	92902-08100	WASHER, spring	8	
9	92990-08600	WASHER, plate	8	
10	J50-K7541-00	BUMPER, rear 1	1	
11	97395-06020	BOLT	2	
12	92990-06100	WASHER, spring	2	
13	90201-06697	WASHER, plate	2	
14	90267-47150	RIVET, blind	2	
15	97313-08020	BOLT	4	
16	92902-08100	WASHER, spring	4	
17	92990-08600	WASHER, plate	4	
18	J50-K7551-00	PROTECTOR 1	1	
19	90267-63047	RIVET, blind	3	
20	J50-K8183-00	PLATE, side sill (L.H)	1	
21	J50-K8184-00	PLATE, side sill (R.H)	1	
22	90267-48139	RIVET, blind	16	
23	J55-K818A-00	PROTECTOR, side plate	2	J38-7818A-00
24	J38-7818E-00	CAP, protector end 1	2	
25	J38-7818F-00	CAP, protector end 2	2	
26	92606-06014	SCREW, oval head	8	
27	J50-F251G-00	SUPPORT, front bumper	2	
28	J50-78215-00	PLATE, side trim	1	



J50100-9230


FIG. 23 BUMPER

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
29	J50-7821F-00	PLATE, side trim	1	
30	90267-40054	RIVET, blind	4	



FWD
J50100-9230


FIG. 24 INSTRUMENT PANEL



J50100-9240

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	J50-77711-00	PANEL, instrument	1	
2	J50-77768-00	LABEL, warning	1	
3	92506-06016	SCREW, pan head	6	
4	92906-06100	WASHER, spring	6	
5	90201-08059	WASHER, plate	6	
6	J50-K7735-00	BOX, glove	1	
7	92506-06016	SCREW, pan head	1	
8	92906-06100	WASHER, spring	1	
9	90201-08059	WASHER, plate	1	
10	90183-05050	NUT, spring	3	
11	97706-50520	SCREW, tapping	3	
12	90201-05721	WASHER, plate	3	
13	J50-K7736-00	LID, glove box	1	
14	90269-08058	RIVET	3	
15	97706-50520	SCREW, tapping	3	
16	90201-05721	WASHER, plate	3	
17	J50-7773E-00	KEY, glove box lid	1	
18	J50-77721-00	BRACKET 1	1	
19	J50-77728-00	WASHER	1	UN
20	98906-05016	SCREW, bind	2	
21	J50-K7780-00	DASH PANEL ASSY	1	
22	90480-12529	GROMMET	1	
23	98906-06016	SCREW, bind	2	
24	90201-06687	WASHER, plate	4	
25	92502-06016	SCREW, pan head	4	
26	92990-06100	WASHER, spring	4	
27	J50-K7732-00	COVER, steering shaft 1	1	
28	J50-K7733-00	COVER, steering shaft 2	1	

FIG. 24 INSTRUMENT PANEL




J50100-9240

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
29	97702-50120	SCREW, tapping	2	
30	92901-05600	WASHER, plate	6	
31	97702-50130	SCREW, tapping	2	
32	97702-50540	SCREW, tapping	4	
33	J50-77741-00	INDICATOR 1	1	
34	J42-77742-00	INDICATOR 2	1	
35	J50-78245-00	SEAL 1	1	
36	J50-78246-00	SEAL, floor 2	2	
37	J50-78247-00	SEAL 3	1	
38	J50-78280-00	ASH TRAY ASSY	1	
39	J50-78281-00	BRACKET, ash tray	1	
40	98506-05010	SCREW, pan head	3	
41	J50-2837X-00	GRILL, air outlet 3	2	
42	J50-78283-00	COVER, 3	1	
43	90465-13169	CLAMP	1	
44	98501-05010	SCREW, pan head	2	
45	92990-05100	WASHER, spring	2	
46	92901-05600	WASHER, plate	2	
47	J50-K8231-00	MAT, main floor 1	1	
48	J50-K8232-00	MAT, main floor 2	1	
49	J50-K8233-00	MAT, main floor 3	1	
50	J50-K8234-00	MAT, main floor 4	1	
51	90267-63047	RIVET, blind	16	
52	90269-07064	RIVET	4	
53	J65-K8271-00	SERVICE LID, pedal	1	J38-78271-02
54	J50-78261-00	PLATE, body protect 1	2	
55	90267-40131	RIVET, blind	6	


FIG. 25 BODY

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	J50-K819A-00	SHELL, front storage	1	
2	J50-77532-00	BRACKET, front (R.H)	1	
3	J50-77533-00	BRACKET, rear (L.H)	1	
4	90110-06102	BOLT, hexagon socket head	2	
5	J50-78248-00	SEAL 4	2	
6	25G-21578-00	EMBLEM	1	
7	J50-7815G-00	SEAL, front storage	1	
8	J50-7814W-00	BRACKET, body lock	1	
9	J50-7814H-00	HOOK, body lock	1	
10	90508-15752	SPRING, torsion	1	
11	90387-055U1	COLLAR	1	
12	90105-05126	BOLT, washer based	1	
13	95701-05500	NUT, flange	1	
14	J50-78118-00	PLATE 2	2	
15	97002-05012	BOLT	4	
16	92990-05100	WASHER, spring	4	
17	90480-12067	GROMMET	1	
18	90480-12480	GROMMET	1	
19	J50-7814G-00	LEVER, body lock	1	
20	90240-03089	PIN, clevis	1	
21	91402-12018	PIN, cotter	1	
22	J50-K8216-00	COVER, bumper gap	1	
23	90267-48101	RIVET, blind	3	
24	J50-78316-00	DAMPER	2	
25	J50-78375-00	SUPPORT 1	1	
26	J50-78376-00	SUPPORT 2	1	
27	95801-06016	BOLT, flange	4	
28	J50-K810E-00	FRONT STORAGE LID COMP.	1	



 J50100-9250

FIG. 25 BODY




REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
29	97313-08020	BOLT	2	
30	92902-08100	WASHER, spring	2	
31	90201-08748	WASHER, plate	2	
32	90338-24112	PLUG	1	
33	90202-09194	WASHER, plate	2	
34	J50-7814E-00	SEAL, body side 1	1	
35	J50-7814F-00	SEAL, body side 2	1	
36	J50-7811A-00	TRIM, upper cowl	1	
37	90183-04005	NUT, spring	2	
38	J50-7816J-00	TRIM, front body 1	1	
39	90183-04005	NUT, spring	2	
40	J50-7816K-00	TRIM, front body 2	1	
41	90183-04005	NUT, spring	2	



J50100-9250

FIG. 26 BODY 2




REF. NO.	PART NO.	DESCRIPTION	QTY	REMARKS
1	J50-K811J-00	BASE, head light	1	
2	98901-08016	SCREW, bind	5	
3	J50-K7251-00	COVER, headlight	1	
4	90183-06057	NUT, spring	4	
5	98906-06014	SCREW, bind	4	
6	J50-7811L-00	TRIM, cowl side (L.H)	2	
7	J50-K817A-00	COVER, front pillar (L.H)	1	
8	J50-K817E-00	COVER, front pillar (R.H)	1	
9	90269-06063	RIVET	4	
10	J50-7817J-00	TRIM, side panel 2	1	
11	J50-7817H-00	TRIM, side panel 1	1	
12	90267-48059	RIVET, blind	8	
13	90201-05725	WASHER, plate	4	
14	J50-78214-00	GRIP, hand	2	
15	98501-05016	SCREW, pan head	4	
16	92990-05100	WASHER, spring	4	
17	92901-05600	WASHER, plate	4	
18	J50-78274-00	COVER, hole 2	4	
19	J50-K7211-00	WINDSHIELD	1	
20	J50-77213-00	TRIM, upper	1	



J50100-9260


FIG. 27 BODY 3

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	J50-K8142-00	PANEL, rear body	1	
2	J50-78291-01	EMBLEM 1	2	
3	J50-77743-00	INDICATOR 3	1	
4	J50-78251-00	PAD, silencer 1	1	
5	J50-78252-00	PAD, silencer 2	1	
6	J50-78253-00	PAD, silencer 3	2	
7	J50-78255-00	PAD, silencer 5	1	
8	90110-06102	BOLT, hexagon socket head	2	
9	J50-7824E-00	TRIM, rear body (L.H)	1	
10	90183-04005	NUT, spring	2	
11	J50-7824F-00	TRIM, rear body (R.H)	1	
12	90183-04005	NUT, spring	2	
13	J50-78427-00	HINGE, seat 2	2	
14	90151-06010	SCREW, countersunk	4	
15	90183-06028	NUT, spring	2	
16	90201-06050	WASHER, plate	2	
17	92501-06020	SCREW, pan head	2	
18	92990-06100	WASHER, spring	2	
19	J50-7827A-00	GUIDE 1	1	
20	90267-40054	RIVET, blind	2	
21	1HX-21780-00	LOCK ASSY	1	
22	97706-40510	SCREW, tapping	2	
23	1HX-2849E-00	HINGE 4	1	
24	90267-40054	RIVET, blind	2	
25	J50-7826A-00	PAD, body protect 1	1	
26	J50-K8272-00	COVER, fuel inlet	1	
27	J50-77764-01	LABEL, warning 4	1	
28	95308-05600	NUT	2	



J50100-9270


FIG. 27 BODY 3



J50100-9270

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
29	J50-H3368-00	STAY, flasher 1	1	
30	J50-H3369-00	STAY, flasher 2	1	
31	90110-06102	BOLT, hexagon socket head	8	
32	J50-K813F-00	COVER, side pillar (L.H)	1	
33	J50-K813G-00	COVER, side pillar (R.H)	1	
34	J50-7813W-00	BRACKET, cover 1	4	
35	J50-7813X-00	BRACKET, cover 2	4	
36	92501-06012	SCREW, pan head	8	
37	92990-06100	WASHER, spring	8	
38	92990-06200	WASHER, plain	16	
39	95303-06600	NUT	2	
40	97001-06012	BOLT	6	
41	92990-06100	WASHER, spring	6	
42	J50-K817F-00	COVER, rear pillar (L.H)	1	
43	J50-K817G-00	COVER, rear pillar (R.H)	1	
44	97780-50512	SCREW, tapping	12	
45	90267-48141	RIVET, blind	2	
46	J50-7818K-00	FLAP, front fender	1	
47	J50-K8191-00	PANEL, rear fender 1	1	
48	90267-48104	RIVET, blind	3	
49	J50-K8192-00	PANEL, rear fender 2	1	
50	90267-48104	RIVET, blind	3	
51	J50-78187-00	FLAP, front fender	1	
52	90267-49152	RIVET, blind	2	
53	90201-05033	WASHER, plate	2	
54	J50-78185-00	EXTENSION, front fender 1	1	
55	J50-78186-00	EXTENSION, front fender 2	1	
56	90267-48101	RIVET, blind	6	


FIG. 28 SUN ROOF



J50100-9280

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	J50-K8314-00	COVER, sun roof	1	
2	98980-08020	SCREW, bind	6	
3	92990-08200	WASHER, plain	6	
4	J50-K8312-00	SUPPORT, sun roof 1	1	
5	J50-K8313-00	SUPPORT, sun roof 2	1	
6	J50-K831A-00	SUPPORT, roof 3	1	
7	J50-78342-00	HOOK, support	6	
8	90269-06063	RIVET	14	
9	J50-K831G-00	STAY, sunroof cover 1	1	
10	J50-K831H-00	STAY, sunroof cover 2	1	
11	95821-08020	BOLT, flange	16	
12	90183-08051	NUT, spring	2	
13	J50-K8311-00	FRAME, sun roof	1	
14	J50-7831X-00	TRIM, roof 3	1	
15	J50-7831J-00	TRIM, roof	1	
16	J50-78315-00	TRIM, roof	1	
17	J50-26290-00	REAR VIEW MIRROR ASS'Y(RIGHT)	1	
18	98506-05016	SCREW, pan head	3	
19	J50-K8301-00	FRAME COMP., roof	1	
20	95701-08500	NUT, flange	4	
21	90201-084K3	WASHER, plate	4	
22	J50-7831L-00	REINFORCEMENT, roof support 1	2	
23	J50-7834E-00	HOLDER COMP. 1	1	
24	J50-7831U-00	PLATE, foot	1	
25	J50-7831K-00	END, roof trim	1	
26	J50-7831R-00	HOOK, end 3	2	
27	J50-78344-00	RETAINER 2	4	
28	98980-06014	SCREW, bind	2	


FIG. 28 SUN ROOF



J50100-9280

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
29	92990-06200	WASHER, plain	2	
30	95780-06300	NUT, flange	2	
31	90468-10050	CLIP	2	
32	90240-06005	PIN, clevis	2	
33	90201-06050	WASHER, plate	2	
34	90267-48138	RIVET, blind	4	
35	J50-78358-00	HOLDER 2	2	
36	JA9-52625-00	KNOB	1	
37	98608-03016	SCREW, oval head	2	
38	J50-7814A-00	SEAL, body upper	1	
39	J50-78316-00	DAMPER	2	
40	J50-78337-00	SEAL, side wind shield	1	
41	J50-7832F-00	GROMMET, roof support 1	1	
42	90201-05651	WASHER, plate	4	
43	90149-05282	SCREW	4	

FIG. 29 CARRIER




REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	J50-78351-00	SUPPORT, bag upper	1	
2	J50-78356-00	PAD, bag support	1	
3	J50-78355-00	BAND	1	
4	J38-78367-00	PLATE, anchor	1	
5	98980-06020	SCREW, bind	1	
6	92990-06100	WASHER, spring	1	
7	95380-06800	NUT	1	
8	92990-06200	WASHER, plain	1	
9	J10-78380-00	LOCK ASSY	2	
10	92580-06016	SCREW, pan head	4	
11	92990-06100	WASHER, spring	4	
12	92990-06600	WASHER, plate	4	
13	95380-06800	NUT	4	
14	92990-06200	WASHER, plain	4	
15	97011-08016	BOLT	4	
16	92902-08100	WASHER, spring	4	
17	J50-7836F-00	GROMMET	2	
18	J50-7831F-00	SUPPORT, roof 5	1	



J50100-9290

FIG. 30 SEAT


REF. NO.	PART NO.	DESCRIPTION	QTY	REMARKS
1	J50-K8451-00	FRAME, slide seat	1	
2	J50-78452-00	SEAT-ADJUSTER 1	1	
3	J50-78457-00	WIRE, adjuster	1	
4	J5Q-78453-00	SEAT-ADJUSTER 2	1	
5	95303-08600	NUT	4	
6	J50-K8421-00	SUPPORT, seat	1	
7	92580-06035	.SCREW, pan head	4	
8	95380-06800	.NUT	4	
9	92990-08600	WASHER, plate	2	
10	95380-08600	NUT	2	
11	97011-08016	BOLT	1	
12	92902-08100	WASHER, spring	1	
13	92990-08600	WASHER, plate	1	
14	J50-78361-00	ARM REST 1	2	
15	98680-05030	SCREW, oval head	2	
16	97780-50330	SCREW, tapping	2	
17	J50-K8401-00	SEAT SUB-ASSY,cushion	1	J42-78401-00
18	J50-K8403-00	SEAT SUB-ASSY, cushion 2	1	J42-78403-00
19	90201-065F3	WASHER, plate	8	
20	92503-06045	SCREW PAN HEAD	8	
21	J50-K8402-00	SEAT SUB ASSY, back	2	J42-78402-00
22	90152-06017	SCREW, countersunk	4	
23	97780-50116	SCREW, tapping	8	
24	J50-K8414-00	PLATE, seat bottom 1	1	
25	J50-78254-00	PAD, silencer 4	1	
26	J50-78425-01	SEAL, seat	1	
27	92990-08600	WASHER, plate	4	
28	95380-08600	NUT	4	



J50100-9300


FIG. 30 SEAT

REF. NO.	PART NO.	DESCRIPTION	QTY	REMARKS
29	J50-78417-00	KNOB, plate seat	2	
30	90201-08795	WASHER, plate	2	
31	90201-105H3	WASHER, plate	2	
32	J50-78139-00	CAP, end	2	



J50100-9300


FIG. 31 STARTING MOTOR



REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	J38-81100-10	STARTER GENERATOR ASSY	1	J38-81100-10
2	J10-81150-10	.ARMATURE ASSY	1	
3	J10-81157-10	.BEARING 1 (6202 SD)	1	
4	J10-81158-10	.BEARING 2 (6203 SD)	1	
5	J10-81159-10	.HOLDER, bearing	1	
6	J38-81110-10	.STATOR ASSY	1	
7	J38-81160-10	.FIELD COIL ASSY	1	
8	J10-81148-10	.SCREW 4	2	
9	95303-06600	..NUT	4	
10	92990-06600	..WASHER, plate	2	
11	92990-06100	..WASHER, spring	4	
12	J10-81148-10	.SCREW 2	4	
13	J38-81165-10	.BRACKET, starter generator 1	1	
14	J10-81166-10	.BRACKET, starter generator 2	1	
15	J10-81147-10	.SCREW 3	2	
16	95303-06600	..NUT	4	
17	92990-06600	..WASHER, plate	2	
18	92990-06100	..WASHER, spring	4	
19	J38-81119-10	.BRUSH HOLDER ASSY	1	
20	J38-81111-10	..BRUSH	4	
21	J38-81113-10	..SPRING, brush	4	
22	J10-81115-10	..WIRE, lead	2	
23	98501-05018	..SCREW, pan head	2	
24	98580-04010	..SCREW, pan head	4	
25	J38-81163-10	.KEY	1	
26	95302-14600	.NUT	1	
27	92901-14100	.WASHER, spring	1	
28	98501-05018	.SCREW, pan head	3	

J38110-5290


FIG. 31 STARTING MOTOR



REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
29	J10-81129-10	.COVER, brush	3	
30	J10-81139-10	.COVER, brush 2	1	
31	J10-81145-10	.SCREW 1	2	
32	92990-06600	.WASHER, plate	2	
33	92990-06100	.WASHER, spring	2	
34	J38-81161-10	.PULLEY	1	
35	90101-12545	BOLT	1	
36	92902-12600	WASHER, plate	2	
37	92901-12100	WASHER, spring	1	
38	95302-12600	NUT	1	

J38110-5290


FIG. 32 FLASHER LIGHT



REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	J50-83310-00	FRONT FLASHER LIGHT ASSY 1	1	
2	J50-83313-00	.GASKET, flasher lens	1	
3	J50-83311-00	.BULB, flasher	1	
4	J50-83312-00	.LENS, flasher	1	
5	97780-40535	.SCREW, tapping	2	
6	J50-83320-00	FRONT FLASHER LIGHT ASSY 2	1	
7	J50-83313-00	.GASKET, flasher lens	1	
8	J50-83311-00	.BULB, flasher	1	
9	J50-83322-00	.LENS, flasher 2	1	
10	97780-40535	.SCREW, tapping	2	
11	90183-04012	NUT, spring	4	
12	25G-83330-00	REAR FLASHER LIGHT ASSY 1	1	
13	25G-83332-00	.LENS, flasher (L.H)	1	
14	256-83311-70	.BULB (12V-27W)	1	
15	97780-40130	.SCREW, tapping	1	
16	25G-83340-00	REAR FLASHER LIGHT ASSY 2	1	
17	25G-83342-00	.LENS, flasher (R.H)	1	
18	256-83311-70	.BULB (12V-27W)	1	
19	97780-40130	.SCREW, tapping	1	
20	97780-60116	SCREW, tapping	4	

← FWD
J50100-9320

FIG. 33 HEADLIGHT




REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	J50-84315-00	RIM, headlight	2	
2	47J-84320-00	LENS ASSY	2	
3	17E-84314-00	BULB, headlight	2	
4	341-84393-40	HOLDER, bulb	2	
5	46X-84396-00	COVER	2	
6	43F-84131-00	SCREW, rim adjuster	4	
7	233-84127-60	WASHER, special	4	
8	341-84332-60	SPRING, screw	4	
9	47J-84334-00	NUT, adjusting	4	
10	5G2-84324-A0	SPRING, reflector	2	
11	98501-05010	SCREW, pan head	8	
12	92990-05100	WASHER, spring	8	



J50100-9330

FIG. 34 TAILLIGHT




REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	J50-84710-00	TAILLIGHT UNIT ASSY	2	
2	25G-84721-01	.LENS, taillight	1	
3	258-84714-61	.BULB (12V-27/8W)	1	
4	2E9-84524-00	.SCREW, lens fitting	2	
5	95701-06500	NUT, flange	4	
6	J50-84727-00	CORD, taillight	1	
7	J42-7717E-00	TAPE 1	4	



J50100-9340


FIG. 35 ELECTRICAL 1



J50100-9350

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	J38-81170-00	TENSIONER ASSY	1	
2	95821-08025	BOLT, flange	2	
3	90109-087A5	BOLT	1	
4	95701-08500	NUT, flange	1	
5	J55-H1173-00	BELT	1	J38-81173-00
6	J38-81350-20	ROTOR ASSY	1	
7	J38-85580-20	COIL, pulser	1	
8	98501-05016	SCREW, pan head	2	
9	92990-05100	WASHER, spring	2	
10	92901-05600	WASHER, plate	2	
11	J50-81910-00	VOLTAGE REGULATOR ASSY	1	
12	92501-06020	SCREW, pan head	2	
13	92990-06100	WASHER, spring	2	
14	92990-06600	WASHER, plate	2	
15	J38-81950-00	RELAY ASSY	1	
16	J41-81820-09	TERMINAL ASSY	1	
17	92902-08100	WASHER, spring	2	
18	95303-08700	NUT	2	
19	97021-06016	BOLT	2	
20	92990-06100	WASHER, spring	2	
21	92990-06600	WASHER, plate	2	


FIG. 36 ELECTRICAL 2



J50100-9360

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	J17-82133-00	SCREW, fitting	2	
2	J55-H2138-00	PLATE, battery fitting	1	J17-82136-00
3	92990-06200	WASHER, plain	2	
4	95701-06300	NUT, nylon	2	
5	J50-H2115-00	WIRE, plus lead	1	
6	J50-H2116-00	WIRE, minus lead	1	
7	J50-H2117-00	WIRE, lead	1	
8	90464-23041	CLAMP	1	
9	J50-82590-00	WIRE HARNESS ASSY	1	
10	42X-82151-00	.FUSE (10A)	4	
11	36Y-82151-00	.FUSE (15A)	2	
12	3K7-81980-00	.DIODE ASSY	2	
13	J38-82305-20	IGNITOR UNIT ASSY	1	
14	J38-82310-20	IGNITION COIL ASSY	1	
15	98501-05020	SCREW, pan head	2	
16	92990-05100	WASHER, spring	2	
17	J38-82318-00	WIRE, sub-lead	1	
18	8K1-82370-20	PLUG CAP ASSY	1	
19	J38-82372-00	SEAL, plug cap	1	
20	J42-82150-50	FUSE HOLDER ASSY	1	
21	J42-82150-50	FUSE HOLDER ASSY	1	
22	J50-82510-00	MAIN SWITCH ASSY	1	
23	J41-82550-00	ENGINE STOP SWITCH ASSY	1	
24	90465-06038	CLAMP	1	
25	J38-85720-00	OIL LEVEL GAUGE ASSY	1	
26	97001-06020	BOLT	2	
27	92990-06100	WASHER, spring	2	
28	92990-06600	WASHER, plate	2	


FIG. 36 ELECTRICAL 2



J50100-9360

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
29	J38-82598-00	GROMMET	1	
30	J50-82530-00	STOP SWITCH ASSY	1	
31	J42-83975-00	SWITCH, handle 2	1	
32	J50-82580-00	WIRE HARNESS ASSY 2	1	
33	26G-83936-00	BAND, switch cord	1	
34	J38-82617-00	SWITCH	1	
35	98511-04025	SCREW, pan head	1	
36	92902-04100	WASHER, spring	1	
37	92901-04600	WASHER, plate	1	
38	J13-25656-00	BRACKET, stop light switch	1	
39	95303-06600	NUT	1	
40	97021-06016	BOLT	1	
41	92990-06100	WASHER, spring	1	

FIG. 37 ELECTRICAL 3



J50100-9370

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	J10-83383-02	BUZZER	1	
2	97021-06016	BOLT	1	
3	92990-06100	WASHER, spring	1	
4	92990-06600	WASHER, plate	1	
5	1HX-83371-00	HORN	1	
6	97001-06012	BOLT	1	
7	92990-06100	WASHER, spring	1	
8	95702-06600	NUT, with washer	1	
9	J50-83530-00	PILOT LIGHT ASSY	1	
10	4G1-84744-00	.BULB (12V-3.4W)	6	
11	98580-04010	SCREW, pan head	2	
12	92902-04100	WASHER, spring	2	
13	J50-83514-00	PLATE, fitting	2	
14	50V-83350-20	FLASHER RELAY ASSY	1	
15	J42-85590-01	CONTROL UNIT ASSY	1	

NUMERICAL INDEX

PART NO.	GRID NO.	PART NO.	GRID NO.
J55-F1419-00	9- 2	J50-K8184-00	23-21
J50-F2110-00	10- 1	J50-K819A-00	25- 1
J50-F2201-00	10-13	J50-K8191-00	27-47
J50-F2501-00	11- 1	J50-K8192-00	27-49
J50-F251G-00	23-27	J50-K8216-00	25-22
J50-F330E-00	12-21	J50-K8231-00	24-47
J50-F3838-00	13- 7	J50-K8232-00	24-48
J50-F4110-00	14- 1	J50-K8233-00	24-49
J50-F5110-00	12-25	J50-K8234-00	24-50
J50-F6311-00	17-16	J55-K8271-00	24-53
J50-F6331-00	5-34	J50-K8272-00	27-26
J50-F6341-00	15-52	J50-K8301-00	28-19
J50-F6351-00	15-53	J50-K831A-00	28- 6
J50-G6241-00	19-16	J50-K831G-00	28- 9
J55-G6260-00	20- 1	J50-K831H-00	28-10
J55-G6270-00	20- 2	J50-K8311-00	28-13
J50-G6371-00	21-62	J50-K8312-00	28- 4
J55-G6383-00	21-63	J50-K8313-00	28- 5
J55-G6521-00	22-12	J50-K8314-00	28- 1
J55-H1173-00	35- 5	J50-K8357-00	13-16
J50-H2115-00	36- 5	J50-K8358-00	13-17
J50-H2116-00	36- 6	J50-K8401-00	30-17
J50-H2117-00	36- 7	J50-K8402-00	30-21
J55-H2136-00	36- 2	J50-K8403-00	30-18
J50-H3368-00	27-29	J50-K8414-00	30-24
J50-H3369-00	27-30	J50-K8421-00	30- 6
J50-K7211-00	26-19	J50-K8451-00	30- 1
J50-K7251-00	26- 3	J17-W2536-00	16- 2
J50-K7511-00	23- 2		16-17
J50-K7541-00	23-10	J17-W2561-00	15-16
J50-K7551-00	23-18	J38-11102-00	1- 1
J50-K7732-00	24-27	J38-11116-00	1-10
J50-K7733-00	24-28	J38-11133-09	1- 2
J50-K7735-00	24- 6	J38-11181-00	1- 6
J50-K7736-00	24-13	J38-11191-00	1- 9
J50-K7780-00	24-21	J38-11193-00	1-12
J50-K810E-00	25-28	812-11198-00	8-17
J50-K811J-00	26- 1	J38-11355-00	8-30
J50-K813F-00	27-32	J38-11400-00	2- 1
J50-K813G-00	27-33	J38-11496-00	2-15
J50-K8142-00	27- 1	J38-11500-00	2-14
J50-K8163-00	23- 1	J38-11531-00	2-18
J50-K817A-00	26- 7	J38-11610-00	2- 3
J50-K817E-00	26- 8	J38-11610-10	2- 3
J50-K817F-00	27-42	J38-11610-20	2- 3
J50-K817G-00	27-43	J38-11631-01-A0	2- 2
J55-K818A-00	23-23	7A9-11633-00	2- 4
J50-K8183-00	23-20	J38-11635-01	2- 2

PART NO.	GRID NO.	PART NO.	GRID NO.
J38-11636-01	2- 2	J38-11650-00	2- 6
J38-11650-00	2- 6	J38-11654-00	2- 7
J38-11654-00	2- 9	J38-11656-00	2- 9
J38-11656-00	2- 9	J38-11656-10	2- 9
J38-11656-10	2- 9	J38-11656-20	2- 9
J38-11656-20	2-10	J38-11657-00	2-10
J38-11657-00	3- 1	J38-12111-01	3- 1
J38-12111-01	3- 4	J38-12117-01	3- 4
J38-12117-01	3- 5	J38-12118-00	3- 5
J38-12118-00	3-16	5H0-12119-00	3-16
5H0-12119-00	3- 2	J38-12121-01	3- 2
J38-12121-01	3- 6	J38-12151-01	3- 6
J38-12151-01	3-13	J38-12152-00	3-13
J38-12152-00	3-10	J38-12153-00	3-10
J38-12153-00	3- 9	J38-12154-00	3- 9
J38-12154-00	3- 8	J38-12156-00	3- 8
J38-12156-00	3-12	J38-12159-00	3-12
J38-12159-00	3- 7	J38-12161-01	3- 7
J38-12161-01	3-11	J38-12171-00	3-11
J38-12171-00	4- 1	J38-12621-01	4- 1
J38-12621-01	4- 4	J38-12640-00	4- 4
J38-12640-00	4- 5	J38-12651-01	4- 5
J38-12651-01	4- 6	J38-12652-00	4- 6
J38-12652-00	8-20	J38-13115-00	8-20
J38-13115-00	8-24	J38-13161-00	8-24
J38-13161-00	5- 1	J38-13556-00	5- 1
J38-13556-00	5- 3	J38-13557-00	5- 3
J38-13557-00	5- 2	J38-13596-00	5- 2
J38-13596-00	6- 1	J50-14101-00	6- 1
J50-14101-00	6- 7	J10-14122-00	6- 7
J10-14122-00	6-11	J38-14133-00	6-11
J38-14133-00	6-23	J38-14141-00	6-23
J38-14141-00	6-10	620-14142-67	6-10
620-14142-67	6-10	620-14142-72	6-10
620-14142-72	6-22	J38-14150-00	6-22
J38-14150-00	6-20	7R1-14162-00	6-20
7R1-14162-00	6-18	796-14184-00	6-18
796-14184-00	6- 9	J38-14185-00	6- 9
J38-14185-00	6- 8	J38-14186-00	6- 8
J38-14186-00	6-19	127-14198-00	6-19
127-14198-00	6- 5	75G-14211-00	6- 5
75G-14211-00	6- 6	620-14212-00	6- 6
620-14212-00	6-17	3G2-1423E-41	6-17
3G2-1423E-41	6-17	3G2-1423E-42	6-17
3G2-1423E-42	6- 4	J38-14243-00	6- 4
J38-14243-00	6-16	J38-14291-00	6-16
J38-14291-00	8-19	J38-14388-00	8-19

PART NO.	GRID NO.	PART NO.	GRID NO.
J38-1441F-00	5-23	J38-14411-00	5-11
J38-14411-00	5-13	J38-14412-00	5-13
J38-14412-00	5-22	J38-14416-00	5-22
J38-14416-00	5-25	J10-14417-00	5-25
J10-14417-00	5-18	J38-14419-00	5-18
J38-14419-00	5-21	J10-14436-00	5-21
J10-14436-00	5-16	J38-14450-00	5-16
J38-14450-00	5- 8	J38-14463-00	5- 8
J38-14463-00	5-26	J38-1446A-00	5-26
J38-1446A-00	5-14	55K-14476-00	5-14
55K-14476-00	5-17	J38-14479-00	5-17
J38-14479-00	5-16	J38-14484-00	5-16
J38-14484-00	6-12	J38-14581-00	6-12
J38-14581-00	6-21	J10-14597-00	6-21
J10-14597-00	7- 2	J38-14613-00	7- 2
J38-14613-00	7- 1	J38-14710-01	7- 1
J38-14710-01	7- 5	J38-14771-00	7- 5
J38-14771-00	8- 1	J38-15100-02	8- 1
J38-15100-02	8-10	J38-15112-00	8-10
J38-15112-00	8- 4	J38-15123-00	8- 4
J38-15123-00	8- 2	J38-15148-00	8- 2
J38-15148-00	8- 3	J38-15155-00	8- 3
J38-15155-00	8- 8	J38-15361-00	8- 8
J38-15361-00	8-11	J38-15363-00	8-11
J38-15363-00	8- 9	J38-15411-01	8- 9
J38-15411-01	8-18	J38-15451-00	8-18
J38-15451-00	20- 5	J17-17688-00	20- 5
J17-17688-00	9-15	J38-2141A-00	9-15
J38-2141A-00	9- 1	J38-21411-02	9- 1
J38-21411-02	9- 7	J38-21486-00	9- 7
J38-21486-00	9- 8	J38-21488-00	9- 8
J38-21488-00	25- 6	25G-21578-00	25- 6
25G-21578-00	14-10	J10-21773-00	14-10
J10-21773-00	27-21	1HX-21780-00	27-21
1HX-21780-00	10- 2	J50-22123-00	10- 2
J50-22123-00	10- 5	J50-22124-00	10- 5
J50-22124-00	10-10		10-10
	9-12	J17-2214F-00	9-12
J17-2214F-00	9-11	J31-2217J-01	9-11
J31-2217J-01	10- 4	J50-22171-00	10- 4
J50-22171-00	10- 9	J50-22172-00	10- 9
J50-22172-00	15-39	J55-2252M-00	15-39
J55-2252M-00	11- 2	J50-22571-00	11- 2
J50-22571-00	11- 3	J50-22572-00	11- 3
J50-22572-00	12-22	J50-23384-00	12-22
J50-23384-00	13-24	J50-23400-00	13-24
J50-23400-00	13-51	J50-23427-00	13-51

NUMERICAL INDEX

PART NO.	GRID NO.	PART NO.	GRID NO.
J50-23447-00	13-37	J13-25656-00	36-35
J50-23507-00	12- 1	J17-25670-01	15- 4
J50-23508-00	12-11	J17-25672-00	15-22
J51-23511-00	12- 5	J17-25673-00	15-27
	12-15		15-43
J50-23512-00	12- 6	J17-25679-01	15-14
J50-23522-00	12-16	J10-25681-00	15-45
J38-23526-00	12- 2	J50-25685-00	15-46
	12-12	J50-26290-00	28-17
J50-23811-00	13- 1	J38-26312-00	5-30
J50-23814-00	13- 3	J38-27204-00	16- 4
J50-23822-00	13-47	J38-27205-00	16-19
J50-23823-00	13-49	J17-27206-00	16- 3
J50-23824-00	13-25		16-18
J50-23828-00	13- 2	J17-27208-00	16- 1
J50-23831-00	13-39	J17-27209-00	16-16
J50-23832-00	13-48	J10-27211-00	15- 3
J50-23833-00	13-42	J17-27221-00	15-18
J50-23834-00	13-32	J17-27228-00	15-28
J50-23837-00	13-40	J17-27231-00	15-23
J42-23839-00	13- 8	J17-27232-00	15-24
J50-2384L-00	13-43	J17-27238-00	16- 9
J50-2384M-00	13-31	J46-27245-00	15-35
J50-2384N-00	13-38	J17-27246-00	15-40
J50-23841-00	13-41	J46-27250-01	15- 1
J50-23844-00	13-30	J17-27258-00	16-24
J50-23857-00	13- 4	J10-27281-00	16- 5
J50-2387A-00	13-26		16-20
J50-2387E-00	13-27	J10-27282-00	16- 6
J50-2387F-00	13-28		16-21
J50-2387G-00	13-29	J10-27286-00	16-11
J50-2387H-00	13-34		16-26
J50-2387J-00	13-35	J17-27853-00	17- 2
J50-2387K-00	13-36	J14-27871-00	17- 6
J50-23876-00	13-50	J38-27872-00	17- 3
J50-23894-00	13-33	J38-27874-00	17- 1
J50-24112-00	14- 3	J10-27911-00	18-13
J50-24311-00	14-19	J10-27912-00	18-10
807-24376-00	8-27	J10-27913-00	18-12
J50-24410-00	14-15	J38-27921-00	18-17
J24-24460-01	14- 9	J10-27922-00	18-18
J38-24461-00	1-11	J10-27927-00	18-14
8R4-24560-00	14- 6	J38-27951-00	18- 1
8F3-24564-00	14- 7	J38-27959-00	18- 5
J50-24611-00	14- 2	J38-27981-00	17-21
J50-24620-00	14- 5	J38-27982-00	18- 7
J17-25118-00	12-30	J50-2837X-00	24-41
J50-25183-00	12-27	1HX-2849E-00	27-23

NUMERICAL INDEX

PART NO.	GRID NO.	PART NO.	GRID NO.	PART NO.	GRID NO.
J38-46205-01	19- 9	J42-77742-00	24-34	J50-78281-00	24-39
J38-46210-00	19- 1	J50-77743-00	27- 3	J50-78283-00	24-42
J38-46220-00	19- 2	J50-77762-00	13-21	J50-78291-01	27- 2
J38-46231-00	19- 8	J38-77763-00	13-20	J50-7831F-00	29-18
J38-46236-00	19-10	J50-77764-01	27-27	J50-7831J-00	28-15
J38-46237-00	19-11	J50-77768-00	24- 2	J50-7831K-00	28-25
J38-46249-00	19-15	J50-7811A-00	25-36	J50-7831L-00	28-22
J38-46251-00	19- 7	J50-7811L-00	26- 6	J50-7831R-00	28-26
J38-46253-00	19- 4	J50-78118-00	25-14	J50-7831U-00	28-24
J38-46284-00	20- 4	J50-7813W-00	27-34	J50-7831X-00	28-14
J38-46311-00	21- 1	J50-7813X-00	27-35	J50-78315-00	28-16
J38-46312-00	21- 7	J50-78139-00	30-32	J50-78316-00	25-24
J38-46319-00	21-12	J50-7814A-00	28-38	J50-7832F-00	28-39
J38-46321-02	21-21	J50-7814E-00	25-34	J50-78337-00	28-41
J38-4633A-00	21-42	J50-7814F-00	25-35	J50-7834E-00	28-40
J38-46331-01	21-22	J50-7814G-00	25-19	J50-7834E-00	28-23
J38-46338-00	21-43	J50-7814H-00	25- 9	J50-78342-00	28- 7
J38-46348-00	21-39	J50-7814W-00	25- 8	J50-78344-00	28-27
J38-46351-00	21-23	J50-7815G-00	25- 7	J50-78351-00	29- 1
J38-46356-00	21-40	J50-7816J-00	25-38	J50-78355-00	29- 3
J38-4636A-00	21-27	J50-7816K-00	25-40	J50-78356-00	29- 2
J38-46361-01	21-24	J50-7817H-00	26-11	J50-78358-00	28-35
J38-46362-00	21-25	J50-7817J-00	26-10	J50-7836F-00	29-17
J38-46363-00	21-26	J38-7818E-00	23-24	J50-78361-00	30-14
J50-46382-00	21-64	J38-7818F-00	23-25	J38-78367-00	29- 4
J38-46384-00	21-49	J50-7818K-00	27-46	J50-78375-00	25-25
J50-46394-00	21-69	J50-78185-00	27-54	J50-78376-00	25-26
J38-46411-01	21-31	J50-78186-00	27-55	J10-78380-00	29- 9
J38-46414-00	21-33	J50-78187-00	27-51	J50-78417-00	30-29
J38-46415-00	21-34	J50-7821F-00	23-29	J50-78425-01	30-26
J38-46417-02	21-35	J50-78214-00	26-14	J50-78427-00	27-13
J38-46421-01	21-32	J50-78215-00	23-28	J50-78452-00	30- 2
J50-46510-00	22- 3	J50-7824E-00	27- 9	J50-78453-00	30- 4
J50-46520-00	22- 4	J50-7824F-00	27-11	J50-78457-00	30- 3
J50-46540-00	22- 1	J50-78245-00	24-35	J38-81100-10	31- 1
J50-46550-00	22- 2	J50-78246-00	24-36	J38-81110-10	31- 6
835-47559-00	21-55	J50-78247-00	24-37	J38-81111-10	31-20
JA9-52625-00	28-36	J50-78248-00	25- 5	J38-81113-10	31-21
7Y6-52625-00	21-68	J50-78251-00	27- 4	J10-81115-10	31-22
J42-7717E-00	34- 7	J50-78252-00	27- 5	J38-81119-10	31-19
J50-77213-00	26-20	J50-78253-00	27- 6	J10-81129-10	31-29
J50-77532-00	25- 2	J50-78254-00	30-25	J10-81139-10	31-30
J50-77533-00	25- 3	J50-78255-00	27- 7	J10-81145-10	31-31
J50-77711-00	24- 1	J50-7826A-00	27-25	J10-81146-10	31-12
J50-77721-00	24-18	J50-78261-00	24-54	J10-81147-10	31-15
J50-77728-00	24-19	J50-7827A-00	27-19	J10-81148-10	31- 8
J50-7773E-00	24-17	J50-78274-00	26-18	J10-81150-10	31- 2
J50-77741-00	24-33	J50-78280-00	24-38	J10-81157-10	31- 3

NUMERICAL INDEX

PART NO.	GRID NO.	PART NO.	GRID NO.	PART NO.	GRID NO.
J10-81158-10	31- 4	J50-83530-00	37- 9	90159-05117	8- 5
J10-81159-10	31- 5	25G-83936-00	36-33	90170-06128	3-17
J38-81160-10	31- 7	J42-83975-00	36-31	90170-16182	2-13
J38-81161-10	31-34	233-84127-60	33- 7	90171-10004	12-33
J38-81163-10	31-25	43F-84131-00	33- 6		13-45
J38-81165-10	31-13	17E-84314-00	33- 3	90179-07564	15- 9
J10-81166-10	31-14	J50-84315-00	33- 1	90179-08261	15-50
J38-81170-00	35- 1	47J-84320-00	33- 2	90179-08327	2- 8
J38-81350-20	35- 6	5G2-84324-A0	33-10	90179-08378	15-13
J50-81910-00	35-11	341-84332-60	33- 8	90179-12262	12-36
J41-81920-09	35-16	47J-84334-00	33- 9		22-11
J38-81950-00	35-15	341-84393-40	33- 4	90183-04005	25-37
3K7-81980-00	36-12	46X-84396-00	33- 5		25-39
J17-82133-00	36- 1	2E9-84524-00	34- 4		25-41
J42-82150-50	36-20	J50-84710-00	34- 1		27-10
	36-21	256-84714-61	34- 3		27-12
42X-82151-00	36-10	25G-84721-01	34- 2	90183-04012	32-11
36Y-82151-00	36-11	J50-84727-00	34- 6	90183-05050	24-10
J38-82305-20	36-13	4G1-84744-00	37-10	90183-06028	27-15
J38-82310-20	36-14	J38-85580-20	35- 7	90183-06057	26- 4
J38-82318-00	36-17	J42-85590-01	37-15	90183-08051	28-12
8K1-82370-20	36-18	J38-85720-00	36-25	90185-10115	10- 3
J38-82372-00	36-19	J50-85752-00	14- 8		12- 4
J50-82510-00	36-22	90101-06555	15- 8		12-14
J50-82530-00	36-30	90101-08344	21-18	90185-12061	13-11
J41-82550-00	36-23		21-45	90185-12072	10- 7
J50-82580-00	36-32	90101-10447	15-37		10-12
J50-82590-00	36- 9	90101-12545	31-35		10-15
J38-82598-00	36-29	90101-12687	12- 7	90201-044A2	13-22
J38-82617-00	36-34		12-17	90201-05033	27-53
J50-83310-00	32- 1	90105-05126	25-12	90201-05651	28-42
J50-83311-00	32- 3	90105-08390	21-36	90201-05721	24-12
	32- 8	90106-08040	17- 9		24-16
256-83311-70	32-14	90109-06513	4- 9	90201-05725	26-13
	32-18	90109-08657	16-10	90201-06050	27-16
J50-83312-00	32- 4	90109-08659	16-25		28-33
J50-83313-00	32- 2	90109-08669	15-11	90201-06059	24- 5
	- 7	90109-087A5	35- 3		24- 9
J50-83320-00	32- 6	90110-06102	25- 4	90201-065F3	30-19
J50-83322-00	32- 9		27- 8	90201-06697	23- 5
25G-83330-00	32-12		27-31		23-13
25G-83332-00	32-13	90113-04050	19-12		24-24
25G-83340-00	32-16	90119-06097	5-28	90201-06778	9-13
25G-83342-00	32-17	90119-08119	7- 7	90201-08087	21-19
50V-83350-20	37-14	90149-05282	28-43		21-46
1HX-83371-00	37- 5	90151-08010	27-14	90201-084K3	28-21
J10-83383-02	37- 1	90152-06017	30-22	90201-084K7	14-12
J50-83514-00	37-13	90157-04092	18-19	90201-08748	25-31

NUMERICAL INDEX

PART NO.	GRID NO.	PART NO.	GRID NO.	PART NO.	GRID NO.
90201-08795	30-30	90269-08058	24-14	90467-10008	8-22
90201-104G8	15-34	90280-05013	2-11		8-26
90201-105H3	30-31	90280-05022	20- 8	90467-11009	14-20
90201-121H8	16-14	90338-24112	25-32	90467-12052	1-16
	16-29	90340-12097	8-16	90468-07179	5-37
90201-121H9	16-15	90340-14036	21-16	90468-08104	8-23
	16-30	90380-12051	15- 7	90468-10049	5-32
90201-12166	21-53	90380-12105	15-33		5-36
90201-123F2	15-31	90384-05163	15- 5		5-40
90201-12588	20- 9	90384-10162	15-17		17-18
90201-16245	13- 6	90384-12164	15- 6	90468-10050	28-31
90201-17713	21-41	90384-14080	15- 2	90480-12067	25-17
90201-201G9	2-19		17-11	90480-12480	25-18
90201-20275	18-16	90386-08141	18- 3	90480-12529	24-22
90201-204K8	21-28	90387-046N7	13-23	90480-13238	5-20
90201-257J2	21-29	90387-055U1	25-11	90480-14100	5-12
90202-07164	19-17	90387-07390	5-29	90480-18277	5-19
90202-07186	19-19	90387-076U6	19-18	90501-10060	21-47
90202-08110	18-20	90387-107F8	15-44	90501-21133	2-16
90202-09194	25-33	90387-152M7	2-21	90501-264A9	3- 3
90202-20130	20- 7	90387-155R3	2-20	90502-10013	13-18
90209-32271	12-31	90387-21690	18-11	90506-12277	15-26
90240-03089	25-20	90387-252M8	21-30	90506-20281	16- 7
90240-06005	28-32	90430-14043	21-17		16- 8
90249-07190	21-48	90445-09073	8-28	90506-26191	16-23
90249-14129	15-49	90445-09222	14-21		17-15
90267-40054	11- 4	90445-09304	14-23	90506-26282	15-21
	23-30	90445-110E6	8-25	90508-14548	15-21
	27-20	90445-113E4	8-21	90508-15752	25-10
	27-24	90445-130F8	1-15	90508-16460	17-19
90267-40073	5-24	90460-43279	5- 9	90508-23542	15-10
90267-40131	24-55	90460-53239	5-10	90508-26557	15-32
90267-47150	23- 6	90460-68230	14- 4	90508-40543	15-36
	23-14	90461-08106	21-70	90508-40678	18- 4
90267-48059	26-12	90461-12117	15-57	90508-45679	20- 6
90267-48101	25-23	90464-15093	8-31	90560-05001	17-20
	27-56	90464-16115	6-39	91316-06025	1-13
90267-48104	27-48	90464-23041	14-25	91401-25030	12-34
	27-50		36- 8		20-11
90267-48138	28-34	90464-26114	5-38	91402-12018	25-21
90267-48139	23-22	90465-06038	36-21	91402-20012	21-52
90267-48141	27-45	90465-06100	21-20	91402-20020	21-67
90267-49152	27-52	90465-08334	17-24	91402-25028	13-46
90267-63047	23-19	90465-13169	15-59	91490-25015	15-56
	24-51		24-43	91490-30015	15-48
90269-06063	26- 9	90467-08017	8-29	91609-35028	17- 5
	28- 8		14-22	91609-40020	21-44
90269-07084	24-52		14-24	91609-40040	21-38

NUMERICAL INDEX

PART NO.	GRID NO.	PART NO.	GRID NO.	PART NO.	GRID NO.
91609-60028	17- 4	92902-08100	21-66	92990-06200	29- 8
91701-05010	5-31	92902-08100	22- 6	92990-06200	29-14
91701-05010	5-35		23- 8		36- 3
	5-41		23-16	92990-06600	1-14
91701-06022	21-50		25-30		4- 8
91701-08018	15-55		29-16		5- 6
91701-10022	15-47		30-12		14-18
91702-05012	17-17		35-17		29-12
91810-09014	3-15	92902-12200	13-12		31-10
91812-16001	21-37	92902-12600	31-36		31-17
92501-06010	6-13	92906-06100	24- 4		31-32
92501-06012	27-36		24- 8		35-14
92501-06020	27-17	92990-04200	5-27		35-21
	35-12	92990-05100	6- 3		36-28
92501-06030	5- 4		24-45		37- 4
92502-06016	4- 7		25-16	92990-08100	7- 4
	24-25		26-16		12-24
92503-06045	30-20		33-12	92990-08200	13-13
92506-06016	24- 3		35- 9		15-15
	24- 7		36-16		28- 3
92580-06016	29-10	92990-06100	5- 5	92990-08600	23- 9
92580-06035	30- 7		6-14		23-17
92606-08014	14-14		14-14		30- 9
92901-04600	14-17		16-12		30-13
92901-05100	16-12		16-27	92990-10600	30-27
92901-05600	15-29		17- 8		9- 5
	24-30		17-14		15-19
	24-46		23- 4	92990-12100	22- 9
	26-17		23-12		12- 8
	35-10		24-26	93102-12224	12-18
92901-10100	9- 4		27-18	93102-20309	21-54
	22- 8		27-37	93102-22189	20- 3
92901-12100	10- 8		27-41		21- 6
	31-37		29- 6	93102-25017	21-11
92901-14100	31-27		29-11	93102-28348	21- 5
92901-16100	2-12		31-11	93102-30195	19- 3
92902-04100	13-10		31-18	93102-35191	8-13
	36-36		31-33	93102-35191	8- 7
	37-12		35-13	93102-35412	12-29
92902-08100	10-17		35-20	93109-08008	18-22
	12-10		36-27	93210-14104	17-12
	12-20		36-41	93306-00507	12-28
	13-14		37- 3	93306-00803	21- 4
	15-12		37- 7		21-10
	15-42		21-51	93306-20324	21- 8
	16-32	92990-06200	27-38	93306-20401	21- 3
	18- 9		28-29		21- 9
	21-58			93306-20541	21- 2

NUMERICAL INDEX

PART NO.	GRID NO.						
93306-20567	12-26	95701-08500	9-10	97090-08020	12-23	98980-08020	28- 2
93306-30621	8-12	95701-08500	28-20	97313-08020	15-41	99001-04600	15-30
93306-30709	8- 6		35- 4		23- 7	99001-06600	18-21
93342-22502	18-15	95702-06600	37- 8		23-15	99001-07600	5-33
93410-25017	21-60	95702-10500	9- 9		25-29	99002-07600	15-20
93450-19047	2- 5	95780-06300	28-30	97395-06020	23- 3	99002-09600	15-54
93605-10090	2-17	95801-06012	15-58		23-11	99009-16400	13- 5
93608-12063	8-14	95801-06016	25-27	97702-50120	24-29	99510-12016	1- 3
93700-06004	19- 6	95801-06020	4- 2	97702-50130	24-31		21-15
94701-00343	1- 8	95811-06030	3-14	97702-50540	24-32		
95021-10040	9- 6	95811-08035	8-15	97706-40510	27-22		
95026-10020	7- 6	95811-08040	21-13	97706-40525	13-19		
95302-12600	31-38		21-56	97706-50520	24-11		
95302-14600	31-26	95811-08050	21-14		24-15		
95303-06600	9-14	95811-08070	1- 4	97780-40130	32-15		
	16-13	95812-08045	1- 5		32-19		
	16-28	95812-10070	12- 3	97780-40535	32- 5		
	18- 2		12-13		32-10		
	27-39	95812-12055	10-14	97780-50116	30-23		
	31- 9	95812-12065	10- 6	97780-50330	30-16		
	31-16		10-11	97780-50512	27-44		
	36-39	95821-08020	28-11	97780-60116	32-20		
95303-06700	15-25	95821-08025	14-11	97780-60516	4- 3		
	17-23		35- 2	98501-05008	6- 2		
95303-08600	21-59	95822-10025	13-44		19-13		
	21-65	97001-06012	27-40	98501-05010	24-44		
	30- 5		37- 6		33-11		
95303-08700	15-51	97001-06020	36-26	98501-05016	26-15		
	17-10	97001-06025	17- 7		31-23		
	35-18		17-22		35- 8		
95306-05600	27-28	97002-05012	25-15	98501-05018	31-28		
95380-06800	29- 7	97011-06020	14-16	98501-05020	36-15		
	29-13	97011-08016	10-16	98506-05010	24-40		
	30- 8		18- 8	98506-05016	28-18		
95380-08600	7- 3		29-15	98511-04025	36-35		
	13-15		30-11	98580-04008	13- 9		
	30-10	97011-10025	9- 3	98580-04010	31-24		
	30-28	97012-08016	16-31		37-11		
95601-06200	5- 7	97012-08025	22- 5	98606-03016	28-37		
95601-12200	20-10	97021-06016	17-13	98680-05030	30-15		
95602-10100	15-38		35-19	98701-05008	6-15		
95602-14100	12-32		36-40	98901-05008	19- 5		
95611-08100	21-61		37- 2	98901-08016	26- 2		
95612-08618	1- 7	97022-06012	14-13	98906-05016	24-20		
95701-05500	25-13	97022-08040	12- 9	98906-06014	26- 5		
95701-06300	18- 6		12-19	98906-06016	24-23		
	36- 4	97022-08075	21-57	98980-06014	28-28		
95701-06500	34- 5	97022-10020	22- 7	98980-06020	29- 5		

NUMERICAL INDEX

PART NO.	GRID NO.	PART NO.	GRID NO.
----------	----------	----------	----------